

CDX-M620/M670

SERVICE MANUAL

Ver 1.0 2001. 03

US Model
CDX-M620/M670
AEP Model
UK Model
E Model
CDX-M670



- The tuner and CD sections have no adjustments.

SPECIFICATIONS

AUDIO POWER SPECIFICATIONS (US MODEL)

POWER OUTPUT AND TOTAL HARMONIC DISTORTION
23.2 watts per channel minimum continuous average power into 4 ohms, 4 channels driven from 20 Hz to 20 kHz with no more than 5% total harmonic distortion.

CD player section

Signal-to-noise ratio 90 dB
Frequency response 10 – 20,000 Hz
Wow and flutter Below measurable limit
Laser Diode Properties (US model)
Material GaAIAs
Wavelength 780 nm
Emission Duration Continuous
Laser output power Less than 44.6 μ W*

* This output is the value measured at a distance of 200 mm from the objective lens surface on the Optical Pick-up Block.

Tuner section

FM

Tuning range 87.5 – 107.9 MHz (US model)
87.5 – 108.0 MHz (AEP, UK, E model)
Antenna terminal External antenna connector
Intermediate frequency 10.7 MHz/450 kHz
Usable sensitivity 8 dBf
Selectivity 75 dB at 400 kHz
Signal-to-noise ratio 66 dB (stereo),
72 dB (mono)
Harmonic distortion at 1 kHz
0.6% (stereo),
0.3% (mono)
Separation 35 dB at 1 kHz
Frequency response 30 – 15,000 Hz

AM (US model)

Tuning range 530 – 1,710 kHz
Antenna terminal External antenna connector
Intermediate frequency 10.7 MHz/450 kHz
Sensitivity 30 μ V

Model Name Using Similar Mechanism	CDX-M700R/M750
CD Drive Mechanism Type	MG-383Z-121//K
Optical Pick-up Name	KSS-720A

MW/LW (AEP, UK, E model)

Tuning range MW: 531 – 1,602 kHz
LW: 153 – 279 kHz
Aerial terminal External aerial connector
Intermediate frequency 10.7 MHz/450 kHz
Sensitivity MW: 30 μ V
LW: 40 μ V

Power amplifier section

Outputs Speaker outputs (sure seal connectors)
Speaker impedance 4 – 8 ohms
Maximum power output 52 W \times 4 (at 4 ohms)

General

Outputs Audio outputs (front/rear)
Subwoofer output (mono)
Power antenna relay
control lead (US model)
Power aerial relay
control lead (AEP, UK, E model)
Power amplifier control
lead

– Continued on next page –

FM/AM COMPACT DISC PLAYER

CDX-M620/M670

FM/MW/LW COMPACT DISC PLAYER

CDX-M670

9-873-505-11
2001C0400-1
© 2001. 3

Sony Corporation
Audio Entertainment Group
General Engineering Dept.

SONY®

CDX-M620/M670

Inputs	Telephone ATT control lead Illumination control lead BUS control input connector BUS audio input connector Antenna input connector (US model) Aerial input connector (AEP, UK, E model) AUX IN connector (US model)
Tone controls	Bass ± 8 dB at 100 Hz Treble ± 8 dB at 10 Hz
Loudness	+8 dB at 100 Hz +2 dB at 10 Hz
Power requirements	12 V DC car battery (negative earth)
Dimensions	Approx. 178 × 50 × 182 mm (w/h/d)
Mounting dimensions	Approx. 182 × 53 × 160 mm (w/h/d)
Mass	Approx. 1.5 kg
Supplied accessories	Parts for installation and connections (1 set) Front panel case (1) Card remote commander RM-X110 (US model) RM-X111 (AEP, UK, E model)

Note

This unit cannot be connected to a digital preamplifier or an equalizer.

Design and specifications are subject to change without notice.

SERVICE NOTES

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic breakdown because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body. During repair, pay attention to electrostatic breakdown and also use the procedure in the printed matter which is included in the repair parts.

The flexible board is easily damaged and should be handled with care.

NOTES ON LASER DIODE EMISSION CHECK

The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe from more than 30 cm away from the objective lens.

Notes on Chip Component Replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK \triangle OR DOTTED LINE WITH MARK \triangle ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.


US model:

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

If the optical pick-up block is defective, please replace the whole optical pick-up block.

Never turn the semi-fixed resistor located at the side of optical pick-up block.



AEP/UK model:

**CLASS 1
LASER PRODUCT**

This label is located on the bottom of the chassis.

**CAUTION—INVISIBLE LASER RADIATION WHEN OPEN
DO NOT STARE INTO BEAM OR
VIEW DIRECTLY WITH OPTICAL INSTRUMENTS**


This label is located on the drive unit's internal chassis.

When replacing the chassis (T) of mechanism deck which have the "CAUTION LABEL" attached, please be sure to put a new CAUTION LABEL (3-223-913-11) to the chassis (T).

NOTE FOR THE OPENING OF THE FRONT PANEL

In this set, the front panel is lowered to below the bottom face when it is opened.

When servicing the set, place it on a stand having a height of about 2 cm.

**TEST MODE**

1. Turn on the power.
2. Push "4" on the card remote control for 2 sec.
3. Push "5" on the control for 2 sec.
4. Push "1" on the control for 2 sec.
(The TEST MODE is entered.)
5. Push the "OPEN/CLOSE" switch on the control for 2 sec.
6. The front panel detouch position is set.
(No display appears at this time.)
7. Turn off the power and disassemble the set.

TABLE OF CONTENTS

1. GENERAL	4
2. DISASSEMBLY	
2-1. Front Panel Assy (Normal)	16
2-2. Front Panel Assy (Inoperative)	16
2-3. CD Mechanism Block, Flexible Board	16
2-4. Sub Panel (CD) Sub Assy	17
2-5. Motor Block Assy, Cam (R) Assy	17
2-6. Main Board	18
2-7. Heat Sink	18
2-8. Chassis (T) Sub Assy	19
2-9. Lever Section	19
2-10. Servo Board	20
2-11. Shaft Roller Assy	20
2-12. Floating Block Assy	21
2-13. Optical Pick-up Block	21
3. PHASE ALIGNMENT	
3-1. Arm (A-L) Assy, Arm (B-L) Assy	22
3-2. Cam (L)	22
3-3. Motor Block	23
3-4. Alignment between Arm (A-L) Assy and Arm (B-L) Assy	23
3-5. Arm (A-R) Assy, Arm (B-R) Assy	24
3-6. Cam (R)	24
4. DIAGRAMS	
4-1. IC Pin Descriptions	25
4-2. Circuit Boards Location	33
4-3. Block Diagram –CD Section–	34
4-4. Block Diagram –Tuner Section–	35
4-5. Block Diagram –Display Section–	36
4-6. Printed Wiring Boards –CD Mechanism Section–	38
4-7. Schematic Diagram –CD Mechanism Section (1/2)–	40
4-8. Schematic Diagram –CD Mechanism Section (2/2)–	41
4-9. Printed Wiring Boards –Main Section–	42
4-10. Schematic Diagram –Main Section (1/4)–	44
4-11. Schematic Diagram –Main Section (2/4)–	45
4-12. Schematic Diagram –Main Section (3/4)–	46
4-13. Schematic Diagram –Main Section (4/4)–	47
4-14. Printed Wiring Board –Sub (CD) Section–	48
4-15. Schematic Diagram –Sub (CD) Section–	49
4-16. Printed Wiring Board –Key Section–	50
4-17. Schematic Diagram –Key Section–	51
4-18. Printed Wiring Board –Display Section–	52
4-19. Schematic Diagram –Display Section–	53
5. EXPLODED VIEWS	
5-1. Chassis Section	56
5-2. Cam Section	57
5-3. Main Board Section	58
5-4. Front Panel (Key) Assy Section	59
5-5. Front Panel (Dspl) Assy Section	60
5-6. CD Mechanism Section (1)	61
5-7. CD Mechanism Section (2)	62
5-8. CD Mechanism Section (3)	63
6. ELECTRICAL PARTS LIST	64


This section is extracted from instruction manual.

US MODEL

Location of controls


Card remote commander RM-X110

Refer to the pages listed for details.
CD/MD: During Playback **RADIO**: During radio reception **MENU**: During menu mode




- 1 SCRL (scroll) button 10
- 2 DSPL (display mode change) button 10, 12, 27
- 3 Number buttons
CD/MD
 ① REP 11
 ② SHUF 11
RADIO 14, 15
TV 28, 29
- 4 EQ7 button 17
- 5 MENU button 9, 11, 12, 13, 14, 15, 16, 17, 18, 19, 21, 22, 23, 25, 26, 27, 28, 30
- 6 SOURCE (Power on/Radio/CD/MD) button 9, 10, 12, 14, 15, 17, 18, 20, 21, 22, 25, 26, 27, 28, 30
- 7 ←/→ SEEK +/- buttons 19, 20, 21, 22
CD/MD 10, 14, 15
RADIO 14, 15
TV 28, 30
MENU 9, 11, 13, 17, 18, 19, 22, 23, 25, 26, 27
- 8 SOUND button 19, 20, 21, 22
- 9 OFF (Stop/Power off) button 10, 27, 30
- 10 VOL +/- buttons
- 11 OPEN/CLOSE button 10, 32
- 12 MODE button
CD/MD 10, 12
RADIO 14, 15
TV 28
- 13 DSO button 18
- 14 LIST button
CD/MD 12
RADIO 16
TV 28, 29
- 15 +/- DISC +/- buttons
CD/MD 10, 12
RADIO 14, 15, 16
TV 30
MENU 9, 11, 12, 13, 14, 16, 17, 18, 19, 21, 22, 23, 25, 26, 27, 28
- 16 ENTER button
CD/MD 12
RADIO 15, 16
MENU 9, 11, 12, 13, 14, 16, 17, 18, 21, 22, 23, 25, 26, 27, 28
- 17 ATT button 25

Main display panel



Operation side



The corresponding buttons of the unit control the same functions as those on the card remote commander.

- 1 OPEN button 8, 10, 32
- 2 Main display window
- 3 Receptor for the card remote commander
- 4 Reset button 8
- 5 Volume adjust buttons
- 6 SCRL (scroll) button
- 7 SOURCE button
- 8 DSPL (display mode change) button
- 9 Sub display window
- 10 DISC +/- (cursor up/down) buttons
- 11 SEEK +/- (cursor left/right) buttons
- 12 MENU button
- 13 LIST button
- 14 CLOSE (front panel close) button 8, 10
- 15 OFF (Stop/Power off) button*
- 16 MODE button
- 17 Number buttons
- 18 SOUND button
- 19 EQ7 button
- 20 ENTER button
- 21 DSO button
- 22 (eject) button 10, 30


continue to next page → 5

AEP, UK, E MODEL

Location of controls


Card remote commander RM-X111

Refer to the pages listed for details.
CD/MD: During Playback **RADIO**: During radio reception **MENU**: During menu mode




- 1 SCRL (scroll) button 12
- 2 DSPL/PTY (display mode change/ programme type) button 12, 13, 17, 20, 25, 35
- 3 Number buttons
CD/MD
 ① REP 12
 ② SHUF 12
RADIO 15, 16, 18, 19, 22, 24
- 4 EQ7 button 26
- 5 MENU button 10, 13, 14, 15, 19, 21, 23, 25, 26, 27, 28, 30, 31, 33, 34, 35
- 6 SOURCE (Power on/Radio/CD/MD) button 10, 11, 13, 15, 16, 19, 22, 26, 27, 29, 30, 31, 33, 35
- 7 ←/→ SEEK +/- buttons 10, 28, 29, 30, 31
CD/MD 11
RADIO 16, 18, 22
MENU 10, 13, 14, 15, 21, 23, 25, 26, 27, 28, 30, 31, 33, 34, 35
- 8 SOUND button 28, 29, 30, 31
- 9 OFF (Stop/Power off) button 11, 35
- 10 VOL +/- buttons 19
- 11 OPEN/CLOSE button 11, 37
- 12 AF button 18, 19
- 13 TA button 19
- 14 MODE button
CD/MD 11, 13
RADIO 15, 16, 19, 22
- 15 DSO button 27
- 16 LIST button
CD/MD 13, 14
RADIO 17, 24
- 17 +/- DISC +/- buttons
CD/MD 11, 14
RADIO 16, 17, 20, 22, 23, 24, 25
MENU 10, 13, 14, 15, 19, 21, 23, 25, 26, 27, 28, 30, 31, 33, 34, 35
- 18 ENTER button
CD/MD 14
RADIO 17, 20, 23, 24, 25
MENU 10, 13, 14, 15, 19, 21, 23, 25, 26, 27, 30, 31, 33, 34, 35
- 19 ATT button 33

Main display panel



Operation side



The corresponding buttons of the unit control the same functions as those on the card remote commander.

- 1 OPEN button 9, 11, 37
- 2 Main display window
- 3 Receptor for the card remote commander
- 4 Reset button 9
- 5 Volume adjust buttons
- 6 SCRL (scroll) button
- 7 SOURCE button
- 8 DSPL/PTY (display mode change/ programme type) button
- 9 Sub display window
- 10 DISC +/- (cursor up/down) buttons
- 11 SEEK +/- (cursor left/right) buttons
- 12 MENU button
- 13 LIST button
- 14 CLOSE (front panel close) button 9, 11
- 15 OFF (Stop/Power off) button*
- 16 MODE button
- 17 Number buttons
- 18 SOUND button
- 19 EQ7 button
- 20 ENTER button
- 21 DSO button
- 22 (eject) button 11


continue to next page → 5

US, AEP, UK, E MODEL

Getting Started

Resetting the unit

Before operating the unit for the first time, or after replacing the car battery or changing the connections, you must reset the unit. Press the reset button with a pointed object, such as a ball-point pen.




Notes

- After resetting the unit in the closed position, be sure to press (OPEN) once before operating further. If a disc is in the unit, the disc will be ejected automatically. Insert the disc again.
- Pressing the reset button will erase the clock setting and some stored contents.

Resetting the unit during use in sub display-position

Reset button by the disc-slot with a pointed object, such as a ball-point pen.



8

Detaching the main display window


You can detach the main display window of this unit to protect the unit from being stolen.

Caution alarm

If you turn the ignition switch to the OFF position without removing the front panel, the caution alarm will beep for a few seconds.


1 Press (OPEN) on the unit for 2 seconds.

CD/MD playback or radio reception stops, and the front panel automatically tilts at an angle of 30°.



Attaching the main display window panel

Place the main display window on the front side of the unit as illustrated, then lightly push the front panel into position until it clicks. Press (SOURCE) (or insert a disc) to operate the unit.




Note

Do not put anything on the inner surface of the main display window.

2 Detach the main display window as illustrated.

After the main display window detaching is complete, the front panel closes automatically.



Notes

- If you detach the main display window while the unit is still turned on, the power will turn off automatically to prevent the speakers from being damaged.
- Do not drop or put excessive pressure on the display window.
- Do not subject the main display window to heat/high temperature or moisture. Avoid leaving it in parked cars or on dashboards/rear trays.

Tips


- If you want to detach the main display window, when the front panel is in the sub-display position, press (CLOSE) for 2 seconds. If a disc is partially inserted, load the disc correctly or remove the disc from the unit.
- When carrying the main display window with you, use the supplied front panel case.

Setting the clock

The clock uses a 12-hour digital indication.


Example: To set the clock to 10:08

- 1 Press (MENU), then press ↑ or ↓ (the either (+/-) side of (DISC)) repeatedly until "Clock" appears.



- 1 Press (ENTER). The hour indication flashes.
- 2 Press ↑ or ↓ to set the hour.
- 3 Press → (the (+) side of (SEEK)). The minute indication flashes.
- 4 Press ↑ or ↓ to set the minute.

2 Press (ENTER).



The clock starts. After the clock setting is completed, the display returns to normal play mode.

Tip

When D.Info mode is set to on, the time is always displayed (page 26).

9

CD Player CD/MD Unit (optional)

In addition to playing a CD with this unit, you can also control external CD/MD units.


Note

If you connect an optional CD unit with the CD TEXT function, the CD TEXT information will appear in the display when you play a CD TEXT disc.

Playing a disc

(With this unit)

- 1 Press (OPEN/CLOSE) or (OPEN) on the unit and insert the disc (labeled side up). Playback starts automatically.



- 2 Press (OPEN/CLOSE) or (CLOSE) on the unit to close the front panel.

If a disc is already inserted, press (SOURCE) repeatedly until "CD" appears to start playback.

To	Press
Stop playback	(OFF)
Eject the disc	(OPEN/CLOSE) or (OPEN) then ▲
Skip tracks - Automatic - Music Sensor	◀▶ (SEEK) (◀▶▶) [once for each track]
Fast-forward/ reverse	◀▶▶ (SEEK) (◀▶▶▶) [hold to desired point]
Manual Search	◀▶▶▶ (SEEK) (◀▶▶▶▶) [hold to desired point]

Notes

- When the last track on the disc is over, playback restarts from the first track of the disc.
- With optional unit connected, playback of the same source will continue on to the optional CD/MD unit.

10

(With optional unit)


- 1 Press (SOURCE) repeatedly to select "CD" or "MD."

- 2 Press (MODE) repeatedly until the desired unit appears. Playback starts.

To	Press
Skip discs	↑↓ (DISC) (+/-)
- Disc selection	

Display items

When the disc/track changes, any prerecorded title*1 of the new disc/track is automatically displayed (if the Auto Scroll function is set to "on," names exceeding 9 characters will be scrolled (page 26)).



- Displayable items
- Disc name*1/artist name*2
 - Track title*1

To	Press
Switch display item	(DSPL)
Scroll display item	(SCRL)

*1 When pressing (DSPL), "NO D.Name" or "NO T.Name" indicates that there is no Disc Memo (page 11) or prerecorded name to display.
*2 Only for CD TEXT discs with the artist name.

Notes

- Some characters cannot be displayed.
- For some CD TEXT discs with very many characters, information may not scroll.
- This unit cannot display the artist name for each track of a CD TEXT disc.

Tip

When Auto scroll is set to off, and the disc/track is changed, the disc/track name does not scroll.

Playing tracks repeatedly

— Repeat Play

The disc in the main unit will repeat a track or the entire disc when it reaches the end. For repeat play, you can select:

- Repeat 1 — to repeat a track.
- Repeat 2* — to repeat a disc.

* Available only when one or more optional CD/MD units are connected.

During playback, press (REP) repeatedly until the desired setting appears in the display. Repeat Play starts.

To return to normal play mode, select "Repeat off."

Playing tracks in random order

— Shuffle Play

- Shuf 1 — to play the tracks on the current disc in random order.
- Shuf 2*1 — to play the tracks in the current optional CD (MD) unit in random order.
- Shuf All*2 — to play all the tracks in all the connected CD (MD) units (including this unit) in random order.

*1 Available only when one or more optional CD (MD) units are connected.

*2 Available only when one or more optional CD units, or two or more optional MD units are connected.

During playback, press (SHUF) repeatedly until the desired setting appears in the display. Shuffle Play starts.

To return to normal play mode, select "Shuf off."

Note

"Shuf All" will not shuffle tracks between CD units and MD units.

Labeling a CD

— Disc Memo (For a CD unit with the CUSTOM FILE function)

You can label each disc with a custom name (Disc Memo). You can enter up to 8 characters for a disc. If you label a CD, you can locate the disc by name (page 12).

- 1 Start playing the disc you want to label in a CD unit with the CUSTOM FILE function.
- 2 Press (MENU), then press ↑ or ↓ repeatedly until "Name Edit" appears.
- 3 Press (ENTER).



The unit will repeat the disc during the labeling procedure.

4 Enter the characters.

- 1 Press ↑*1 repeatedly to select the desired character.

A → B → C → ... → 0 → 1 → 2 → ... → +
→ * → ... → *2 → A

*1 For reverse order, press ↓.
*2 (blank space)

- 2 Press → after locating the desired character.



If you press ← (the (-) side of (SEEK)), you can move back to the left.

- 3 Repeat steps 1 and 2 to enter the entire name.

- 5 To return to normal CD play mode, press (ENTER).

continue to next page →

11

- Tip**
- Simply overwrite or enter " " to correct or erase a name.
 - There is another way to start labeling a CD: Press (LIST) for 2 seconds instead of performing steps 2 and 3. You can also complete the operation by pressing (LIST) for 2 seconds instead of step 5.
 - You can label CDs on a unit without the CUSTOM FILE function if that unit is connected along with a CD unit that has the function. The Disc Memo will be stored in the memory of the CD unit with the CUSTOM FILE function.

Note
Repeat/shuffle play is suspended until the Name Edit is complete.

Viewing the Disc Memo

As a display item, the Disc Memo always takes priority over any original CD TEXT information.

To	Press
View	(BSPL) during CD/CD TEXT disc playback

Tip
To find out about other items that can be displayed, see page 10.

Erasing the Disc Memo

- Press (SOURCE) repeatedly to select "CD."
- Press (MODE) repeatedly to select the CD unit storing the Disc Memo.
- Press (MENU), then press ↑ or ↓ repeatedly until "Name Del" appears.
- Press (ENTER). The stored names will appear.
- Press ↑ or ↓ repeatedly to select the disc name you want to erase. The stored names will appear.
- Press (ENTER) for 2 seconds. The name is erased. Repeat steps 5 and 6 if you want to erase other names.
- Press (ENTER). The unit returns to normal CD play mode.

Notes

- When the Disc Memo for a CD TEXT disc is erased, the original CD TEXT information is displayed.
- If you cannot find the Disc Memo you want to erase, try selecting a different CD unit in step 2.

Locating a disc by name

— List-up (For a CD unit with the CD TEXT/ CUSTOM FILE function, or an MD unit)

You can use this function for discs that have been assigned custom names*1 or for CD TEXT discs*2.

- *1 Locating a disc by its custom name: when you assign a name for a CD (page 11) or an MD.
- *2 Locating discs by the CD TEXT information: when you play a CD TEXT disc on a CD unit with the CD TEXT function.

- Press (LIST). The name assigned to the current disc appears in the display.



- Press ↑ or ↓ repeatedly until you find the desired disc.
- Press (ENTER) to play the disc.

Notes

- Some letters cannot be displayed (exception: Disc Memo).
- If the optional TV monitor is connected, the list appears on the TV monitor instead of the display on the unit.

Selecting specific tracks for playback

— Bank (For a CD unit with the CUSTOM FILE function)

If you label the disc, you can set the unit to skip or play the tracks of your choice.

- Start playing the disc you want to label.
- Press (MENU), then press ↑ or ↓ repeatedly until "Bank Sel" appears.
- Press (ENTER).



- Label the tracks.
 - Press ← or → repeatedly to select the track you want to label.
 - Press (ENTER) repeatedly to select "Play" or "Skip."
- Repeat step 4 to set "Play" or "Skip" for all the tracks.

- Press (ENTER). The unit returns to normal CD play mode.

Notes

- You can set "Play" and "Skip" for up to 24 tracks.
- You cannot set "Skip" for all the tracks on a CD.

Playing specific tracks only

You can select:

- Bank on — to play the tracks with the "Play" setting.
- Bank inv (Inverse) — to play the tracks with the "Skip" setting.

- During playback, press (MENU), then press ↑ or ↓ repeatedly until "Bank on," "Bank inv," or "Bank off" appears.
- Press → repeatedly until the desired setting appears.



- Press (ENTER). Playback starts from the track following the current one.

To return to normal play mode, select "Bank off" in step 2.

US MODEL

Radio

The unit can store up to 6 stations per band (FM1, FM2, FM3, AM1, and AM2).

Caution
When tuning in stations while driving, use Best Tuning Memory to prevent accidents.

Storing stations automatically

— Best Tuning Memory (BTM)

The unit selects the stations with the strongest signals within the selected band, and stores them in the order of their frequency.

- Press (SOURCE) repeatedly to select the radio.
- Press (MODE) repeatedly to select the band.
- Press (MENU), then press ↑ or ↓ repeatedly until "BTM" appears.
- Press (ENTER). A beep sounds when the setting is stored.

Notes

- If only a few stations can be received due to weak signals, some number buttons will retain their former settings.
- When a number is indicated in the display, the unit starts storing stations from the one currently displayed.

Receiving the stored stations

- Press (SOURCE) repeatedly to select the radio.
- Press (MODE) repeatedly to select the band.
- Press the number button (1 to 6) on which the desired station is stored.

Tip
Press ↑ or ↓ to receive the stations in the order they are stored in the memory (Preset Search function).

If preset tuning does not work

Press either side of (SEEK) to search for the station (automatic tuning). Scanning stops when the unit receives a station. Repeat until the desired station is received.

- Tip**
- If automatic tuning stops too frequently, turn on the Local Seek to limit seek to stations with stronger signals (see "Changing the sound and display settings" on page 26).
 - If you know the frequency of the station you want to listen to, press and hold either side of (SEEK) to locate the approximate frequency, then press (SEEK) repeatedly to fine adjust to the desired frequency (manual tuning).

If FM stereo reception is poor

Select monaural reception mode (see "Changing the sound and display settings" on page 26). The sound improves, but becomes monaural ("ST" disappears).

Note
If interference occurs, this unit will automatically narrow the reception frequency to eliminate noise (IF Auto function). In such cases, some FM stereo broadcasts may become monaural while in the stereo reception mode.

Tip
To always hear FM stereo broadcasts in stereo, you can change the IF Auto setting and widen the frequency signal reception (see "Changing the sound and display settings" on page 26). Note that some interference may occur in this setting.

Storing only the desired stations

You can manually preset the desired stations on any chosen number button.

- Press (SOURCE) repeatedly to select the radio.
- Press (MODE) repeatedly to select the band.
- Press either side of (SEEK) to tune in the station that you want to store.
- Press the desired number button (1 to 6) for 2 seconds until "MEM" appears. The number button indication appears in the display.

Note
If you try to store another station on the same number button, the previously stored station will be erased.


Storing station names

— Station Memo

You can assign a name to each radio station and store it in memory. The name of the station currently tuned in appears in the display. You can assign a name using up to 8 characters for a station.

Storing the station names

- Tune in a station whose name you want to store.
- Press (MENU), then press ↑ or ↓ repeatedly until "Name Edit" appears.
- Press (ENTER).




- Enter the characters.
 - Press ↑ repeatedly to select the desired character.

A → B → C ... 0 → 1 → 2 ... → +
→ → * ... → ^ → A

- *1 For reverse order, press ↓.
- *2 (blank space)

- Press → after locating the desired character.



If you press ←, you can move back to the left.

- Repeat steps 1 and 2 to enter the entire name.
- Press (ENTER).

continue to next page →

AEP, UK, E MODEL

Tips

- Simply overwrite or enter " " to correct or erase a name.
- There is another way to start storing station names: Press (LIST) for 2 seconds instead of performing steps 2 and 3. You can also complete the operation by pressing (LIST) for 2 seconds instead of step 5.

Erasing the station name

- During radio reception, press (MENU), then press ↑ or ↓ repeatedly until "Name Del" appears.
- Press (ENTER).
- Press ↑ or ↓ repeatedly to select the station whose name you want to erase.
- Press (ENTER) for 2 seconds. The name is erased. Repeat steps 3 to 4 if you want to erase other names.
- Press (ENTER). The unit returns to normal radio reception mode.

Note
If you have already erased all of the station names, "NO Data" appears in step 4.

Tuning in a station through a list

— List-up

- During radio reception, press (LIST) momentarily. The frequency or the name assigned to the current station appears in the display.



- Press ↑ or ↓ repeatedly until you find the desired station. If no name is assigned to the selected station, the frequency appears in the display.

- Press (ENTER) to tune in the desired station.

Note
If the optional TV monitor is connected, and if the monitor responds to this function, the list appears on the TV monitor instead of the display on the unit.

Playing specific tracks only

- You can select:
- Bank on — to play the tracks with the "Play" setting.
 - Bank inv (Inverse) — to play the tracks with the "Skip" setting.

- During playback, press (MENU), then press ↑ or ↓ repeatedly until "Bank on," "Bank inv," or "Bank off" appears.
- Press → repeatedly until the desired setting appears.



- Press (ENTER). Playback starts from the track following the current one.

To return to normal play mode, select "Bank off" in step 2.

Radio

The unit can store up to 6 stations per band (FM1, FM2, FM3, MW, and LW).

Caution
When tuning in stations while driving, use Best Tuning Memory to prevent accidents.

Storing stations automatically

— Best Tuning Memory (BTM)

The unit selects the stations with the strongest signals within the selected band, and stores them in the order of their frequency.

- Press (SOURCE) repeatedly to select the radio.
- Press (MODE) repeatedly to select the band.
- Press (MENU), then press ↑ or ↓ repeatedly until "BTM" appears.
- Press (ENTER). A beep sounds when the setting is stored.

Notes

- If only a few stations can be received due to weak signals, some number buttons will retain their former settings.
- When a number is indicated in the display, the unit starts storing stations from the one currently displayed.

Receiving the stored stations

- Press (SOURCE) repeatedly to select the radio.
- Press (MODE) repeatedly to select the band.
- Press the number button (1 to 6) on which the desired station is stored.

Tip
Press ↑ or ↓ to receive the stations in the order they are stored in the memory (Preset Search function).

If preset tuning does not work

Press either side of (SEEK) to search for the station (automatic tuning). Scanning stops when the unit receives a station. Repeat until the desired station is received.

- Tips**
- If automatic tuning stops too frequently, turn on the Local Seek to limit seek to stations with stronger signals (see "Changing the sound and display settings" on page 34).
 - If you know the frequency of the station you want to listen to, press and hold either side of (SEEK) to locate the approximate frequency, then press (SEEK) repeatedly to fine adjust to the desired frequency (manual tuning).

If FM stereo reception is poor

Select monaural reception mode (see "Changing the sound and display settings" on page 34). The sound improves, but becomes monaural ("ST" disappears).

Storing only the desired stations

You can manually preset the desired stations on any chosen number button.

- Press (SOURCE) repeatedly to select the radio.
- Press (MODE) repeatedly to select the band.
- Press either side of (SEEK) to tune in the station that you want to store.
- Press the desired number button (1 to 6) for 2 seconds until "MEM" appears. The number button indication appears in the display.

Note
If you try to store another station on the same number button, the previously stored station will be erased.

Tuning in a station through a list

— List-up

- During radio reception, press (LIST) momentarily. The frequency or the name assigned to the current station appears in the display.




- Press ↑ or ↓ repeatedly until you find the desired station. If no name is assigned to the selected station, the frequency appears in the display.

- Press (ENTER) to tune in the desired station.

RDS

Overview of RDS

FM stations with Radio Data System (RDS) service send inaudible digital information along with the regular radio programme signal. For example, one of the following will be displayed upon receiving a station with RDS capability.



* see "Tuning in stations by programme type" on page 20.

To	Press
Switch display item	(DSP/PTY)

RDS services

- RDS data offers you other conveniences, such as:
- Automatic retuning of a programme, helpful during long-distance drives. — AF → page 18
 - Receiving traffic announcements, even when enjoying another programme/source. — TA → page 19
 - Selecting stations by the type of programme it broadcasts. — PTY → page 20
 - Automatic clock time setting. — CT → page 21


Notes

- Depending on the country or region, not all of the RDS functions are available.
- RDS may not work properly if the signal strength is weak or if the station you are tuned to is not transmitting RDS data.

Automatic retuning for best reception results

— AF function

The alternative frequencies (AF) function allows the radio to always tune into the area's strongest signal for the station you are listening to.



- 1 Select an FM station (page 15).
- 2 Press **(AF)** repeatedly until "AF on" appears. The unit starts searching for an alternative frequency with a stronger signal in the same network. If "NO AF" flashes, the currently tuned into station does not have an alternative frequency.

Note
When there is no alternative frequency in the area or when you do not need to search for one, turn the AF function off by selecting "AF off."

For stations without alternative frequencies

Press either side of **(SEEK)** while the station name is flashing (within 8 seconds). The unit starts searching for another frequency with the same PI (Programme Identification) data ("PI Seek" appears). If the unit cannot find the same PI, the unit returns to the previously selected frequency.

Staying with one regional programme

When AF function is on: this unit's factory-set setting restricts reception to a specific region, so you won't be switched to another regional station with a stronger frequency. If you leave this regional programme's reception area or would like to take advantage of the whole AF function, select "REG off" from the MENU (page 34).

Note
This function does not work in the United Kingdom and in some other areas.

Local Link function (United Kingdom only)

This function enables you to select other local stations in the area, even if they are not stored on your number buttons.

- 1 Press a number button **(1)** to **(6)** that has a local station stored on it.
- 2 Within 5 seconds, press the number button of the local station again.
- 3 Repeat this procedure until the desired local station is received.

Receiving traffic announcements

— TA/TP

By activating the Traffic Announcement (TA) and Traffic Programme (TP), you can automatically tune in an FM station broadcasting traffic announcements. These settings function regardless of the current FM programme/source, CD/MD; the unit switches back to the original source when the bulletin is over.

Press **(TA)** repeatedly until "TA on" appears. The unit starts searching for traffic information stations. "TP" indicates reception of such stations, and "TA" flashes during an actual traffic announcement. The unit will continue searching for stations available with TP if "NO TP" is indicated.

To cancel all traffic announcements, select "TA off."

To	Press
Cancel current announcement	(TA)

Tip
You can also cancel the current announcement by pressing **(SOURCE)** or **(MODE)**.

Presetting the volume of traffic announcements

You can preset the volume level of the traffic announcements so you won't miss hearing them.

- 1 Press **(VOL)** to adjust the desired volume level.
- 2 Press **(TA)** for 2 seconds. "TA" appears and the setting is stored.

Receiving emergency announcements

If either AF or TA is on, the unit will switch to emergency announcements, if one comes in while listening to an FM station or CD/MD.

Presetting RDS stations with AF and TA setting

When you preset RDS stations, the unit stores each station's AF/TA setting (on/off) as well as its frequency. You can select a different setting (for AF, TA, or both) for individual preset stations, or the same setting for all preset stations. If you preset stations with "AF on," the unit automatically stores stations with the strongest radio signal.

Presetting the same setting for all preset stations

- 1 Select an FM band (page 15).
- 2 Press **(AF)** and/or **(TA)** to select "AF on" and/or "TA on." Note that selecting "AF off" or "TA off" stores not only RDS stations, but also non-RDS stations.
- 3 Press **(MENU)**, then press **↑** or **↓** repeatedly until "BTM" appears.
- 4 Press **(ENTER)** until "BTM" flashes.

Presetting different settings for each preset station

- 1 Select an FM band, and tune in the desired station (page 16).
- 2 Press **(AF)** and/or **(TA)** to select "AF on" and/or "TA on."
- 3 Press the desired number button **(1)** to **(6)** until "MEM" appears.

Repeat from step 1 to preset other stations.

Tuning in stations by programme type

— PTY

You can tune in a station by selecting the type of programme you would like to listen to.

Programme types	Display
News	News
Current Affairs	Affairs
Information	Info
Sports	Sport
Education	Educate
Drama	Drama
Culture	Culture
Science	Science
Varied	Varied
Popular Music	Pop M
Rock Music	Rock M
Easy Listening	Easy M
Light Classical	Light M
Classical	Classics
Other Music Type	Other M
Weather	Weather
Finance	Finance
Children's Programmes	Children
Social Affairs	Social A
Religion	Religion
Phone In	Phone In
Travel	Travel
Leisure	Leisure
Jazz Music	Jazz
Country Music	Country
National Music	Nation M
Oldies Music	Oldies
Folk Music	Folk M
Documentary	Document

Note
You cannot use this function in some countries where no PTY (Programme Type selection) data is available.

- 1 Press **(DSPLPTY)** during FM reception until "PTY" appears.



The current programme type name appears if the station is transmitting the PTY data. "-----" appears if the received station is not an RDS station, or if the RDS data is not received.

- 2 Press **↑** or **↓** repeatedly until the desired programme type appears. The programme types appear in the order shown in the table. "-----" appears if the programme type is not specified in the RDS data.
- 3 Press **(ENTER)**. The unit starts searching for a station broadcasting the selected programme type.

Setting the clock automatically

— CT

The CT (Clock Time) data from the RDS transmission sets the clock automatically.

- 1 During radio reception, press **(MENU)**, then press **↑** or **↓** repeatedly until "CT off" appears.



- 2 Press **→** repeatedly until "CT on" appears. The clock is set.
- 3 Press **(ENTER)** to return to the normal display.

To cancel the CT function, select "CT off" in step 2.

Notes
• The CT function may not work even though an RDS station is being received.
• There might be a difference between the time set by the CT function and the actual time.


DAB (optional)

You can connect an optional DAB tuner to this unit.

Overview of DAB

DAB (Digital Audio Broadcasting) is a new multimedia broadcasting system that transmits audio programmes with a quality comparable to that of CDs. This is made possible by the use of a microcomputer in the DAB tuner which uses the radio signals sent from multiple aerials and multi-path signals (reflected radio waves) to boost the strength of the main signal. This makes DAB almost immune to radio interference even in a moving object such as a car.

Each DAB station bundles radio programmes (services) into an ensemble which it then broadcasts. Each service contains one or more components. All ensembles, services, and components are identified by name, so you can access any of them without having to know their frequencies.



Notes
• The DAB system is still in a testing phase. Some services have not been sufficiently defined or are presently being tested. At present, such services are not supported by the optional DAB tuner unit XT-100DAB.
• DAB programmes are broadcast in Band-III (174 to 240 MHz) and L-Band (1,452 to 1,492 MHz), with each band divided into channels (41 in Band-III and 23 in L-Band). One ensemble is broadcast per channel by each DAB station.

Basic operations of DAB

Searching for the ensemble and service

— Automatic Tuning

- 1 Press **(SOURCE)** repeatedly to select the radio.
- 2 Press **(MODE)** repeatedly to select "DAB."
- 3 Press and hold either side of **(SEEK)** until "Seek +" or "Seek -" appears.



The unit will stop seeking when an ensemble is located. The unit will then automatically select the first service and display its name, and the display indicator will change from "Seek +"/"Seek -" to the service name.

- 4 Press either side of **(SEEK)** to select the desired service.

Selecting the ensemble

— Manual Tuning

If you know the channel number of ensemble, follow the procedure below to tune in.

- 1 Press **(SOURCE)** repeatedly to select the radio.
- 2 Press **(MODE)** repeatedly to select "DAB."
- 3 Press **↑** or **↓** until "Ch. XXX" appears.



- 4 Press **↑** or **↓** repeatedly until the desired channel number appears.

Receiving the preset services

Following procedure is available after presetting the service. For details on presetting the services, refer to "Presetting DAB services automatically," (page 23) and "Presetting DAB services manually" (page 23).

- 1 Press **(SOURCE)** repeatedly to select the radio.
- 2 Press **(MODE)** repeatedly to select "DAB."
- 3 Press **↑** or **↓** repeatedly to select the preset service.

Tip
There is another way to receive the preset service (preset on numbers 1 to 6).
Press the number button (1 to 6) on which the desired service is stored.

Refer to the level indication to check the receiving condition of the DAB programme. The level indication increases as the strength of the receiving signal increases.

level 0 level 1 level 2 level 3 level 4
A A A A A

"A" will flash in the display if the reception is poor.

Note
To display the level indication, select the spectrum analyzer pattern A-1 or A-2 (page 33).

Presetting DAB services automatically

— BTM

The BTM (Best Tuning Memory) function picks out DAB ensembles and automatically assigns the services within the ensembles to preset service numbers. The unit can preset up to 40 services.

If services have been previously set, the BTM function operates under the following conditions:

- If you activate the BTM function while listening to a preset service, the unit will store detected services (by overwriting) only to preset numbers higher than that of the current preset service.
- If you activate the function while listening to a service that is not preset, the unit will replace the contents of all preset numbers.
- In both cases above, if the unit detects a service that is identical to one already preset, the previously stored service remains unchanged and the newly detected service is not preset.

- 1 While listening to a DAB programme, press **(MENU)**.
- 2 Press **↑** or **↓** repeatedly until "BTM" appears.

- 3 Press **(ENTER)**.
A beep sounds when the service is stored. After activating the BTM function, the unit tunes the service assigned in the last smallest preset memory No. automatically.

Note
If the unit can only tune in a few services, the BTM function may not assign services to all the preset service numbers.

Presetting DAB services manually

— Preset Edit

You can also preset DAB services manually or delete a service which is already preset. Note that up to 40 services (preset either by the BTM function or manually) can be preset to the unit's memory.


- 1 While listening to a DAB programme, press **(MENU)**.
- 2 Press **↑** or **↓** repeatedly until "PRS Edit" appears, then press **(ENTER)**.

- 3 Select the service and the preset number you want to preset.

- 1 Press either side of **(SEEK)** to select the service.
- 2 Press **↑** or **↓** to select the preset number.



- 3 Press **(ENTER)**.
The Preset Edit commands will appear in the display.



- 4 Press **↑** or **↓** to select the desired command.

- 5 Press **(ENTER)**.
To edit other services, repeat steps 3 and 4.

continue to next page →

Replacing the services in preset memories

Press **↑** or **↓** to select "Over Wrt" in step 4, then press **(ENTER)**.

Tip
There is another way to preset the service (on numbers 1 to 6).
After receiving the service, press the desired number button (1 to 6) until a beep sounds.

Adding the services in preset memories

Press **↑** or **↓** to select "Insert" in step 4, then press **(ENTER)**.

Note
"Insert" does not appear if the maximum number of services (40) is already preset in memory.

Erasing the services in preset memories

Press **↑** or **↓** to select "Delete" in step 4, then press **(ENTER)**.

Tuning in DAB progra through a list

Follow the procedure below to tune in a DAB programme manually.

- 1 While listening to a DAB programme, press **(LIST)** repeatedly until "E" (ensemble list) appears.

E: ensemble list
S: service list
C: component list
P: preset list



All available ensembles will be listed.

- 2 Press **↑** or **↓** until the desired ensemble appears, then press **(ENTER)**.
The first service for the ensemble is selected automatically.

- 3 Press **(LIST)** repeatedly until "S" (service list) appears.
All services available for the ensemble will be listed.

- 4 Press **↑** or **↓** repeatedly until the desired service appears, then press **(ENTER)**.
The first component for the service is selected automatically.

- 5 Press **(LIST)** repeatedly until "C" (component list) appears.
All components available for the service will be listed.

- 6 Press **↑** or **↓** until the desired component appears, then press **(ENTER)**.

Automatic updating of the ensemble list

When you perform the BTM function for the first time, all the ensembles available in your area are automatically stored. When you perform the BTM function again, the contents of these lists are updated in accordance with the conditions described on page 23.

An ensemble is added to the respective list when it is received during Automatic Tuning or Manual Tuning but is unlisted.

An ensemble is also deleted from the respective list when:

- you select an ensemble from the list, but it cannot be received.
- you perform Automatic Tuning or Manual Tuning to receive a listed ensemble, service, or the component, but it cannot be received.

Switching multi-channel audio and DRC

DAB can contain multi-channel audio. You can select main or sub-channel for reception. Also, if you turn on the DRC (Dynamic Range Control) function, the dynamic range on the service which supports DRC can automatically be extended.

The following items can be set:

- **BLGL** — to select the channel from either "Main" (main-channel) or "Sub" (sub-channel).
- **DRC** — to turn on or off the function.

- 1 While listening to a DAB programme, press **(MENU)**.
- 2 Press **↑** or **↓** repeatedly until "DRC" or "BLGL" appears.

- 3 Press either side of **(SEEK)** to select the desired setting (Example: "on" or "off").

- 4 Press **(ENTER)**.

Note
"BLGL" appears in the menu only when the unit is receiving a multi-channel programme.

Locating a DAB service by programme type (PTY)

You can use the PTY (Programme type selection) function to tune in the programme you want.

- 1 While listening to a DAB programme, press **(DISP/PTY)**.
- 2 Press **↑** or **↓** repeatedly to select the programme type.



The programme types appear in the order shown on page 20.

- 3 Press **(ENTER)**.
Searching for a service of the selected programme type begins automatically.

US, AEP, UK, E MODEL

Tuning up for your best sound

The unit provides the various functions to adjust the sound so that you can enjoy the best sounding music.

Setting the equalizer (EQ7)

You can select an equalizer curve for 7 music types (Vocal, Club, Jazz, New Age, Rock, Custom, and Xplod). You can store and adjust the equalizer settings for frequency and level.

Selecting the equalizer curve

- 1 Press **(SOURCE)** to select a source (radio, CD, or MD).
- 2 Press **(EQ7)** repeatedly until the desired equalizer curve.




To cancel the equalizing effect, select "off." After 3 seconds, the display returns to the normal playback mode.


Adjusting the equalizer curve

- 1 Press **(MENU)**.
- 2 Press **↑** or **↓** repeatedly until "EQ7 Tune" appears, then press **(ENTER)**.
- 3 Press **←** or **→** to select the desired equalizer curve, then press **(ENTER)**. Each time you press **(SEEK)**, the item changes.
- 4 Select the desired frequency and level.
 - 1 Press **←** or **→** to select the desired frequency.

Each time you press **←** or **→**, the frequency changes as follows:



- 2 Press **↑** or **↓** to adjust the desired volume level. (CDX-M770)
The volume level is adjustable by 1 dB steps from -12 dB to +12 dB. (CDX-M670/M620)
The volume level is adjustable by 1 dB steps from -10 dB to +10 dB.



To restore the factory-set equalizer curve, press **(ENTER)** for 2 seconds.

- 5 Press **(ENTER)**.
After the effect setting is complete, the display returns to the normal playback mode.

Setting the soundstage menu — Dynamic Soundstage Organizer (DSO)


If your speakers are installed into the lower part of the doors, the sound will come from below and may not be clear. The DSO (Dynamic Soundstage Organizer) function creates a more ambient sound as if there were speakers in the dashboard (virtual speakers).

Selecting the DSO mode (CDX-M770)

DSO mode of CDX-M770

Display window	Meaning
STD	Virtual speakers (Standard)
WIDE	Virtual speakers (Wide)
STD-SP	Standard+depth
WIDE-SP	Wide+depth
off	Cancel

Image of virtual speakers



- *1 STD
- *2 Wide
- *3 STD+depth
- *4 Wide+depth
- *5 Actual speakers position (lower part of the front doors)

- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(DSO)** repeatedly to select the desired DSO mode.



To cancel the DSO mode, select "off." After 3 seconds, the display returns to the normal playback mode.

If the sound from the tweeter is too shrill (CDX-M770)

- 1 While the unit is operating, press **(MENU)**.
- 2 Press **↑** or **↓** repeatedly until "DSO norm" appears.
- 3 Press **→** to select "DSO soft."



- 4 Press **(MENU)**.

To restore the sound, select "DSO norm."

Listening to each programme source in its registered DSO — Source Sound Memory (SSM)

Each time you return to the same source, you can hear the same DSO menu and equalizer curve registered for that source, even after changing the programme source or turning the unit off and then on again.

Adjusting the sound characteristics

You can adjust the sound characteristics. The bass and treble levels and subwoofer volume can be stored independently for each source.

- 1 Select the item you want to adjust by pressing **(SOUND)** repeatedly. Each time you press **(SOUND)**, the item changes as follows:

(CDX-M770)
POS (position) → BAL (left-right)
→ F (front volume) → R (rear volume) → SUB (subwoofer volume)


(CDX-M670/M620)
BAS (bass) → TRE (treble)
→ BAL (left-right) → FAD (front-rear)
→ SUB (subwoofer volume)

- 2 Adjust the selected item by pressing **←** or **→**.
When adjusting with the rotary commander, press **(SOUND)** and rotate the VOL control.

Note
Adjust within 3 seconds after selecting the item.


Selecting the listening position (CDX-M770 only)

You can set a delayed time for the sound to reach the listeners from the speakers. In this way, the unit can simulate a natural sound field so that you feel as if you are in the center of the sound field no matter where you sit in the car.



Display window	Centre of sound field
POS ALL	Normal setting (① + ② + ③)
POS Front	Front part (① + ②)
POS Front-R	Right front (②)
POS Front-L	Left front (①)
POS Rear	Rear part (③)
POS off	Cancel

- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(SOUND)** repeatedly until "POS" appears.



- 3 Press **←** or **→** to select the desired listening position.
All ↔ Front ↔ Front-R ↔ Front-L ↔ Rear ↔ off ↔ All

The listening positions appear in the order shown above.

To cancel the POS mode, select "off." After three seconds, the display returns to the normal playback mode.

Tips

- * The DSO effect may be hard to discern depending on the type of car you are driving and the music you are listening to.
- * When DSO setting is "WIDE," the FM reception is inaudible. In this case, reset the DSO setting to "STD."

Turning the DSO mode on (off) (CDX-M670/M620)

DSO mode of CDX-M670/M620	Memory presets	Meaning
on	Virtual speakers	
off	Cancel	

- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(DSO)** to select "on" or "off."




To cancel the DSO mode, select "DSO off." After 3 seconds, the display returns to the normal playback mode.

Adjusting the DSO mode (CDX-M770)

- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(MENU)**.
- 3 Press **↑** or **↓** repeatedly until "DSO tune" appears, then press **(ENTER)**.
- 4 Press **←** or **→** to select the desired DSO mode, then press **(ENTER)**.
- 5 Select the effect level.

You can select the desired effect from 3 effect levels for each DSO mode.

Press **↑** or **↓** repeatedly to select desired effect.



To restore the effect, press **(ENTER)** for 2 seconds.

- 6 Press **(ENTER)**.

Adjusting the balance (BAL)

You can adjust the sound balance from the left and right speakers.

- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(SOUND)** repeatedly until "BAL" appears.



- 3 Press **←** or **→** to adjust the balance. After 3 seconds, the display returns to the normal playback mode.

Adjusting the bass (CDX-M670/M620 only)

You can adjust the bass from the speakers.

- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(SOUND)** repeatedly until "BAS" appears.




- 3 Press **←** or **→** to adjust the balance. After 3 seconds, the display returns to the normal playback mode.

Adjusting the treble (CDX-M670/M620 only)

You can adjust the treble from the speakers.

- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(SOUND)** repeatedly until "TRE" appears.



- 3 Press **←** or **→** to adjust the balance. After 3 seconds, the display returns to the normal playback mode.

Adjusting the balance (FAD) (CDX-M670/M620 only)

You can adjust the sound balance from the front and rear speakers.

- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(SOUND)** repeatedly until "FAD" appears.



- 3 Press **←** or **→** to adjust the balance. After 3 seconds, the display returns to the normal playback mode.

Adjusting the front and rear volume (CDX-M770 only)


- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(SOUND)** repeatedly to select the "F" for the front speakers or "R" for the rear speakers.




- 3 Press **←** or **→** to adjust the volume of front/rear speakers. After 3 seconds, the display returns to the normal playback mode.

Adjusting the cut-off frequency and the output volume level for the front/rear speakers

To match the characteristics of the installed speaker system, you can adjust the output volume level and select the cut-off frequency of the speakers.



- 1 Press **(MENU)**.
- 2 Press **↑** or **↓** repeatedly to select "Front HPF" or "Rear HPF."
- 3 Press **(ENTER)**.




continue to next page →

- 4 Press **←** or **→** to select the cut-off frequency. Each time you press **←** or **→**, the frequency changes as follows:
off ↔ 78 Hz ↔ 99 Hz ↔ 125 Hz ↔ 157 Hz ↔ 198 Hz
- 5 Press **↑** or **↓** to adjust the volume level. The volume level is adjustable by 1 dB steps from -12 dB to +12 dB.
Tip
When you lower the volume all the way down, "∞dB" appears and the cut-off frequency is disabled.
- 6 Press **(ENTER)**. After the effect is complete, the display returns to the normal playback mode.

Adjusting the volume of the subwoofer(s)

- 1 Press **(SOURCE)** to select a source (tuner, CD, or MD).
- 2 Press **(SOUND)** repeatedly until "SUB" appears.




- 3 Press **←** or **→** to adjust the volume. After 3 seconds, the display returns to the normal playback mode.

Tip
When you press **←** repeatedly to adjust the volume all the way down, "∞dB" appears and the cut-off frequency of the subwoofer is disabled.

Adjusting the frequency of the subwoofer(s) (CDX-M770 only)

To match the characteristics of the connected subwoofer(s), you can cut out the unwanted high and middle frequency signals entering the subwoofer(s). By setting the cut-off frequency (see the diagram below), the subwoofer(s) will output only low frequency signals so you can get a clearer sound image.



- 1 Press **(MENU)**.
- 2 Press **↑** or **↓** repeatedly until "SUB LPF" appears.
- 3 Press **(ENTER)**.



- 4 Press **←** or **→** to select the desired cut-off frequency. Each time you press **←** or **→**, the frequency changes as follows:
62 Hz ↔ 78 Hz ↔ 99 Hz ↔ 125 Hz ↔ 157 Hz ↔ off

- 5 Press **↑** or **↓** to adjust the volume. The volume level is adjustable by 1 dB steps from -12 dB to +12 dB.
Tip
When you lower the volume all the way down, "∞dB" appears and the cut-off frequency is disabled.

- 6 Press **(ENTER)**. After the frequency setting is complete, the display returns to the normal playback mode.

Other adjustable items (CDX-M670/M620 only)

The following items can be adjusted:

- HPF (High pass filter) — to select the cut-off frequency to "off," "78 Hz," or "125 Hz."
- LPF (Low pass filter) — to select the cut-off frequency to "78 Hz," "125 Hz," or "off."
- Loud (Loudness) — to enjoy bass and treble even at low volumes. The bass and treble will be reinforced.

- 1 Press **(MENU)**. To set A.Src, press **(MENU)** during CD/MD playback.
- 2 Press **↑** or **↓** repeatedly until the desired item appears.
- 3 Press **→** to select the desired setting (Example: "on" or "off").
- 4 Press **(ENTER)**. After the mode setting is completed, the display returns to normal play mode.

Note
The displayed item will differ depending on the source.


Tip
You can easily switch among categories by pressing **↑** or **↓** for 2 seconds.

Other Functions


You can also control the unit (and optional CD/MD units) with an optional rotary commander. RM-XSS (supplied with CDX-M770 only)

Using the rotary commander

First, attach the appropriate label depending on how you want to mount the rotary commander. The rotary commander works by pressing buttons and/or rotating controls.







Inserting the supplied lithium battery



Tip
For information on lithium battery, refer to "Notes on lithium battery" (page 31).

continue to next page → 23

US MODEL
Connection



Cautions


- This unit is designed for negative ground 12 V DC operation only.
 - Do not get the wires under a screw, or caught in moving parts (e.g. seat railing).
 - Before making connections, disconnect the ground terminal of the car battery to avoid short circuits.
 - Connect the yellow and red power input leads only after all other leads have been connected.
 - Run all ground wires to a common ground point.
 - Be sure to insulate any loose unconnected wires with electrical tape for safety.
 - The use of optical instruments with this product will increase eye hazard.
- Notes on the power supply cord (yellow)**
- When connecting this unit in combination with other stereo components, the connected car circuit's rating must be higher than the sum of each component's fuse.
 - When no car circuits are rated high enough, connect the unit directly to the battery.

Parts list (1)

The numbers in the list are keyed to those in the instructions.
 For the use of release key (2), see the supplied operating instructions.

Caution

Handle the bracket (1) carefully to avoid injuring your fingers.



Connection example (2)

Notes (2-A)


Be sure to connect the ground cord before connecting the amplifier.

Tip (2-B-2)

For connecting two or more changers, the source selector XA-C30 (optional) is necessary.

Connection diagram (3)

- 1 To a metal surface of the car
First connect the black ground lead, then connect the yellow and red power input leads.
 - 2 To the power antenna control lead or power supply lead of antenna booster amplifier
Notes
 - It is not necessary to connect this lead if there is no power antenna or antenna booster, or with a manually-operated telescopic antenna.
 - When your car has a built-in FM/AM antenna in the rear/side glass, see "Notes on the control and power supply leads."
 - 3 To AMP REMOTE IN of an optional power amplifier
Notes
 - This connection is only for amplifiers. Connecting any other system may damage the unit.
 - 4 To the interface cable of a car telephone
 - 5 To a car's illumination signal
Be sure to connect the black ground lead to it first.
 - 6 To the +12 V power terminal which is energized in the accessory position of the ignition key switch
Notes
 - If there is no accessory position, connect to the +12 V power (battery) terminal which is energized at all times.
 - Be sure to connect the black ground lead to it first.
 - When your car has a built-in FM/AM antenna in the rear/side glass, see "Notes on the control and power supply leads."
 - 7 To the +12 V power terminal which is energized at all times
Be sure to connect the black ground lead to it first.
- Notes on the control and power supply leads**
- The power antenna control lead (blue) supplies +12 V DC when you turn on the tuner.
 - When your car has built-in FM/AM antenna in the rear/side glass, connect the power antenna control lead (blue) or the necessary power input lead (red) to the power terminal of the existing antenna booster. For details, consult your dealer.
 - A power antenna without relay box cannot be used with this unit.
- Memory hold connection**
- When the yellow power input lead is connected, power will always be supplied to the memory circuit even when the ignition key is turned off.
- Notes on speaker connection**
- Before connecting the speakers, turn the unit off.
 - Use speakers with an impedance of 4 to 8 ohms, and with adequate power handling capacities to avoid its damage.
 - Do not connect the speaker terminals to the car chassis, or connect the terminals of the right speakers with those of the left speaker.
 - Do not connect the ground lead of this unit to the negative (-) terminal of the speaker.
 - Do not attempt to connect the speakers in parallel.
 - Connect only passive speakers. Connecting active speakers (with built-in amplifiers) to the speaker terminals may damage the unit.
 - To avoid a malfunction, do not use the built-in speaker wires installed in your car if the unit shares a common negative (-) lead for the right and left speakers.
 - Do not connect the unit's speaker cords to each other.



Précautions

- Cet appareil est exclusivement conçu pour fonctionner sur une tension de 12 V CC avec masse négative.
 - Évitez de fixer des vis sur les câbles ou de coincer ceux-ci dans des pièces mobiles (par exemple, armature de siège).
 - Avant d'effectuer les raccordements, débranchez la borne de terre de la batterie du véhicule pour éviter tout court-circuit.
 - Raccordez les fils d'entrée d'alimentation jaune et rouge seulement après avoir terminé tous les autres raccordements.
 - Rassemblez tous les fils de terre en un point de masse commun.
 - Veillez à isoler avec du chatterton tout fil lâche non raccordé.
- Remarques sur le cordon d'alimentation (jaune)**
- Lorsque cet appareil est raccordé à d'autres éléments stéréo, la valeur nominale des circuits de la voiture raccordée doit être supérieure à la somme des fusibles de chaque élément.
 - Si aucun circuit de la voiture n'est assez puissant, raccordez directement l'appareil à la batterie.


Liste des composants (1)

Les numéros de l'illustration correspondent à ceux des instructions.

Pour l'utilisation de la clé de déblocage (2), reportez-vous au mode d'emploi.

Attention

Manipulez précautionneusement le support (1) pour éviter de vous blesser aux doigts.



Exemple de raccordement (2)

Remarques (2-A)
Raccordez d'abord le fil de masse avant de raccorder l'amplificateur.

Conseil (2-B-C)
Dans le cas du raccordement de deux changeurs ou plus, le sélecteur de source XA-C30 (en option) est indispensable.

Schéma de raccordement (3)

① A un point métallique de la voiture
Branchez d'abord le fil de masse noir et, ensuite, les fils d'entrée d'alimentation jaune et rouge.

② Vers le fil de commande de l'antenne électrique ou le fil d'alimentation de l'amplificateur d'antenne

- Remarques**
- Il n'est pas nécessaire de raccorder ce fil s'il n'y a pas d'antenne électrique ni d'amplificateur d'antenne, ou avec une antenne télescopique manuelle.
 - Si votre voiture est équipée d'une antenne FM/AM intégrée dans la vitre arrière/laterale, voir "Remarques sur les fils de commande et d'alimentation".
- ③ Au niveau du AMP REMOTE IN de l'amplificateur de puissance en option
Ce raccordement s'applique uniquement aux amplificateurs. Le branchement de tout autre système risque d'endommager l'appareil.
- ④ Vers le cordon de liaison d'un téléphone de voiture
- ⑤ Au signal d'éclairage de la voiture
Raccordez d'abord le fil de masse noir.
- ⑥ À la borne +12 V qui est alimentée quand la clé de contact est sur la position accessoires
- Remarques**
- S'il n'y a pas de position accessoires, raccordez la borne d'alimentation (batterie) +12 V qui est alimentée en permanence. Raccordez d'abord le fil de masse noir.
 - Si votre voiture est équipée d'une antenne FM/AM intégrée dans la vitre arrière/laterale, voir "Remarques sur les fils de commande et d'alimentation".
- ⑦ À la borne +12 V qui est alimentée en permanence
Raccordez d'abord le fil de masse noir.
- Remarques sur les fils de commande et d'alimentation**
- Le fil de commande de l'antenne électrique (bleu) fournit une alimentation de +12 V CC lorsque vous mettez l'appareil sous tension.
 - Lorsque votre voiture est équipée d'une antenne FM/AM intégrée dans la vitre arrière/laterale, raccordez la sortie de commande de l'antenne (bleu) ou l'entrée d'alimentation des accessoires (rouge) au bornier de l'amplificateur d'antenne existant. Pour plus de détails, consultez votre revendeur.
 - Une antenne électrique sans boîtier de relais ne peut pas être utilisée avec cet appareil.
- Raccordement pour la conservation de la mémoire**
Lorsque le fil d'entrée d'alimentation jaune est raccordé, le circuit de la mémoire est alimenté en permanence même si la clé de contact est sur la position d'arrêt.
- Remarques sur le raccordement des haut-parleurs**
- Avant de raccorder les haut-parleurs, mettez l'appareil hors tension.
 - Utilisez des haut-parleurs ayant une impédance de 4 à 8 ohms avec une capacité de manipulation adéquate pour éviter de les endommager.
 - Ne raccordez pas les bornes du système de haut-parleur au châssis de la voiture et ne raccordez pas les bornes du haut-parleur droit à celles du haut-parleur gauche.
 - Ne raccordez pas le câble de masse de cet appareil à la borne négative (-) de l'enceinte.
 - N'essayez pas de raccorder les haut-parleurs en parallèle.
 - Pour éviter tout dysfonctionnement, n'utilisez pas les fils des haut-parleurs intégrés installés dans votre voiture si l'appareil partage un fil négatif commun (-) pour les haut-parleurs droit et gauche.
 - Ne raccordez pas entre eux les cordons des haut-parleurs de l'appareil.

Precauciones

- Esta unidad ha sido diseñada para alimentarse con 12 V CC, negativo a masa, solamente.
 - No coloque los cables debajo de ningún tornillo, ni los aprisione con partes móviles (p.ej. los ratles del asiento).
 - Antes de realizar las conexiones, desconecte el terminal de puesta a masa de la batería del automóvil a fin de evitar cortocircuitos.
 - Conecte los cables de entrada de alimentación amarillo y rojo solamente después de haber conectado los demás.
 - Conecte todos los conductores de puesta a masa a un punto común.
 - Por razones de seguridad, asegúrese de aislar con cinta eléctrica los cables sueltos que no estén conectados.
- Notas sobre el cable de suministro de alimentación (amarillo)**
- Cuando conecte esta unidad en combinación con otros componentes estéreo, la capacidad nominal del circuito conectado del automóvil debe ser superior a la suma del fusible de cada componente.
 - Si no hay circuitos del automóvil con capacidad nominal suficientemente alta, conecte la unidad directamente a la batería.


Lista de componentes (1)

Los números de la lista corresponden a los de las instrucciones.

Con respecto al uso de la llave de liberación (2), consulte el manual de instrucciones suministrado.

Precaución

Tenga mucho cuidado al manipular el soporte (1) para evitar posibles lesiones en los dedos.



Ejemplo de conexiones (2)

Notas (2-A)
Asegúrese de conectar primero el cable de puesta a masa antes de realizar la conexión al amplificador.

Consejo (2-B-C)
Si desea conectar dos o más cambiadores, necesitará el selector de fuente XA-C30 (opcional).

Diagramas de conexión (3)







① A una superficie metálica del automóvil
Conecte primero el cable de masa negro, y después los cables amarillo y rojo de entrada de alimentación.




② Al cable de control de la antena motorizada o al cable de fuente de alimentación del amplificador de antena

- Notas**
- Si no se dispone de antena motorizada ni de amplificador de antena, o se utiliza una antena telescópica accionada manualmente, no será necesario conectar este cable.
 - Si el automóvil incorpora una antena de FM/AM en el cristal trasero/lateral, consulte "Notas sobre los cables de control y de fuente de alimentación".
- ③ Para conectar a AMP REMOTE IN del amplificador de potencia opcional
Esta conexión es sólo para amplificadores. La conexión de cualquier otro sistema puede dañar la unidad.
- ④ Al cable de interfaz de un teléfono para automóvil
- ⑤ A una señal de iluminación del automóvil
Asegúrese de conectar primero el cable de masa negro.
- ⑥ Al terminal de alimentación de +12 V que recibe energía en la posición de accesorios del interruptor de la llave de encendido
- Notas**
- Si no hay posición de accesorios, conecte al terminal de alimentación (batería) de +12 V que recibe energía sin interrupción. Asegúrese de conectar primero el cable de masa negro.
 - Si el automóvil incorpora una antena de FM/AM en el cristal trasero/lateral, consulte "Notas sobre los cables de control y de fuente de alimentación".
- ⑦ Al terminal de alimentación de +12 V que recibe energía sin interrupción
Asegúrese de conectar primero el cable de masa negro.
- Notas sobre los cables de control y de fuente de alimentación**
- El conductor de control de la antena motorizada (azul) suministrará +12 V CC cuando conecte la alimentación del sintonizador.
 - Si el automóvil dispone de una antena de FM/AM incorporada en el cristal trasero/lateral, conecte el cable de control de antena motorizada (azul) o el cable de entrada de alimentación auxiliar (rojo) al terminal de alimentación del amplificador de antena existente. Para obtener información detallada, consulte a su proveedor.
 - Con esta unidad no es posible utilizar una antena motorizada sin caja de relé.
- Conexión para protección de la memoria**
Si conecta el conductor de entrada amarillo, el circuito de la memoria recibirá siempre alimentación, incluso aunque ponga la llave de encendido en la posición OFF.
- Notas sobre la conexión de los altavoces**
- Antes de conectar los altavoces, desconecte la alimentación de la unidad.
 - Utilice altavoces con una impedancia de 4 a 8 ohmios con la capacidad de potencia adecuada para evitar que se dañen.
 - No conecte los terminales de altavoz al chasis del automóvil, ni conecte los terminales del altavoz derecho con los del izquierdo.
 - No conecte el cable de puesta a tierra de esta unidad al terminal negativo (-) del altavoz.
 - No intente conectar los altavoces en paralelo.
 - Conecte solamente altavoces pasivos. Si conecta altavoces activos (con amplificadores incorporados) a los terminales de altavoz, puede dañar la unidad.
 - Para evitar fallos de funcionamiento, no utilice los cables de altavoz incorporados instalados en el automóvil si su unidad comparte un cable negativo común (-) para los altavoces derecho e izquierdo.
 - No conecte los cables de altavoz de la unidad entre sí.

AEP, UK, E MODEL
Connection

Equipment used in illustrations (not supplied)
In Abbildungen dargestellte Geräte (nicht mitgeliefert)
Appareils utilisés dans les illustrations (non fournis)
Apparecchiatura utilizzata nelle illustrazioni (non in dotazione)
Apparatuur gebruikt voor illustratiedoeleinden (niet meegeleverd)

 Front speaker Frontlautsprecher Haut-parleur avant Diffusori anteriori Voorluidspreker	 Power amplifier Endverstärker Amplificateur de puissance Amplificatore di potenza Eindverstärker
 Rear speaker Haut-parleur arrière Diffusori posteriori Achterluidspreker	 CD/MD changer CD/MD-Wechsler Changeur de CD/MD Cambia CD/MD CD/MD-wisselaar
 Active subwoofer Haut-parleur d'extrêmes-graves actif Aktiver Tieftöner Actieve subwoofer Subwoofer attivo	 Rotary commander RM-X45 Joystick RM-X45 Satellite de commande RM-X45 Telecomando a rotazione RM-X45 Bedieningsatelliet RM-X45



Cautions

- This unit is designed for negative earth 12 V DC operation only.
- Do not get the wires under a screw, or caught in moving parts (e.g. seat railing).
- Before making connections, turn the car ignition off to avoid short circuits.
- Connect the power connecting cord ③ to the unit and speakers before connecting it to the auxiliary power connector.
- Run all earth wires to a common earth point.
- Be sure to insulate any loose unconnected wires with electrical tape for safety.

Notes on the power supply cord (yellow)

- When connecting this unit in combination with other stereo components, the connected car circuit's rating must be higher than the sum of each component's fuse.
- When no car circuits are rated high enough, connect the unit directly to the battery.


Parts list (1)

The numbers in the list are keyed to those in the instructions.

For the use of release key ②, see the supplied operating instructions.

Caution

Handle the bracket ① carefully to avoid injuring your fingers.



Connection example (2)

Notes (2-A)

- Be sure to connect the earth cord before connecting the amplifier.
- If you connect an optional power amplifier and do not use the built-in amplifier, the beep sound will be deactivated.

Tip (2-B-1)

For connecting two or more CD/MD changers, the source selector XA-C30 (optional) is necessary.

Connection diagram (3)

- A** To AMP REMOTE IN of an optional power amplifier
This connection is only for amplifiers. Connecting any other system may damage the unit.
- B** To the interface cable of a car telephone.

Warning

If you have a power aerial without a relay box, connecting this unit with the supplied power connecting cord ③ may damage the aerial.

Notes on the control leads

- The power aerial control lead (blue) supplies +12 V DC when you turn on the tuner or when you activate the AF (Alternative Frequency), TA (Traffic Announcement) function.
- When your car has built-in FM/MW/LW aerial in the rear/side glass, connect the power aerial control lead (blue) or the accessory power input lead (red) to the power terminal of the existing aerial booster.
- A power aerial without a relay box cannot be used with this unit.

Memory hold connection

When the yellow power input lead is connected, power will always be supplied to the memory circuit even when the ignition switch is turned off.

Notes on speaker connection

- Before connecting the speakers, turn the unit off.
- Use speakers with an impedance of 4 to 8 ohms and with adequate power handling capacities to avoid its damage.
- Do not connect the speaker terminals to the car chassis, or connect the terminals of the right speakers with those of the left speaker.
- Do not connect the earth lead of this unit to the negative (-) terminal of the speaker.
- Do not attempt to connect the speakers in parallel.
- Connect only passive speakers. Connecting active speakers (with built-in amplifiers) to the speaker terminals may damage the unit.
- To avoid a malfunction, do not use the built-in speaker wires installed in your car if the unit shares a common negative (-) lead for the right and left speakers.
- Do not connect the unit's speaker cords to each other.

Vorsicht

- Dieses Gerät ist ausschließlich für den Betrieb bei 12 V Gleichstrom (negative Erdung) bestimmt.
- Achten Sie darauf, daß die Kabel nicht unter einer Schraube oder zwischen beweglichen Teilen wie z. B. in einer Sitzlehne eingeklemmt werden.
- Schalten Sie, bevor Sie irgendwelche Anschlüsse vornehmen, die Zündung des Fahrzeuges aus, um Kurzschlüsse zu vermeiden.
- Verbinden Sie das Stromversorgungskabel ③ mit dem Gerät und den Lautsprechern, bevor Sie es mit dem Hilfsstromanschluß verbinden.
- Schließen Sie alle Erdungskabel an einen gemeinsamen Massepunkt an.
- Aus Sicherheitsgründen müssen alle losen, nicht angeschlossenen Drähte mit Isolierband abisoliert werden.

Hinweise zum Stromversorgungskabel (3)

- Wenn Sie dieses Gerät zusammen mit anderen Stereokomponenten anschließen, muß der Autostromkreis, an den die Geräte angeschlossen sind, eine höhere Leistung aufweisen als die Summe der Sicherungen der einzelnen Komponenten.
- Wenn kein Autostromkreis eine so hohe Leistung aufweist, schließen Sie das Gerät direkt an die Batterie an.


Teilleiste (1)

Die Nummern in der Liste sind dieselben wie im Erläuterungsteil.

Wie Sie den Löseschlüssel ② verwenden, schlagen Sie bitte in der mitgelieferten Bedienungsanleitung nach.

Vorsicht

Seien Sie beim Umgang mit der Halterung ① vorsichtig, damit Sie sich nicht die Hände verletzen.



Anschlußbeispiel (2)

Hinweise (2-A)

- Schließen Sie unbedingt zuerst das Massekabel an, bevor Sie den Verstärker anschließen.
- Wenn Sie einen gesondert erhältlichen Endverstärker anschließen und den integrierten Verstärker nicht benutzen, wird der Signalton deaktiviert.

Tip (2-B-1)

Zum Anschließen von zwei oder mehr CD/MD-Wechslern wird der gesondert erhältliche Signalquellenwähler XA-C30 benötigt.

Anschlußdiagramm (3)

- A** An AMP REMOTE IN des gesondert erhältlichen Endverstärkers
Dieser Anschluß ist ausschließlich für Verstärker gedacht. Schließen Sie nichts anderes daran an. Andernfalls kann das Gerät beschädigt werden.
- B** An Schnittstellenkabel eines Autotelefon

Warnung

Wenn Sie eine Motorantenne ohne Relaiskästchen verwenden, kann durch Anschließen dieses Geräts mit dem mitgelieferten Stromversorgungskabel ③ die Antenne beschädigt werden.

Hinweise zu den Steuerleitungen


- Die Motorantennen-Steuereleitung (blau) liefert +12 V Gleichstrom, wenn Sie den Tuner einschalten oder die AF- (Alternativfrequenzsuche) oder die TA-Funktion (Verkehrsrundschau) aktivieren.
- Wenn das Fahrzeug mit einer in der Heck-/Seitenfensterscheibe integrierten FM (UKW)/MW/LW-Antenne ausgestattet ist, schließen Sie die Motorantennen-Steuereleitung (blau) oder die Zubehörstromversorgungsleitung (rot) an den Stromversorgungsanschluß des vorhandenen Antennenverstärkers an. Näheres dazu erfahren Sie bei Ihrem Händler.
- Es kann nur eine Motorantenne mit Relaiskästchen angeschlossen werden.

Stromversorgung des Speichers

Wenn das gelbe Stromversorgungskabel angeschlossen ist, wird der Speicher stets (auch bei ausgeschalteter Zündung) mit Strom versorgt.

Hinweise zum Lautsprecheranschluß

- Schalten Sie das Gerät aus, bevor Sie die Lautsprecher anschließen.
- Verwenden Sie Lautsprecher mit einer Impedanz zwischen 4 und 8 Ohm und ausreichender Belastbarkeit. Ansonsten können die Lautsprecher beschädigt werden.
- Verbinden Sie die Lautsprecheranschlüsse nicht mit dem Wagenschluss, und verbinden Sie auch nicht die Anschlüsse des rechten mit denen des linken Lautspechers.
- Verbinden Sie die Masseleitung dieses Geräts nicht mit dem negativen (-) Lautsprecheranschluß.
- Versuchen Sie nicht, Lautsprecher parallel anzuschließen.
- An die Lautsprecheranschlüsse dieses Geräts dürfen nur Passivlautsprecher angeschlossen werden. Schließen Sie keine Aktivlautsprecher (Lautsprecher mit eingebauten Verstärkern) an, da diese sonst beschädigt werden können.
- Um Fehlfunktionen zu vermeiden, verwenden Sie nicht die im Fahrzeug installierten, integrierten Lautsprecherleitungen, wenn am Ende eine gemeinsame negative (-) Leitung für den rechten und den linken Lautsprecher verwendet wird.
- Verbinden Sie nicht die Lautsprecherkabel des Geräts miteinander.



Attenzione
 • Questo apparecchio è stato progettato per l'uso solo a 12 V CC con massa negativa.
 • Evitare che i cavi rimangano bloccati da una vite o montati nelle parti mobili (ad esempio nelle guide scorrevoli dei sedili).
 • Prima di effettuare i collegamenti, spegnere il motore dell'automobile onde evitare di causare cortocircuiti.
 • Collegare il cavo di alimentazione dell'alimentazione all'apparecchio e ai diffusori prima di collegarlo al connettore di alimentazione ausiliario.
 • Portare tutti i cavi di massa a un punto di massa comune.
 • Per sicurezza, assicurarsi di isolare qualsiasi cavo non collegato mediante apposite nastri.

Note sul cavo di alimentazione (giallo)
 • Se questo apparecchio viene collegato con altri componenti stereo, la potenza nominale dei circuiti dell'automobile deve essere superiore a quella prevista dalla somma dei fusibili di ciascun componente.
 • Se la potenza nominale dei circuiti dell'automobile non è sufficiente, collegare l'apparecchio direttamente alla batteria.

Elenco dei componenti (1)
 I numeri nella lista corrispondono a quelli riportati nelle istruzioni.
 Per informazioni sull'utilizzo del tasto di rilascio (2), vedere le istruzioni per l'uso in dotazione.

Attenzione
 Maneggiare la staffa (3) con cautela per evitare di ferirsi le mani.

Let op!
 • Dit apparaat is ontworpen voor gebruik op gelijkstroom van een 12 Volts auto-accu, negatief geaard.
 • Zorg ervoor dat de draden niet onder een schroef of tussen bewegende onderdelen (bv. zetelruimte) terechtkomen.
 • Alvorens aansluitingen te verrichten moet u het contact afzetten om kortsluiting te vermijden.
 • Sluit het netsnoer (2) aan op het toestel en de luidsprekers voordat u het op de hulpspeelvoeding aansluit.
 • Sluit alle aarddraden op een gemeenschappelijk aardpunt aan.
 • Voorziet niet aangesloten draden om veiligheidsredenen altijd van isolatietape.

Opmerkingen bij de voedingskabel (geel)
 • Wanneer u dit toestel aansluit samen met andere componenten, moet het vermogen van de aangesloten auto-accu groter zijn dan de som van de zekeringen van elke component afzonderlijk.
 • Wanneer het vermogen ontoereikend is, moet u het toestel rechtstreeks aansluiten op de batterij.

Onderdelenlijst (1)
 De nummers in de afbeelding verwijzen naar die in de montage-aanwijzingen.
 Raadpleeg de meegeleverde gebruikersaanwijzing om de speciale sleutel te bedienen (3).

Voorzichtig
 Houd de beugel (3) voorzichtig vast zodat u uw vingers niet verwondt.

Voorbeeldaansluitingen (2)
 Opmerkingen (2-A)
 • Sluit eerst de massakabel aan alvorens de versterker aan te sluiten.
 • Als u een wettigbare vermogensversterker aansluit en de ingebouwde versterker niet gebruikt, is de piptoont uitgeschakeld.
 Tip (2-B) (3)
 Om twee of meer CD/MD-wisselaars te laten sluiten, hebt u een ander systeem aan te sluiten, hebt u een auto-antenne (optioneel) nodig.

Aansluitschema (3)
 • Naar AMP REMOTE IN van een los verkrijgbare vermogensversterker
 Deze aansluiting is alleen bedoeld voor versterkers. Door een ander systeem aan te sluiten kan het toestel worden beschadigd.
 • Naar het interface-snoer van een autotelefoon

Opgelet
 Indien u een elektrische antenne heeft zonder relaiskast, kan het aansluiten van deze eenheid met het bijgeleverde netsnoer (2) de antenne beschadigen.

Opmerkingen betreffende de aansluitingen
 • De voedingskabel (blauw) van de elektrisch bediende antenne levert +12V gelijkstroom wanneer u de tuner aanschakelt of de functie AF (Alternative Frequency) of TA (Traffic Announcement) activeert.
 • Wanneer uw auto is uitgerust met een FM/AM/LW-antenne in de achterruitvoorsluit, moet u de antennevoedingskabel (blauw) of de hulpspeelvoeding (rood) aansluiten op de voedingsingang van de bestaande antenneversterker. Raadpleeg uw dealer voor meer details.
 • Met dit apparaat is het niet mogelijk een automatische antenne zonder relaiskast te gebruiken.
 Instandhouden van het gehuigen
 Zorg dat gele stroomdraad is aangesloten, blijft de stroomvoorziening van het gehuigen intact, ook wanneer het contact van de auto wordt uitgeschakeld.
 Opmerkingen betreffende het aansluiten van de luidsprekers
 • Zorg dat het apparaat is uitgeschakeld, alvorens de luidsprekers aan te sluiten.
 • Gebruik luidsprekers met een impedantie van 4 tot 8 Ohm en niet op dat die het vermogen van de versterker kunnen verliezen. Als dit wordt verzuimd, kunnen de luidsprekers ernstig beschadigd raken.
 • Verbind in geen geval de aansluitingen van de luidsprekers met het chassis van de auto en sluit de aansluitingen van de rechter en linker luidspreker niet op elkaar aan.
 • Verbind de massakabel van dit toestel niet met de negatieve (-) aansluiting van de luidspreker.
 • Probeer nooit de luidsprekers parallel aan te sluiten.
 • Sluit geen actieve luidsprekers (met ingebouwde versterkers) aan op de luidspreker-aansluiting van dit apparaat. Dit zal leiden tot beschadiging van de actieve luidsprekers. Sluit dus altijd uitsluitend luidsprekers zonder ingebouwde versterker aan.
 • Om defecten te vermijden mag u de bestaande luidsprekerbedrading in uw auto niet gebruiken wanneer er een gemeenschappelijke negatieve (-) draad is voor de rechter en linker luidsprekers.
 • Verbind de luidsprekerdraden niet met elkaar.

Précautions
 • Cet appareil est conçu pour fonctionner sur courant continu de 12 V avec masse négative.
 • Évitez de fixer des vis sur les câbles ou de coincer ceux-ci dans des pièces mobiles (par exemple, armature de siège).
 • Avant d'effectuer des raccordements, éteignez le moteur pour éviter les courts-circuits.
 • Branchez le cordon d'alimentation (2) sur l'appareil et les haut-parleurs avant de le brancher sur le connecteur d'alimentation auxiliaire.
 • Rassemblez tous les fils de terre en un point de masse commun.
 • Veillez à isoler avec du châtignon tout fil lâche non raccordé.

Remarques sur le cordon d'alimentation (jaune)
 • Lorsque cet appareil est raccordé à d'autres éléments-stéréo, la valeur nominale des circuits de la voiture raccordés doit être supérieure à la somme des fusibles de chaque élément.
 • Si aucun circuit de la voiture n'est assez puissant, raccordez directement l'appareil à la batterie.

Liste des composants (1)
 Les numéros de l'illustration correspondent à ceux des instructions.
 Pour l'utilisation de la clé de déblocage (3), reportez-vous au mode d'emploi.

Attention
 Manipulez précautionneusement le support (3) pour éviter de vous blesser aux doigts.

Exemple de raccordement (2)
 Remarques (2-A)
 • Raccordez d'abord le fil de masse avant de raccorder l'amplificateur.
 • Si vous raccordez un amplificateur de puissance indépendant et que vous n'utilisez pas l'amplificateur intégré, le bip sonore est désactivé

Conseil (2-B) (3)
 Dans le cas du raccordement de deux changeurs de CD/MD ou plus, le sélecteur de source XA-C30 (en option) est indispensable.

Schéma de raccordement (3)
 A Au niveau du AMP REMOTE IN d'un amplificateur de puissance facultatif
 Ce raccordement existe seulement pour les amplificateurs. Le raccordement à tout autre système peut endommager l'appareil.
 B Vers le cordon de liaison d'un téléphone de voiture

Avertissement
 Si vous disposez d'une antenne électrique sans boîtier de relais, le branchement de cet appareil au moyen du cordon d'alimentation fourni (2) risque d'endommager l'antenne.


Remarques sur les fils de contrôle
 • Le fil de commande (bleu) de l'antenne électrique assure une alimentation de +12 V CC lorsque vous activez la fonction AF (fréquence secondaire) ou TA (informations routières).
 • Lorsque votre voiture est équipée d'une antenne FM/AM/LW intégrée dans la vitre arrière latérale, raccordez la sortie de commande de l'antenne (bleu) ou l'entrée d'alimentation des accessoires (rouge) au bornier de l'amplificateur d'antenne existant. Pour plus de détails, consultez votre revendeur.
 • Une antenne électrique sans boîtier de relais ne peut pas être utilisée avec cet appareil.

Raccordement pour la conservation de la mémoire
 Lorsque le fil d'entrée d'alimentation jaune est raccordé, le circuit de la mémoire est alimenté en permanence même si la clé de contact est sur la position d'arrêt.

Remarques sur le raccordement des haut-parleurs
 • Avant de raccorder les haut-parleurs, mettez l'appareil hors tension.
 • Utilisez des haut-parleurs ayant une impédance de 4 à 8 Ohms avec une capacité de manipulation adéquate pour éviter de les endommager.
 • Ne raccordez pas les bornes du système de haut-parleurs au châssis de la voiture et ne raccordez pas les bornes du haut-parleur droit à celles du haut-parleur gauche.
 • Ne raccordez pas le câble de masse de cet appareil à la borne négative (-) de l'enceinte.
 • N'essayez pas de raccorder les haut-parleurs en parallèle.
 • Raccordez uniquement des haut-parleurs passifs.
 • Le raccordement de haut-parleurs actifs (avec amplificateurs intégrés) aux bornes des haut-parleurs peut endommager l'appareil.
 • Pour éviter tout dysfonctionnement, n'utilisez pas les fils des haut-parleurs intégrés installés dans votre voiture si l'appareil partage un fil négatif commun (-) pour les haut-parleurs droit et gauche.
 • Ne raccordez pas entre eux les cordons des haut-parleurs de l'appareil.

**SECTION 2
DISASSEMBLY**


Note : This set can be disassemble according to the following sequence.




Note : Follow the disassembly procedure in the numerical order given.

2-1. FRONT PANEL ASSY (NORMAL)


1 Turn on the power and open the front panel.




2-2. FRONT PANEL ASSY (INOPERATIVE)



2-3. CD MECHANISM BLOCK, FRONT PANEL (KEY) ASSY




2-4. SUB PANEL (CD) SUB ASSY




2-5. MOTOR BLOCK ASSY, CAM (R) ASSY


Note : Install the motor block assy and cam (R) assy in this roder.
For phase alignment between cams (L) and (R), see page 22 and 24.




2-6. MAIN BOARD




2-7. HEAT SINK




2-8. CHASSIS (T) SUB ASSY




2-9. LEVER SECTION




2-10. SERVO BOARD




2-11. SHAFT ROLLER ASSY



2-12. FLOATING BLOCK ASSY




2-13. OPTICAL PICK-UP BLOCK




SECTION 3 PHASE ALIGNMENT

3-1. ARM (A-L) ASSY, ARM (B-L) ASSY




3-2. CAM (L)

- 1 Move the arm (B-L) assy in the direction of the arrow **A** and the arm (A-L) assy in the direction of the arrow **B** fully (full open state).
- 2 Align the hole (large) on the cam (L) with part **C** and install the cam.
- 4 Turn the cam (L) clockwise and counterclockwise to verify that both the arms are operated.




3-3. MOTOR BLOCK

- 1 Turn the cam (L) and position the cam so that part **A** does not touch the SWITCH board SW900.




3-4. ALIGNMENT BETWEEN ARM (A-L) ASSY AND ARM (B-L) ASSY

- 1 Input 9V DC to the motor terminal until the cam (L) stops rotating.
Take care to avoid overload of the motor.
- 2 Verify that the arm (A-L) assy and arm (B-L) assy are positioned as shown below (full open).




3-5. ARM (A-R) ASSY, ARM (B-R) ASSY



3-6. CAM (R)

- 1 Move the arm (B-R) assy in the direction of the arrow **A** and the arm (A-R) assy in the direction of the arrow **B** fully (full open state).
- 2 Align the hole (large) on the cam (R) with part **C** and install the cam.
- 4 Turn the cam (R) clockwise and counterclockwise to verify that both the arms are operated.



SECTION 4 DIAGRAMS

4-1. IC PIN DESCRIPTIONS

• IC501 CXD2598Q (DIGITAL SERVO, DIGITAL SIGNAL PROCESSOR) (SERVO BOARD)

Pin No.	Pin Name	I/O	Pin Description
1	DVDD	—	Digital power supply pin
2	DVSS	—	Digital ground
3	SOUT	O	Servo brock serial data output (Not used.)
4	SOCK	O	Servo brock serial data read clock output (Not used.)
5	XOLT	O	Servo brock serial data latch output (Not used.)
6	SQSO	O	Sub Q 80 bit, PCM peak and level data output. CD TEXT data output
7	SQCK	I	Clock input from SQSO read out.
8	SCSY	I	Fixed at “L”.
9	SBSO	O	Serial output of sub-P to W. (Not used.)
10	EXCK	I	Clock input from SBSO read out. (Fixed at “L”)
11	XRST	I	System reset (“L”: Reset)
12	STSM	I	System mute input (Fixed at “L”)
13	DATA	I	Serial data input from CPU.
14	XLAT	I	Latch input from CPU. Latch serial data at the falling edge.
15	CLOK	I	Serial data transfer clock input from CPU.
16	SENS	O	SENS output for CPU.
17	SCLK	I	Clock input from SENS serial data read.
18	ATSK	I/O	Input/output for anti-shock.
19	WFCK	O	WFCK (Write Flame Clock) output (Not used.)
20	XUGF	O	XUGF output (Not used.)
21	XPCK	O	XPCK output (Not used.)
22	GFS	O	GFS output
23	C2PO	O	C2PO output (Not used.)
24	SCOR	O	“H” output at either detection, sub code sync S0 or S1.
25	C4M	O	4.2336 MHz output (Not used.)
26	WDCK	O	Word clock output $f=2Fs$ (Not used.)
27	COUT	I/O	Track number count signal input/output (Not used.)
28	MIRR	I/O	Mirror signal input/output (Not used.)
29	DVSS	—	Digital ground
30	DVDD	—	Digital power supply pin
31	DFCT	I/O	Diffect signal input/output (Not used.)
32	FOK	I/O	Focus OK signal input/output
33	PWM1	I	External control input of spindle motor.
34	LOCK	I/O	Lock signal input/output
35	MDP	O	Servo control output of spindle motor.
36	SSTP	I	Disc most inner track detection signal input
37	FSTIO	I/O	2/3 frequency division input/output of pins ⑥⑥ and ⑥⑦. (Not used.)
38	SFDR	O	Sled drive output
39	SRDR	O	Sled drive output
40	TFDR	O	Tracking drive output
41	TRDR	O	Tracking drive output
42	FFDR	O	Focus drive output
43	FRDR	O	Focus drive output
44	DVDD	—	Digital power supply pin
45	DVSS	—	Digital ground
46	TEST	I	Test pin (Fixed at “L”).
47	TES1	I	Test pin (Fixed at “L”).
48	XTSL	I	X’tal select input (“L”: 16.9344 MHz, “H”: 33.8688 MHz)
49	VC	I	Center voltage input
50	FE	I	Focus error signal input
51	SE	I	Sled error signal input

Pin No.	Pin Name	I/O	Pin Description
52	TE	I	Tracking error signal input
53	CE	I	Center servo analog input
54	RFDC	I	RF signal input
55	ADIO	O	Test pin (Not used.)
56	AVSSO	—	Analog ground
57	IGEN	I	Constant current input from OP amplifier.
58	AVDDO	—	Analog ground
59	ASYO	O	EFM full-swing output (“L”: VSS, “H”: VDD)
60	ASYI	I	Asymmetry compare voltage input
61	RFAC	I	EFM signal input
62	AVSS3	—	Analog ground
63	CLTV	I	VCO control voltage input from master.
64	FILO	O	Filter output for master PLL. (slave=digital PLL)
65	FILI	I	Filter input from master PLL.
66	PCO	O	Charge pump output for master PLL.
67	AVDD3	—	Analog power supply pin
68	BIAS	I	Asymmetry circuit constant current input
69	VCTL	I	VCO2 control input from wideband EFM PLL.
70	V16M	O	VCO2 oscillator output for wideband EFM PLL. (Not used.)
71	VPCO	O	Charge pump output for wideband EFM PLL. (Not used.)
72	DVSS	—	Digital ground
73	MD2	I	Digital out ON/OFF control input (“L”: OFF, “H”: ON)
74	DOUT	O	Digital out output
75	ASYE	I	Asymmetry circuit ON/OFF input (“L”: OFF, “H”: ON)
76	DVDD	—	Digital power supply pin
77	LRCK	O	D/A interface LR clock output (f=Fs)
78	LRCKI	I	D/A interface LR clock input
79	PCMD	O	D/A interface serial data output (2’s COMP, MSB fast)
80	PCMD	I	D/A interface serial data input (2’s COMP, MSB fast)
81	BCK	O	D/A interface bit clock output
82	BCKI	I	D/A interface bit clock input
83	EMPH	O	Emphasis ON/OFF signal output
84	EMPHI	I	Emphasis ON/OFF signal input (“H”: ON, “L”: OFF)
85	XVDD	—	Power supply for master clock.
86	XTAI	I	X’tal oscillator input from master clock (16.9344 MHz).
87	XTAO	O	X’tal oscillator output for master clock (16.9344 MHz). (Not used.)
88	XVSS	—	Ground pin for master clock.
89	AVDD1	—	Analog power supply pin
90	AOUT1	O	Lch analog output (Not used.)
91	AIN1	I	Lch OP amplifier input (Not used.)
92	LOUT1	O	Lch LINE output (Not used.)
93	AVSS1	—	Analog ground
94	AVSS2	—	Analog ground
95	LOUT2	O	Rch LINE output (Not used.)
96	AIN2	I	Rch OP amplifier input (Not used.)
97	AOUT2	O	Rch analog output (Not used.)
98	AVDD2	—	Analog power supply pin
99	RMUT	O	Rch “0” detect Flug (Not used.)
100	LMUT	O	Lch “0” detect Flug (Not used.)

• IC5 CXP84640-072Q (CD SYSTEM CONTROL) (SERVO BOARD)

Pin No.	Pin Name	I/O	Pin Description
1	ITRPT	—	Not used in this set.
2, 3	—	—	Not used in this set.
4, 5	NCO	—	Not used in this set.
6	OPEN	I	Front panel open detection input
7	CLOSE	O	Front panel close control output
8	LINKOFF	I	Bus interface link input
9	NCO	—	Not used in this set.
10	$\overline{D SW}$	I	Down switch input (SW1)
11	SSTP	I	Limit switch input (SW4)
12, 13	NCO	—	Not used in this set.
14, 15	—	—	Not used in this set.
16	EMPH O	O	De-emphasis ON/OFF control output
17	CDMON	O	CD mechanism deck power control output
18	CD ON	O	CD power control output
19	A MUT	O	System attenuate control output
20	$\overline{LD ON}$	O	Laser power ON/OFF control output
21	$\overline{CD RST}$	O	CD system reset output
22	HOLD	O	Hold switch output
23	AGC CONT	O	AGC control output
24	—	—	Not used in this set.
25	PH3	I	Not used in this set.
26	$\overline{TSTIN0}$	I	Not used in this set.
27	$\overline{TSTIN1}$	I	Not used in this set.
28	$\overline{TST.CLV}$	I	Not used in this set.
29	NCO	—	Not used in this set.
30	\overline{RESET}	I	System reset input (“L”=Reset)
31	X IN	I	X’tal oscillator input from system clock. (10 MHz)
32	$\overline{X OUT}$	O	X’tal oscillator output for system clock. (10 MHz)
33	GND	—	Analog ground
34	$\overline{XT OUT}$	O	Not used in this set.
35	XT IN	I	Not used in this set.
36	AVSS	—	A/D converter ground
37	AVREF	I	A/D converter reference voltage input
38	TEP L	I	Not used in this set.
39	TEP H	I	Not used in this set.
40	SLED-	I	Sled drive input
41	PH2	I	Not used in this set.
42	SEK/SMET	I	Fixed at “H” in this set.
43	GFS/MNT2 SEL	I	Fixed at “H” in this set.
44	SC-JIG ON/OFF	I	Fixed at “H” in this set.
45	SCLK	O	CD-TEXT data read clock output
46	LOCK	I/O	Lock signal input/output
47	—	—	Not used in this set.
48	SCK2	O	Sub Q read clock output
49	SI2	I	Sub Q 80 bit, PCM peak and level data 16 bit input.
50	—	—	Not used in this set.
51	BUS CLK	I/O	Bus system serial clock input/output
52	BUS SI	I	Bus system serial interface input
53	BUS SO	O	Bus system serial interface output
54	F OK	I	Focus OK signal input
55	GFS	I	GFS signal detection input
56	TEST MODE	I	Fixed at “H” in this set.

CDX-M620/M670

Pin No.	Pin Name	I/O	Pin Description
57	SENS	I	SENS signal input
58	—	—	Not used in this set.
59	—	—	Not used in this set.
60	BU.IN	I	Back-up power detection input
61	$\overline{\text{BUSON}}$	I	Bus on control input
62	$\overline{\text{IN SW}}$	I	Disc in switch input (SW3)
63	$\overline{\text{SELF SW}}$	I	Self switch input (SW2)
64	SCOR	O	Sub-code sync output
65	CD-CKO	O	CD signal process serial clock output
66	LM LOD	O	Loading motor control output
67	CD DATA	O	CD signal process serial data output
68	CD-XLAT	O	CD signal process serial data latch output
69	LM-EJ	O	Loading motor control output
70	DRV-OE	O	Focus/tracking coil/sled motor control output
71	MD2	O	Digital out ON/OFF control output (“L”: OFF, “H”: ON)
72	VDD	—	Power supply pin
73	NIH	I	Fixed at “H” in this set.
74	V/Z	I	Fixed at “H” in this set.
75	PH1	I	Not used in this set.
76	—	—	Not used in this set.
77	DOUT-SEL	I	Fixed at “H” in this set.
78 – 80	—	—	Not used in this set.

- IC501 MB90574BPMT-G-321-BND (SYSTEM CONTROL) (MAIN BOARD) (US MODEL)
- IC501 MB90574BPMT-G-322-BND (SYSTEM CONTROL) (MAIN BOARD) (AEP, UK, E MODEL)

Pin No.	Pin Name	I/O	Pin Description
1 – 3	(NCO)	O	Not used. (Open)
4	SP LATCH	O	Spectrum analyzer data latch signal
5	ATT	O	System mute signal
6	SYS RST	O	System reset signal
7	(NCO)	O	Not used. (Open)
8	VCC	—	Power supply pin (+5 V)
9	(NCO)	O	Not used. (Open)
10	E2P SIO	I/O	Tuner unit EEPROM BUS serial data input/output
11	E2P CKO	I/O	Tuner unit EEPROM BUS serial clock input/output
12	FLS SI	I	Flash CPU write-in data input
13	FLS SO	O	Flash CPU write-in data output
14	BUS ON	O	BUS ON signal
15	BEEP	O	Beep signal
16	TEL ATT	I	Telephone mute signal
17	UNI SI	I	SONY BUS serial data input
18	UNI SO	O	SONY BUS serial data output
19	UNI CKO	O	SONY BUS serial clock output
20 – 23	(NCO)	O	Not used. (Open)
24	SIRCS	I	Wireless remote data input
25	DSP SI	I	DSP serial data input
26	DSP SO	O	DSP serial data output
27	DSP CKO	O	DSP serial clock output
28	DSP PLL	O	DSP PLL clock control signal
29	DSP MST	O	DSP master/slave control signal
30	(NCO)	O	Not used. (Open)
31	VOL ATT	O	Electronic volume mute signal
32	TU ATT	O	Not used. (Open)
33	VSS	—	Ground
34	C	—	Not used. (Open)
35	DSP LAT	O	DSP latch signal
36	DSP RST	O	DSP reset signal
37	SHIFT	O	OSC frequency shift signal for DC/DC conv.
38	DVCC	—	Power supply pin (+5 V)
39	DVSS	—	Ground
40	FP CTRL	O	OPEN/CLOSE motor voltage control signal
41	(NCO)	O	Not used. (Open)
42	AVCC	—	Power supply pin (+5 V)
43	AVRH	—	Power supply pin (+5 V)
44	AVRL	—	Ground
45	AVSS	—	Ground
46	KEY IN0	I	Key input 0
47	KEY IN1	I	Key input 1
48	RC IN0	I	Rotary commander input 0
49	(NCO)	O	Not used. (Open)
50	QUALITY	I	Noise detection signal
51	(NCO)	O	Not used. (Open)
52	MPTH	I	Tuner multi path detection signal
53	VSM	I	S-meter voltage detection signal
54	VCC	—	Power supply pin (+5 V)
55	STBY	O	Power amplifier drive signal
56	NS MASK	O	Noise detection ON/OFF control signal

Pin No.	Pin Name	I/O	Pin Description
57	DDC ON	O	DC/DC converter power control signal
58	CD EJECT OK	O	CD eject control signal
59	CD OPEN REQ	I	Front panel open request signal
60	(NCO)	O	Not used. (Open)
61	OPEN KEY	I	OPEN key detection signal
62	NOSE SW	I	Nose SW detection signal
63	VSS	—	Ground
64	DETACH SW	I	Detach SW detection signal
65	PWM	I	Oscillation frequency count input
66 – 68	(NCO)	O	Not used. (Open)
69	FLASH W	I	Flash write-in signal
70	I2C SIO	I/O	I2C serial data input/output
71	I2C CKO	I/O	I2C serial clock input/output
72	RC IN1	I	Rotary commander input 1
73	X1A	—	Crystal oscillator (32.768 kHz)
74	X0A	—	Crystal oscillator (32.768 kHz)
75	DAVN	I	RDS data acquisition detect signal
76	CDON IN	I	CD mechanism power control signal
77	BU IN	I	Back-up power detection signal
78	DSP READY	I	DSP ready signal
79	KEY ACK	I	Key acknowledge signal
80	AD ON	O	A/D converter power control signal
81	ACC IN	I	Accessory key ON signal
82	FLS PWON	O	Flash power ON control signal
83	PW ON	O	Audio circuit power ON control signal
84	TEST IN	I	Test mode initial setting detection signal
85	RAM BU	I	RAM reset detection signal
86	HSTX	I	Hardware standby input
87	MD2	I	Connecting to ground in this set.
88	MD1	I	Connecting to VCC in this set.
89	MD0	I	Connecting to VCC in this set.
90	RSTX	I	Reset input
91	VSS	—	Ground
92	X0	—	Crystal oscillator (3.68 MHz)
93	X1	—	Crystal oscillator (3.68 MHz)
94	VCC	—	Power supply pin (+5 V)
95	ILL IN	I	Illumination dimmer control signal
96	I DET	I	OPEN/CLOSE motor abnormal current detection
97	MOT –	O	OPEN/CLOSE motor control signal
98	MOT +	O	OPEN/CLOSE motor control signal
99	CLOSE SW	I	Close SW detection signal
100	OPEN SW	I	Open SW detection signal
101	CENT SW	I	Cent SW detection signal
102	(NCO)	O	Not used. (Open)
103	CDMD SEL	I	CD/MD selector signal
104	DEST SEL1	I	Destination selector signal 1
105	DEST SEL2	I	Destination selector signal 2
106	BOOT	O	Display CPU write-in control signal
107	(NCO)	O	Not used. (Open)
108	DSP ON	O	DSP power control signal
109	SENS ON	O	Not used. (Open)
110	EMPH IN	I	Emphasis input
111	PACK IN	I	Pack detection signal


Pin No.	Pin Name	I/O	Pin Description
112	4V SEL	I	4V select control signal
113	(NCO)	O	Not used. (Open)
114	TUN ON	O	Tuner power control signal
115	LED SW1	O	Illumination select control signal 1
116	LED SW2	O	Illumination select control signal 2
117	(NCO)	O	Not used. (Open)
118	(NCO)	O	Not used. (Open)
119	VSS	—	Ground
120	(NCO)	O	Not used. (Open)

• IC702 HD643255A36F (SUB SYSTEM CONTROL) (MAIN BOARD)


Pin No.	Pin Name	I/O	Pin Description
1	SA CLK	O	Not used. (Open)
2	PG4	O	Not used. (Open)
3	VSS	—	Ground
4	NC	—	Not used. (Open)
5	VCC	—	Power supply pin (+ 5V)
6 – 9	PC0 – PC3	O	Not used. (Open)
10	VSS	—	Ground
11 – 14	PC4 – PC7	O	Not used. (Open)
15 – 18	PB0 – PB3	O	Not used. (Open)
19	VSS	—	Ground
20 – 23	PB4 – PB7	O	Not used. (Open)
24 – 27	PA0 – PA3	O	Not used. (Open)
28	VSS	—	Ground
29 – 31	PA4 – PA6	O	Not used. (Open)
32	SA EN IN	I	Connecting to ground in this set.
33	SPE LAT	I	Spectrum analyzer data latch signal
34	BU IN	I	Back-up power detection signal
35, 36	VSS	—	Ground
37	P65	O	Not used. (Open)
38	BUS ON	I	BUS ON signal
39	VCC	—	Power supply pin (+5 V)
40 – 43	PE0 – PE3	O	Not used. (Open)
44	VSS	—	Ground
45	DSP SEL	I	Spectrum analyzer data select signal
46	LED SW1	I	Illumination select control signal 1
47	LED SW2	I	Illumination select control signal 2
48	PE7	O	Not used. (Open)
49	BU IN	O	Not used. (Open)
50	LINK OFF	O	Link OFF control signal
51	PD2	O	Not used. (Open)
52	ILL ON	O	Illumination power control signal
53	VSS	—	Ground
54 – 56	PD4 – PD6	O	Not used. (Open)
57	BOOT	I	Display CPU write-in control signal
58	VCC	—	Power supply pin (+5 V)
59	P30	O	Not used. (Open)
60	LCD SO/TX	O	LCD driver serial data output
61	SP SI	I	Spectrum analyzer data input
62	RX	I	Flash CPU write-in data input
63	SP CKI	I	Spectrum analyzer clock input
64	LCD CKO	O	LCD driver serial clock output
65	VSS	—	Ground
66	LCD CEO	O	LCD driver chip enable output
67, 68	VSS	—	Ground
69	LCD INH	O	LCD driver inhibit control signal
70	LCD CE1	O	LCD driver chip enable output
71	LCD CE2	O	LCD driver chip enable output
72 – 78	P27 – P21	O	Not used. (Open)
79	FL W	O	Flash write control signal
80	FW E	I	Flash write enable signal
81	SYS RST	I	System reset signal
82	NMI	I	Non maskable interrupt signal

Pin No.	Pin Name	I/O	Pin Description
83	STBY	I	Hardware standby signal
84	VCC	—	Power supply pin (+5 V)
85	XTAL	—	Crystal oscillator (18.432 MHz)
86	EXTAL	—	Crystal oscillator (18.432 MHz)
87	VSS	—	Ground
88	PF7	O	Not used. (Open)
89	VCC	—	Power supply pin (+5 V)
90 – 96	PF6 – PF0	O	Not used. (Open)
97	UNI SO	O	SONY BUS serial data output
98	UNI SI	I	SONY BUS serial data input
99, 100	VSS	—	Ground
101	UNI CKI	I	SONY BUS serial clock input
102	P53	O	Not used. (Open)
103	AVCC	—	Power supply pin (+5 V)
104	VREF	—	Power supply pin (+5 V)
105 – 112	P40 – P47	I	Connecting to ground in this set.
113	AVSS	—	Ground
114	VSS	—	Ground
115 – 122	P17 – P10	O	Not used. (Open)
123	MD0	I	Mode setting 0
124	MD1	I	Mode setting 1
125	MD2	I	Mode setting 2
126 – 128	PG0 – PG2	O	Not used. (Open)


4-2. CIRCUIT BOARDS LOCATION




4-3. BLOCK DIAGRAM — CD SECTION —



4-4. BLOCK DIAGRAM — TUNER SECTION —



4-5. BLOCK DIAGRAM — DISPLAY SECTION —



THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.
(In addition to this, the necessary note is printed in each block.)

for schematic diagram:

- All capacitors are in μF unless otherwise noted. pF: μpF
- 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $1/4\text{W}$ or less unless otherwise specified.
- % : indicates tolerance.
- Δ : internal component.
- : panel designation.

Note: The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

- — : B+ Line.
- Power voltage is dc 14.4V and fed with regulated dc power supply from ACC and BATT cords.
- Voltages are taken with a VOM (Input impedance 10 M Ω). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with an oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.
 - : FM
 - : AM/MW
 - : CD

for printed wiring boards:


- — : parts extracted from the component side.
- — : parts extracted from the conductor side.
- ○ : Through hole.
- : Pattern from the side which enables seeing. (The other layer's patterns are not indicated.)

Caution:
Pattern face side: Parts on the pattern face side seen from the (Side B) pattern face are indicated.
Parts face side: Parts on the parts face side seen from the (Side A) parts face are indicated.

• Waveforms

— Servo Board —


(MODE: CD PLAY)



• Waveforms


— Main Board —

(MODE: FM)



4-6. PRINTED WIRING BOARDS — CD MECHANISM SECTION —

【SERVO BOARD】(SIDE B)



1-676-706-

31

【SERVO BOARD】(SIDE A)


【PICK-UP FLEXIBLE BOARD】

1-676-707- 21

OPTICAL PICK-UP
KSS-720A


• Semiconductor Location

Ref. No.	Location
IC1	C-2
IC5	C-6
IC7	F-2
IC501	F-5
Q101	B-2




【DISC IN SW BOARD】


1 MAIN BOARD
CN401
(Page 43)



【LIMIT SW BOARD】




【MOTOR FLEXIBLE BOARD】 1-677-182- 11



• Refer to page 37 for Waveforms.

4-7. SCHEMATIC DIAGRAM — CD MECHANISM SECTION (1/2) — • Refer to page 54 for IC Block Diagrams.




Note:
• Voltage is dc with respect to ground under no-signal conditions.
no mark : CD PLAY

(Page 41)

(Page 46)


4-8. SCHEMATIC DIAGRAM — CD MECHANISM SECTION (2/2) — • Refer to page 37 for Waveforms. • Refer to page 54 for IC Block Diagrams.



Note:
 • Voltage is dc with respect to ground under no-signal conditions.
 no mark : CD PLAY

4-9. PRINTED WIRING BOARDS — MAIN SECTION —


【MAIN BOARD】(SIDE A)



• Semiconductor Location

Ref. No.	Location	Ref. No.	Location
D104	K-8	IC502	J-9
D107	E-2	IC650	J-2
D109	G-2	IC651	I-3
D202	C-13	IC652	I-3
D203	B-13	IC702	I-12
D204	G-8	IC801	I-9
D205	G-9		
D302	B-7	Q101	F-2
D303	B-6	Q102	F-1
D304	B-6	Q105	E-3
D309	G-7	Q107	H-4
D311	C-7	Q108	G-4
D404	C-4	Q109	K-9
D406	D-4	Q110	F-4
D407	C-6	Q111	E-4
D503	H-6	Q112	K-8
D505	H-5	Q114	D-2
D506	J-8	Q115	E-2
D507	J-8	Q116	E-2
D509	I-8	Q117	G-1
D511	H-5	Q118	G-1
D602	F-5	Q201	C-13
D604	G-4	Q202	H-10
D605	F-5	Q203	G-9
D606	G-4	Q301	B-10
D609	G-7	Q302	B-9
D612	G-6	Q303	B-11
D650	I-2	Q304	B-10
D804	J-10	Q305	B-11
D807	H-10	Q306	E-8
		Q307	E-7
		Q308	E-8
IC101	F-2	Q309	C-8
IC102	D-2	Q310	C-7
IC201	G-9	Q312	C-8
IC202	F-13	Q401	C-4
IC301	G-8	Q402	D-5
IC302	F-9	Q404	D-5
IC303	C-11	Q405	D-6
IC304	C-11	Q406	D-7
IC305	E-10	Q407	D-6
IC306	E-8	Q602	G-5
IC307	D-9	Q651	J-3
IC308	D-9	Q652	I-3
IC310	C-12		
IC501	I-6		

2
KEY BOARD
CN1
(Page 50)




• Semiconductor Location

Ref. No.	Location	Ref. No.	Location	Ref. No.	Location	Ref. No.	Location	Ref. No.	Location	Ref. No.	Location	Ref. No.	Location
D101	E-3	D306	B-8	D502	H-4	D608	G-7	D802	J-10	IC601	G-5	Q119	F-1
D102	F-3	D307	B-8	D504	I-4	D610	B-8	D803	J-5	IC701	I-12	Q501	I-5
D105	D-1	D308	B-8	D508	H-4	D611	B-2	D805	J-10			Q502	G-14
D106	E-2	D401	B-3	D510	G-4	D651	I-3	D806	J-11			Q603	G-5
D301	B-7	D405	C-5	D603	G-5	D652	J-4					Q650	I-2
D305	B-8	D501	B-2	D607	G-4	D801	J-12	IC309	A-7				


• Refer to page 37 for Waveforms.

4-10. SCHEMATIC DIAGRAM — MAIN SECTION (1/4) — • Refer to page 54 for IC Block Diagrams.



Note:
 • Voltage is dc with respect to ground under no-signal (detuned) condition.
 no mark : FM


4-11. SCHEMATIC DIAGRAM — MAIN SECTION (2/4) — • Refer to page 54 for IC Block Diagrams.



Note:
 • Voltage is dc with respect to ground under no-signal (detuned) condition.
 no mark : FM

• Refer to page 37 for Waveforms.


4-12. SCHEMATIC DIAGRAM — MAIN SECTION (3/4) — • Refer to page 54 for IC Block Diagrams.



Note:
 • Voltage is dc with respect to ground under no-signal (detuned) condition.
 no mark : FM
 () : AM/MW/LW
 < > : CD PLAY

• Refer to page 37 for Waveforms.


4-13. SCHEMATIC DIAGRAM — MAIN SECTION (4/4) — • Refer to page 54 for IC Block Diagrams.



Note:
 • Voltage is dc with respect to ground under no-signal (detuned) condition.
 no mark : FM


4-14. PRINTED WIRING BOARD — SUB (CD) SECTION —

【SUB (CD) BOARD】(SIDE A)



(Page 43)
MAIN BOARD
CN603

【SUB (CD) BOARD】(SIDE B)




• Semiconductor Location

Ref. No.	Location
D901	B-10
D902	B-6
D903	B-7
D906	B-10
D907	B-6
(D908)	B-13
IC901	B-13
Q901	B-9
Q902	B-9

() : SIDE B



4-15. SCHEMATIC DIAGRAM — SUB (CD) SECTION — • Refer to page 55 for IC Block Diagram.



Note:

- Voltage is dc with respect to ground under no-signal (detuned) condition.
- no mark : FM

4-16. PRINTED WIRING BOARD — KEY SECTION —



4
DISPLAY BOARD
CN60
(Page 52)


2
MAIN BOARD
CN604
(Page 42)

• Semiconductor Location

Ref. No.	Location	Ref. No.	Location	Ref. No.	Location
(D7)	A-8	LED5	B-2	LED14	A-13
(D8)	A-9	LED6	B-3	LED15	A-11
		LED7	C-1	LED16	C-11
(IC1)	B-7	LED8	C-3	LED17	B-12
		LED9	C-13	LED18	C-12
LED1	B-4	LED10	C-2		
LED2	B-10	LED11	A-3	Q1	A-4
LED3	B-2	LED12	A-2	Q2	A-3
LED4	B-3	LED13	C-13	Q3	B-4

(): SIDE B


4-17. SCHEMATIC DIAGRAM — KEY SECTION —



Note:
 • Voltage is dc with respect to ground under no-signal (detuned) condition.
 no mark : FM

4-18. PRINTED WIRING BOARD — DISPLAY SECTION —


【DISPLAY BOARD】(SIDE A)



(Page 50)
KEY BOARD
CN2

④

【DISPLAY BOARD】(SIDE B)




• Semiconductor Location

Ref. No.	Location	Ref. No.	Location	Ref. No.	Location
(D61)	A-11	(IC60)	B-9	LED66	B-2
(D62)	A-2	(IC61)	B-11	LED67	B-12
(D63)	A-2	(IC62)	A-13	LED68	C-2
(D64)	A-3			LED69	C-12
(D65)	A-3	LED60	A-1	(Q60)	A-2
(D66)	A-3	LED62	A-2	(Q61)	A-2
(D67)	B-10	LED63	A-12	(Q62)	B-2
(D68)	A-12	LED64	B-2		
(D70)	A-13	LED65	B-12		

() : SIDE B


4-19. SCHEMATIC DIAGRAM — DISPLAY SECTION — • Refer to page 55 for IC Block Diagrams.




Note:
 • Voltage is dc with respect to ground under no-signal (detuned) condition.
 no mark : FM

• IC BLOCK DIAGRAMS


IC1 CXA2596M




IC7 LA6576L-TE-L




IC306 TC7660SE0A713




IC101 TL1451ACDB-E20




IC601 BA8270F-E2




IC202 SAA6588T-V2-118




IC651 BA6288FS-E2




IC102 RN5VD53AA-TL



IC305 TDA7406TR



IC62, 901 RRX9000-0601



**SECTION 5
EXPLODED VIEWS**


NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- -XX and -X mean standardized parts, so they may have some difference from the original one.

- Color Indication of Appearance Parts
Example :
 KNOB, BALANCE (WHITE) ... (RED)
 ↑ ↑
 Parts Color Cabinet's Color
- Accessories and packing materials and hardware (# mark) list are given in the last of this parts list.


The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

5-1. CHASSIS SECTION




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
* 1	3-230-511-01	COVER		* 4	1-681-373-11	SUB (CD) BOARD	
2	1-776-207-72	CORD (WITH CONNECTOR) (POWER) (US)		5	3-230-515-01	SLIDER (FLEXIBLE)	
2	1-776-527-71	CORD (WITH CONNECTOR) (ISO) (POWER)		6	3-230-514-01	COVER (FLEXIBLE)	
			(AEP,UK,E)	7	3-230-516-01	SPRING (FLEXIBLE), TENSION	
3	X-3380-551-1	PANEL (CD) SUB ASSY, SUB (M670:US)		8	3-045-756-01	SCREW (PANEL)	
3	X-3380-552-1	PANEL (CD) SUB ASSY, SUB (M620)		* 9	3-045-743-01	BRACKET (CD)	
3	X-3380-554-1	PANEL (CD) SUB ASSY, SUB (AEP,UK,E)		CN901	1-783-268-11	CABLE, FLAT 11P	

5-2. CAM SECTION




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	3-230-495-01	CAM (L)		* 60	1-681-375-11	SW BOARD	
52	X-3380-549-1	ARM (B-R) ASSY		* 61	X-3378-711-1	BRACKET (MOTOR) ASSY	
53	X-3380-544-1	BRACKET (L) ASSY		62	3-230-494-01	GEAR (C)	
54	X-3380-548-1	ARM (B-L) ASSY		63	3-230-496-01	CAM (R)	
55	X-3380-546-1	ARM (A-L) ASSY		64	X-3380-545-1	BRACKET (R) ASSY	
56	3-376-464-11	SCREW (+PTT 2.6X6), GROUND POINT		65	3-030-909-11	DAMPER, OIL	
57	3-045-714-01	GEAR (B)		66	X-3380-547-1	ARM (A-R) ASSY	
58	3-342-940-01	WASHER (M)		M601	X-3378-769-1	MOTOR ASSY (OPEN/CLOSE)	
59	3-045-713-01	GEAR (A)					

5-3. MAIN BOARD SECTION




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	X-3380-558-1	CHASSIS (CD) ASSY		* 109	3-230-513-01	HEAT SINK (REG)	
* 102	3-230-417-01	SHEET, INSULATING		* 110	3-230-509-01	CHASSIS, BACK	
103	3-230-493-01	GEAR (DRIVE SHAFT)		* 111	3-019-565-01	BRACKET (IC)	
104	3-230-444-01	GUIDE (DRIVE SHAFT)		* 112	3-230-510-21	HEAT SINK (US)	
105	3-045-721-01	SHAFT, DRIVE		* 112	3-230-510-31	HEAT SINK (AEP,UK,E)	
106	3-040-692-01	RING, CE TYPE RETAINING		113	1-777-246-41	CORD (WITH CONNECTOR) (ANT)	
107	3-376-464-11	SCREW (+PTT 2.6X6), GROUND POINT		114	1-790-375-21	CORD (WITH CONNECTOR) (SUB OUT (MONO))	
* 108	A-3283-172-A	MAIN BOARD, COMPLETE (M670:US)		115	1-757-775-11	CORD (WITH CONNECTOR) (AUX-IN (AUDIO))	
* 108	A-3283-173-A	MAIN BOARD, COMPLETE (M620)		F901	1-532-877-11	FUSE (BLADE TYPE) (AUTO FUSE) 10A	
* 108	A-3283-174-A	MAIN BOARD, COMPLETE (AEP,UK,E)		TUX201	A-3220-813-A	TUNER UNIT (TUX-020)	

5-4. FRONT PANEL (KEY) ASSY SECTION




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	X-3380-536-1	PANEL (KEY) SUB ASSY, FRONT (M670:US)		* 164	3-230-486-01	HOLDER (LCD-KEY)	
151	X-3380-537-1	PANEL (KEY) SUB ASSY, FRONT (M620)		165	1-694-808-21	CONDUCTIVE BOARD, CONNECTION	
151	X-3380-539-1	PANEL (KEY) SUB ASSY, FRONT (AEP,UK,E)		166	1-694-807-21	CONDUCTIVE BOARD, CONNECTION	
152	3-230-483-01	BUTTON (ENTER)		* 167	3-230-487-01	PLATE (LCD-KEY), LIGHT GUIDE	
153	3-230-482-01	BUTTON (EQ7)		* 168	3-230-488-01	SHEET (LCD-KEY), DIFFUSION	
154	3-230-480-01	BUTTON (EJECT)		* 169	3-230-415-01	SHEET (KEY), INSULATING	
155	3-230-481-01	BUTTON (SEEK)		170	X-3380-543-1	PANEL ASSY, BASE	
156	3-230-485-01	PLATE (RING), LIGHT GUIDE		171	X-3380-560-1	SPRING (DETOUCH L) ASSY	
157	3-230-477-01	BUTTON (+/-)		172	3-063-745-11	SCREW (+P M2 B TITE)	
158	3-230-478-01	BUTTON (SOURCE)		173	3-230-490-01	GUIDE (DETOUCH)	
159	3-230-484-01	BUTTON (CLOSE)		174	2-134-636-31	SCREW (M1.7X2.5)	
160	3-231-433-01	CUSHION (ELECTROSTATIC)		175	3-230-416-01	SCREW	
161	3-230-398-01	BUTTON (6 KEY) (US)		176	X-3380-561-1	SPRING (DETOUCH R) ASSY	
161	3-230-398-11	BUTTON (6 KEY) (AEP,UK,E)		177	1-681-390-11	FLEXIBLE BOARD	
162	3-230-479-01	BUTTON (MODE) (US)		178	3-230-491-01	GUIDE (FLEXIBLE)	
162	3-230-479-11	BUTTON (MODE) (AEP,UK,E)		LCD1	1-804-349-11	DISPLAY PANEL, LIQUID CRYSTAL	
* 163	A-3283-164-A	KEY BOARD, COMPLETE (US)					
* 163	A-3283-176-A	KEY BOARD, COMPLETE (AEP,UK,E)					

5-5. FRONT PANEL (DSPL) ASSY SECTION




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
201	3-230-470-01	PANEL (FRONT BACK)		* 209	3-230-466-01	HOLDER (LCD-DSPL)	
202	3-230-472-01	SPRING (LOCK), TENSION		210	3-230-426-01	BUTTON (OPEN)	
203	3-230-471-01	LOCK (DETOUCH)		211	3-230-422-01	PLATE (LOGO), LIGHT GUIDE	
204	3-230-378-01	SHEET, INSULATING		212	3-230-427-01	BUTTON (RESET-DSPL)	
* 205	3-230-469-01	SHEET (DSPL), REFLECTION		213	X-3380-903-1	PANEL SUB (DSPL) ASSY, FRONT	
* 206	3-230-467-01	PLATE (LCD-DSPL), LIGHT GUIDE		214	3-230-423-01	FILTER (IR-DSPL)	
207	1-694-806-21	CONDUCTIVE BOARD, CONNECTION		215	3-232-858-01	CUSHION (LIGHT GUIDE PLATE)	
* 208	3-230-468-01	SHEET (DSPL), DIFFUSION		LCD60	1-804-348-11	DISPLAY PANEL, LIQUID CRYSTAL	

5-6. CD MECHANISM SECTION (1)
(MG-383Z-121//K)




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
* 251	1-676-709-11	DISC IN SW BOARD		260	3-040-040-01	ARM (ROLLER)	
252	3-040-039-01	CHASSIS (T)		* 261	A-3294-809-A	SERVO BOARD, COMPLETE	
253	3-040-038-01	SPRING (LR), TENSION		262	3-221-779-01	BRACKET (MOTOR)	
254	3-040-050-01	LEVER (L)		263	3-040-034-01	SPRING (RA), TENSION	
255	3-040-022-01	RETAINER (ROLLER), SHAFT		264	3-040-042-01	WASHER	
256	3-040-044-01	ROLLER (S)		265	3-043-880-01	RING (RA), RETAINING	
257	3-040-067-01	LEVER (R)		266	3-044-206-11	SCREW, SPECIAL	
258	A-3301-980-A	SHAFT ROLLER ASSY		267	3-231-392-01	PLATE (CD), SHIELD	
259	3-040-037-01	GUIDE (DISC)		M903	A-3315-039-A	MOTOR SUB ASSY, LO (LOADING)	

5-7. CD MECHANISM SECTION (2)
(MG-383Z-121//K)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
301	3-040-025-01	ARM, CHUCKING		308	3-040-033-01	SPRING (KF1), TENSION	
302	3-040-031-01	DAMPER (T)		309	A-3307-422-A	CHASSIS (M) COMPLETE ASSY	
303	3-040-056-01	LEVER (D)		310	3-040-059-01	SPRING (TR), TENSION	
304	3-040-024-01	RETAINER (DISC)		311	3-040-057-01	LEVER (LOCK)	
305	3-040-054-01	WHEEL (LW), WORM		312	3-040-058-01	GEAR (MDL)	
306	3-040-026-01	SPRING (CH), TENSION		313	3-040-052-01	WHEEL (U), WORM	
307	3-040-032-01	SPRING (FL), COMPRESSION		314	3-040-051-01	LEVER (TR)	

5-8. CD MECHANISM SECTION (3)
(MG-383Z-121//K)



The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
351	X-3378-480-1	CHASSIS (OP) ASSY (including M901)		357	1-677-182-11	MOTOR FLEXIBLE BOARD	
352	3-040-029-01	SPRING (SL), TORSION		* 358	1-676-708-11	LIMIT SW BOARD	
353	3-040-045-01	BASE (DRIVING)		359	3-909-607-01	SCREW	
354	3-040-194-01	GEAR (MIDWAY)		\triangle 360	8-820-103-03	PICK-UP, OPTICAL KSS-720A/K1RP	
355	A-3301-983-A	SHAFT (FEED) ASSY		361	3-040-030-01	SPRING (FEED), PLATE	
356	1-676-707-11	PICK-UP FLEXIBLE BOARD		M902	A-3301-985-A	MOTOR ASSY, SLED (SLED)	

DISPLAY

**SECTION 6
ELECTRICAL PARTS LIST**

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL: Metal-film resistor.
METAL OXIDE: Metal oxide-film resistor.
F: nonflammable

- Items marked "***" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u : μ , for example:
uA.. : μ A.. uPA.. : μ PA..
uPB.. : μ PB.. uPC.. : μ PC.. uPD.. : μ PD..
- CAPACITORS
uF : μ F
- COILS
uH : μ H

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
		DISPLAY BOARD *****				< FERRITE BEAD >	
	1-694-806-21	CONDUCTIVE BOARD, CONNECTION		FB60	1-500-329-21	INDUCTOR, FERRITE BEAD	
	3-230-378-01	SHEET, INSULATING				< IC >	
*	3-230-466-01	HOLDER (LCD-DSPL)		IC60	8-759-653-26	IC LC75878W	
*	3-230-467-01	PLATE (LCD-DSPL), LIGHT GUIDE		IC61	8-759-653-26	IC LC75878W	
*	3-230-468-01	SHEET (DSPL), DIFFUSION		IC62	8-759-830-18	IC RRX9000-0601#1	
*	3-230-469-01	SHEET (DSPL), REFLECTION				< LIQUID CRYSTAL DISPLAY >	
		< CAPACITOR >		LCD60	1-804-348-11	DISPLAY PANEL, LIQUID CRYSTAL	
C60	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V			< DIODE >	
C61	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V				
C62	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V				
C63	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V	LED60	8-719-079-49	LED LWT673-R1S2-34 (SONY)	
C64	1-115-412-11	CERAMIC CHIP	680PF 5% 25V	LED62	8-719-076-58	LED NSSW440-BRS (LCD BACK LIGHT)	
C65	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V	LED63	8-719-076-58	LED NSSW440-BRS (LCD BACK LIGHT)	
C66	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V	LED64	8-719-076-58	LED NSSW440-BRS (LCD BACK LIGHT)	
C67	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V	LED65	8-719-076-58	LED NSSW440-BRS (LCD BACK LIGHT)	
C70	1-115-412-11	CERAMIC CHIP	680PF 5% 25V	LED66	8-719-076-58	LED NSSW440-BRS (LCD BACK LIGHT)	
C71	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V	LED67	8-719-076-58	LED NSSW440-BRS (LCD BACK LIGHT)	
C72	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V	LED68	8-719-076-58	LED NSSW440-BRS (LCD BACK LIGHT)	
C73	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V	LED69	8-719-076-58	LED NSSW440-BRS (LCD BACK LIGHT)	
C74	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V			< SWITCH >	
C75	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V	LSW60	1-771-883-11	SWITCH, TACTILE (WITH LED) (OPEN)	
C76	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V			< TRANSISTOR >	
C77	1-124-778-00	ELECT CHIP	22uF 20% 6.3V	Q60	8-729-106-60	TRANSISTOR 2SB1132-T101-QR	
C78	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	Q61	8-729-038-67	TRANSISTOR KRC102S	
C79	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V	Q62	8-729-904-66	TRANSISTOR DTD113EK-T-146	
C80	1-164-388-11	CERAMIC CHIP	270PF 5% 50V			< RESISTOR >	
C81	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V	R60	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
		< CONNECTOR >		R61	1-216-833-11	METAL CHIP 10K 5% 1/16W	
CN60	1-815-500-21	PLUG, CONNECTOR 15P		R62	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
		< DIODE >		R63	1-216-037-00	METAL CHIP 330 5% 1/10W	
D61	8-719-422-41	DIODE MA8051-L-TX		R64	1-216-037-00	METAL CHIP 330 5% 1/10W	
D62	8-719-977-12	DIODE KDZ6.8V		R65	1-216-025-11	RES-CHIP 100 5% 1/10W	
D63	8-719-977-12	DIODE KDZ6.8V		R66	1-216-025-11	RES-CHIP 100 5% 1/10W	
D64	8-719-977-12	DIODE KDZ6.8V		R67	1-216-025-11	RES-CHIP 100 5% 1/10W	
D65	8-719-977-12	DIODE KDZ6.8V		R68	1-216-025-11	RES-CHIP 100 5% 1/10W	
D66	8-719-977-12	DIODE KDZ6.8V		R69	1-216-033-00	METAL CHIP 220 5% 1/10W	
D67	8-719-420-14	DIODE MA8082-M(TX)		R70	1-216-864-11	SHORT 0	
D68	8-719-977-12	DIODE KDZ6.8V		R71	1-216-033-00	METAL CHIP 220 5% 1/10W	
D70	8-719-083-14	DIODE RRX9000-0501					

DISPLAY

DISC IN SW

KEY

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R72	1-216-811-11	METAL CHIP	150 5% 1/16W	C7	1-165-176-11	CERAMIC CHIP 0.047uF 10% 16V	
R73	1-216-805-11	METAL CHIP	47 5% 1/16W	C8	1-165-176-11	CERAMIC CHIP 0.047uF 10% 16V	
R74	1-216-864-11	SHORT	0	C9	1-164-156-11	CERAMIC CHIP 0.1uF 25V	
R76	1-216-841-11	METAL CHIP	47K 5% 1/16W	C10	1-162-974-11	CERAMIC CHIP 0.01uF 50V	
R77	1-216-825-11	METAL CHIP	2.2K 5% 1/16W			< CONNECTOR >	
R78	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	CN1	1-815-499-21	CONNECTOR, FPC (ZIF) 18P	
R79	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	CN2	1-815-501-11	SOCKET, CONNECTOR 15P	
R80	1-216-825-11	METAL CHIP	2.2K 5% 1/16W			< DIODE >	
R81	1-216-817-11	METAL CHIP	470 5% 1/16W	D7	8-719-422-41	DIODE MA8051-L-TX	
R82	1-216-809-11	METAL CHIP	100 5% 1/16W	D8	8-719-422-80	DIODE MA8075-H-TX	
R83	1-216-809-11	METAL CHIP	100 5% 1/16W			< IC >	
R84	1-216-809-11	METAL CHIP	100 5% 1/16W	IC1	8-759-653-26	IC LC75878W	
R85	1-216-841-11	METAL CHIP	47K 5% 1/16W			< LIQUID CRYSTAL DISPLAY >	
R86	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	LCD1	1-804-349-11	DISPLAY PANEL, LIQUID CRYSTAL	
R87	1-216-825-11	METAL CHIP	2.2K 5% 1/16W			< DIODE >	
R88	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	LED1	8-719-079-26	LED NSSB440-WRST-THR (LCD BACK LIGHT)	
R89	1-216-825-11	METAL CHIP	2.2K 5% 1/16W	LED2	8-719-079-26	LED NSSB440-WRST-THR (LCD BACK LIGHT)	
R90	1-216-809-11	METAL CHIP	100 5% 1/16W	LED3	8-719-078-39	LED CL-170SR-CD-T (RING ILLUMINATION)	
R91	1-216-809-11	METAL CHIP	100 5% 1/16W	LED4	8-719-078-39	LED CL-170SR-CD-T (RING ILLUMINATION)	
R92	1-216-809-11	METAL CHIP	100 5% 1/16W	LED5	8-719-078-39	LED CL-170SR-CD-T (RING ILLUMINATION)	
R93	1-216-817-11	METAL CHIP	470 5% 1/16W	LED6	8-719-078-39	LED CL-170SR-CD-T (RING ILLUMINATION)	
R94	1-216-864-11	SHORT	0	LED7	8-719-078-39	LED CL-170SR-CD-T (CLOSE)	
R95	1-216-846-11	METAL CHIP	120K 5% 1/16W	LED8	8-719-078-39	LED CL-170SR-CD-T (MODE)	
R96	1-216-850-11	METAL CHIP	270K 5% 1/16W	LED9	8-719-078-39	LED CL-170SR-CD-T (▲)	
R97	1-216-033-00	METAL CHIP	220 5% 1/10W	LED10	8-719-078-39	LED CL-170SR-CD-T (OFF)	
		< SWITCH >		LED11	8-719-078-39	LED CL-170SR-CD-T (DSPL/PTY)	
S60	1-771-884-11	SWITCH, TACTILE (WITH LED) (RESET)		LED12	8-719-078-39	LED CL-170SR-CD-T (SCRL)	
*****				LED13	8-719-078-39	LED CL-170SR-CD-T (ENTER)	
*	1-676-709-11	DISC IN SW BOARD		LED14	8-719-078-39	LED CL-170SR-CD-T (LIST)	
		*****		LED15	8-719-078-39	LED CL-170SR-CD-T (MENU)	
		< SWITCH >		LED16	8-719-078-39	LED CL-170SR-CD-T (SOUND)	
SW2	1-529-566-21	SWITCH, PUSH (1 KEY) (SELF)		LED17	8-719-078-09	LED SLR-332CD-T32MN (DSO)	
SW3	1-529-566-21	SWITCH, PUSH (1 KEY) (DISC IN)		LED18	8-719-078-09	LED SLR-332CD-T32MN (EQ7)	
*****						< SWITCH >	
*	A-3283-164-A	KEY BOARD, COMPLETE (US)		LSW1	1-771-883-11	SWITCH, TACTILE (WITH LED) (-)	
*	A-3283-176-A	KEY BOARD, COMPLETE (AEP,UK,E)		LSW2	1-771-476-11	SWITCH, KEYBOARD (WITH LED) (SOURCE)	
		*****		LSW5	1-771-883-11	SWITCH, TACTILE (WITH LED) (+)	
	1-694-807-21	CONDUCTIVE BOARD, CONNECTION		LSW6	1-771-476-11	SWITCH, KEYBOARD (WITH LED) (AF)	
*	1-694-808-21	CONDUCTIVE BOARD, CONNECTION				(AEP,UK,E)	
*	3-230-486-01	HOLDER (LCD-KEY)		LSW7	1-771-476-11	SWITCH, KEYBOARD (WITH LED) (1/REP)	
*	3-230-487-01	PLATE (LCD-KEY), LIGHT GUIDE		LSW8	1-771-476-11	SWITCH, KEYBOARD (WITH LED) (2/SHUF)	
*	3-230-488-01	SHEET (LCD-KEY), DIFFUSION		LSW9	1-771-476-11	SWITCH, KEYBOARD (WITH LED) (3)	
		< CAPACITOR >		LSW10	1-771-476-11	SWITCH, KEYBOARD (WITH LED) (6)	
C1	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V	LSW11	1-771-476-11	SWITCH, KEYBOARD (WITH LED) (5)	
C2	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V	LSW12	1-771-476-11	SWITCH, KEYBOARD (WITH LED) (4)	
C3	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V				
C4	1-107-826-11	CERAMIC CHIP	0.1uF 10% 16V	LSW13	1-771-883-11	SWITCH, TACTILE (WITH LED) (I◀◀◀)	
C5	1-115-412-11	CERAMIC CHIP	680PF 5% 25V				
C6	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V				

CDX-M620/M670

KEY	LIMIT SW
------------	-----------------

Ref. No.	Part No.	Description	Remark
LSW15	1-771-476-11	SWITCH, KEYBOARD (WITH LED) (TA) (AEP,UK,E)	
LSW18	1-771-883-11	SWITCH, TACTILE (WITH LED) (DISC -)	
LSW20	1-771-883-11	SWITCH, TACTILE (WITH LED) (DISC +)	
LSW22	1-771-883-11	SWITCH, TACTILE (WITH LED) (▶▶▶▶▶▶)	
< TRANSISTOR >			
Q1	8-729-106-60	TRANSISTOR 2SB1132-T101-QR	
Q2	8-729-038-67	TRANSISTOR KRC102S	
Q3	8-729-904-66	TRANSISTOR DTD113EK-T-146	
< RESISTOR >			
R1	1-216-837-11	METAL CHIP 22K 5%	1/16W
R2	1-216-835-11	METAL CHIP 15K 5%	1/16W
R3	1-216-833-11	METAL CHIP 10K 5%	1/16W
R4	1-216-831-11	METAL CHIP 6.8K 5%	1/16W
R5	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
R6	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
R7	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R8	1-216-823-11	METAL CHIP 1.5K 5%	1/16W
R9	1-216-823-11	METAL CHIP 1.5K 5%	1/16W
R10	1-216-821-11	METAL CHIP 1K 5%	1/16W
R11	1-216-819-11	METAL CHIP 680 5%	1/16W
R12	1-216-819-11	METAL CHIP 680 5%	1/16W
R13	1-216-819-11	METAL CHIP 680 5%	1/16W
R14	1-216-837-11	METAL CHIP 22K 5%	1/16W
R15	1-216-835-11	METAL CHIP 15K 5%	1/16W
R16	1-216-833-11	METAL CHIP 10K 5%	1/16W
R17	1-216-831-11	METAL CHIP 6.8K 5%	1/16W
R18	1-216-829-11	METAL CHIP 4.7K 5%	1/16W
R19	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
R20	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R21	1-216-823-11	METAL CHIP 1.5K 5%	1/16W
R22	1-216-823-11	METAL CHIP 1.5K 5%	1/16W
R23	1-216-821-11	METAL CHIP 1K 5%	1/16W
R24	1-216-819-11	METAL CHIP 680 5%	1/16W
R25	1-216-819-11	METAL CHIP 680 5%	1/16W
R26	1-216-819-11	METAL CHIP 680 5%	1/16W
R27	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
R28	1-216-833-11	METAL CHIP 10K 5%	1/16W
R29	1-216-827-11	METAL CHIP 3.3K 5%	1/16W
R30	1-216-815-11	METAL CHIP 330 5%	1/16W
R31	1-216-033-00	METAL CHIP 220 5%	1/10W
R32	1-216-025-11	RES-CHIP 100 5%	1/10W
R33	1-216-807-11	METAL CHIP 68 5%	1/16W
R34	1-216-035-00	METAL CHIP 270 5%	1/10W
R35	1-216-035-00	METAL CHIP 270 5%	1/10W
R36	1-216-817-11	METAL CHIP 470 5%	1/16W
R37	1-216-029-00	METAL CHIP 150 5%	1/10W
R38	1-216-809-11	METAL CHIP 100 5%	1/16W
R39	1-216-809-11	METAL CHIP 100 5%	1/16W
R40	1-216-809-11	METAL CHIP 100 5%	1/16W
R41	1-216-841-11	METAL CHIP 47K 5%	1/16W

Ref. No.	Part No.	Description	Remark
R42	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R43	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R44	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R45	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R46	1-216-025-11	RES-CHIP 100 5%	1/10W (US)
R47	1-216-029-00	METAL CHIP 150 5%	1/10W
R48	1-216-029-00	METAL CHIP 150 5%	1/10W
R49	1-216-029-00	METAL CHIP 150 5%	1/10W
R50	1-216-025-11	RES-CHIP 100 5%	1/10W (US)
R51	1-216-029-00	METAL CHIP 150 5%	1/10W
R52	1-216-029-00	METAL CHIP 150 5%	1/10W
R53	1-216-029-00	METAL CHIP 150 5%	1/10W
R54	1-216-029-00	METAL CHIP 150 5%	1/10W
R55	1-216-029-00	METAL CHIP 150 5%	1/10W
< SWITCH >			
S1	1-786-101-11	SWITCH, DETECTION (DETOUCH)	
S2	1-771-884-11	SWITCH, TACTILE (WITH LED) (CLOSE)	
S3	1-692-135-21	SWITCH, KEYBOARD (MODE)	
S4	1-771-884-11	SWITCH, TACTILE (WITH LED) (▲)	
S7	1-692-135-21	SWITCH, KEYBOARD (OFF)	
S8	1-692-135-21	SWITCH, KEYBOARD (SCRL)	
S9	1-692-135-21	SWITCH, KEYBOARD (DSPL/PTY)	
S10	1-692-135-21	SWITCH, KEYBOARD (ENTER)	
S11	1-692-135-21	SWITCH, KEYBOARD (LIST)	
S12	1-692-135-21	SWITCH, KEYBOARD (MENU)	
S13	1-692-135-21	SWITCH, KEYBOARD (SOUND)	
S14	1-771-884-11	SWITCH, TACTILE (WITH LED) (DSO)	
S15	1-771-884-11	SWITCH, TACTILE (WITH LED) (EQ7)	

*	1-676-708-11	LIMIT SW BOARD *****	
< CONNECTOR >			
CN13	1-770-347-21	CONNECTOR, FPC 6P	
< SWITCH >			
SW4	1-529-565-11	SWITCH, PUSH (1 KEY) (LIMIT)	

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-3283-172-A	MAIN BOARD, COMPLETE (M670:US)		C128	1-125-837-11	CERAMIC CHIP 1uF	10% 6.3V
*	A-3283-173-A	MAIN BOARD, COMPLETE (M620)		C201	1-162-918-11	CERAMIC CHIP 18PF	5% 50V
*	A-3283-174-A	MAIN BOARD, COMPLETE (AEP,UK,E)		C202	1-164-156-11	CERAMIC CHIP 0.1uF	25V
		*****		C205	1-164-156-11	CERAMIC CHIP 0.1uF	25V
				C206	1-164-156-11	CERAMIC CHIP 0.1uF	25V
*	3-019-565-01	BRACKET (IC)		C207	1-124-589-11	ELECT 47uF	20% 16V
*	3-230-509-01	CHASSIS, BACK		C208	1-164-156-11	CERAMIC CHIP 0.1uF	25V
*	3-230-510-21	HEAT SINK (US)		C209	1-104-942-11	ELECT 1uF	20% 50V
*	3-230-510-31	HEAT SINK (AEP,UK,E)		C210	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
*	3-230-513-01	HEAT SINK (REG)					(AEP,UK,E)
	7-685-792-09	SCREW +PTT 2.6X6 (S)		C211	1-164-360-11	CERAMIC CHIP 0.1uF	16V
	7-685-794-09	SCREW +PTT 2.6X10 (S)					(AEP,UK,E)
		< BUZZER >		C212	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
BZ501	1-504-920-11	BUZZER					(AEP,UK,E)
		< CAPACITOR >		C213	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
							(AEP,UK,E)
C51	1-162-919-11	CERAMIC CHIP 22PF	5% 50V	C214	1-162-915-11	CERAMIC CHIP 10PF	0.5PF 50V
			(M670:US)				(AEP,UK,E)
C52	1-162-919-11	CERAMIC CHIP 22PF	5% 50V	C215	1-125-891-11	CERAMIC CHIP 0.47uF	10% 10V
			(M670:US)	C216	1-104-664-11	ELECT 47uF	20% 10V
C53	1-162-919-11	CERAMIC CHIP 22PF	5% 50V				(AEP,UK,E)
			(M670:US)	C217	1-164-315-11	CERAMIC CHIP 470PF	5% 50V
C54	1-162-919-11	CERAMIC CHIP 22PF	5% 50V				(AEP,UK,E)
			(M670:US)	C218	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V
C55	1-162-919-11	CERAMIC CHIP 22PF	5% 50V				(AEP,UK,E)
			(M670:US)	C219	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V
							(AEP,UK,E)
C57	1-162-927-11	CERAMIC CHIP 100PF	5% 50V	C220	1-162-924-11	CERAMIC CHIP 56PF	5% 50V
C58	1-164-156-11	CERAMIC CHIP 0.1uF	25V				(AEP,UK,E)
C101	1-124-570-11	ELECT 220uF	20% 16V	C221	1-162-924-11	CERAMIC CHIP 56PF	5% 50V
C103	1-164-156-11	CERAMIC CHIP 0.1uF	25V				(AEP,UK,E)
C104	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V	C222	1-165-176-11	CERAMIC CHIP 0.047uF	10% 16V
							(AEP,UK,E)
C105	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V	C223	1-164-315-11	CERAMIC CHIP 470PF	5% 50V
C106	1-162-959-11	CERAMIC CHIP 330PF	5% 50V				(AEP,UK,E)
C107	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V	C224	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V
C108	1-162-959-11	CERAMIC CHIP 330PF	5% 50V				(AEP,UK,E)
C109	1-126-176-11	ELECT 220uF	20% 10V	C225	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V
							(AEP,UK,E)
C110	1-164-217-11	CERAMIC CHIP 150PF	5% 50V	C226	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V
C111	1-115-156-11	CERAMIC CHIP 1uF	10V				(AEP,UK,E)
C112	1-164-156-11	CERAMIC CHIP 0.1uF	25V	C227	1-162-966-11	CERAMIC CHIP 0.0022uF	10% 50V
C113	1-126-176-11	ELECT 220uF	20% 10V				(AEP,UK,E)
C115	1-162-964-11	CERAMIC CHIP 0.001uF	10% 50V	C228	1-162-959-11	CERAMIC CHIP 330PF	5% 50V
							(AEP,UK,E)
C116	1-126-176-11	ELECT 220uF	20% 10V	C229	1-125-838-11	CERAMIC CHIP 2.2uF	10% 6.3V
C117	1-126-176-11	ELECT 220uF	20% 10V				(AEP,UK,E)
C118	1-164-156-11	CERAMIC CHIP 0.1uF	25V	C230	1-164-739-11	CERAMIC CHIP 560PF	5% 50V
C119	1-162-923-11	CERAMIC CHIP 47PF	5% 50V				(AEP,UK,E)
C120	1-164-156-11	CERAMIC CHIP 0.1uF	25V	C231	1-124-233-11	ELECT 10uF	20% 16V
							(AEP,UK,E)
C121	1-128-057-11	ELECT 330uF	20% 6.3V	C301	1-162-927-11	CERAMIC CHIP 100PF	5% 50V
C122	1-110-654-11	DOUBLE LAYERS 0.047F	5.5V	C302	1-162-927-11	CERAMIC CHIP 100PF	5% 50V
C123	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V	C303	1-136-154-00	FILM 0.012uF	5% 50V
C124	1-162-970-11	CERAMIC CHIP 0.01uF	10% 25V	C304	1-136-154-00	FILM 0.012uF	5% 50V
C125	1-164-156-11	CERAMIC CHIP 0.1uF	25V	C305	1-124-233-11	ELECT 10uF	20% 16V
C126	1-124-937-11	ELECT 10uF	20% 16V				
C127	1-164-156-11	CERAMIC CHIP 0.1uF	25V				

CDX-M620/M670

MAIN

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C306	1-162-965-11	CERAMIC CHIP	0.0015uF 10% 50V	C348	1-125-891-11	CERAMIC CHIP	0.47uF 10% 10V
C307	1-162-965-11	CERAMIC CHIP	0.0015uF 10% 50V				(EXCEPT M670:US)
C308	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C348	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V
C309	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V				(M670:US)
C310	1-164-156-11	CERAMIC CHIP	0.1uF 25V (M670:US)	C349	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V
				C350	1-164-227-11	CERAMIC CHIP	0.022uF 10% 25V
				C351	1-164-156-11	CERAMIC CHIP	0.1uF 25V (M670:US)
C311	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V (M670:US)	C352	1-164-156-11	CERAMIC CHIP	0.1uF 25V (M670:US)
C312	1-164-156-11	CERAMIC CHIP	0.1uF 25V (M670:US)	C353	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V
C313	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C354	1-162-974-11	CERAMIC CHIP	0.01uF 50V (M670:US)
C314	1-164-156-11	CERAMIC CHIP	0.1uF 25V	C355	1-164-156-11	CERAMIC CHIP	0.1uF 25V (M670:US)
C315	1-164-156-11	CERAMIC CHIP	0.1uF 25V	C356	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V (M670:US)
C316	1-124-937-11	ELECT	10uF 20% 16V	C357	1-125-891-11	CERAMIC CHIP	0.47uF 10% 10V
C317	1-124-233-11	ELECT	10uF 20% 16V				(EXCEPT M670:US)
C318	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C357	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V (M670:US)
C319	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C358	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V
C320	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C359	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V
C321	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V (M670:US)	C360	1-126-382-11	ELECT	100uF 20% 16V
C322	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V (M670:US)	C361	1-124-233-11	ELECT	10uF 20% 16V
C323	1-162-927-11	CERAMIC CHIP	100PF 5% 50V				(EXCEPT M670:US)
C324	1-124-233-11	ELECT	10uF 20% 16V	C361	1-126-786-11	ELECT	47uF 20% 16V (M670:US)
C325	1-126-157-11	ELECT	10uF 20% 16V	C362	1-164-156-11	CERAMIC CHIP	0.1uF 25V (M670:US)
C328	1-124-233-11	ELECT	10uF 20% 16V	C363	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C329	1-164-156-11	CERAMIC CHIP	0.1uF 25V	C364	1-125-891-11	CERAMIC CHIP	0.47uF 10% 10V
C332	1-127-573-11	CERAMIC CHIP	1uF 10% 16V	C365	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V
C333	1-127-573-11	CERAMIC CHIP	1uF 10% 16V	C366	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
C334	1-124-234-00	ELECT	22uF 20% 16V (M670:US)	C371	1-104-942-11	ELECT	1uF 20% 50V
C335	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V	C372	1-126-157-11	ELECT	10uF 20% 16V (M670:US)
C336	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V (M670:US)	C373	1-125-837-11	CERAMIC CHIP	1uF 10% 6.3V
C337	1-125-891-11	CERAMIC CHIP	0.47uF 10% 10V (EXCEPT M670:US)	C374	1-126-786-11	ELECT	47uF 20% 16V
C337	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V (M670:US)	C375	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V
C338	1-127-573-11	CERAMIC CHIP	1uF 10% 16V	C376	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
C339	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V (M670:US)	C377	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
C340	1-124-234-00	ELECT	22uF 20% 16V (M670:US)	C378	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
C341	1-127-573-11	CERAMIC CHIP	1uF 10% 16V	C379	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
C342	1-124-234-00	ELECT	22uF 20% 16V (M670:US)	C380	1-162-927-11	CERAMIC CHIP	100PF 5% 50V
C343	1-164-156-11	CERAMIC CHIP	0.1uF 25V	C381	1-164-156-11	CERAMIC CHIP	0.1uF 25V
C344	1-125-891-11	CERAMIC CHIP	0.47uF 10% 10V (EXCEPT M670:US)	C382	1-126-176-11	ELECT	220uF 20% 10V
C344	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V (M670:US)	C383	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V
C345	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C384	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V
C346	1-127-715-11	CERAMIC CHIP	0.22uF 10% 16V (M670:US)	C385	1-162-919-11	CERAMIC CHIP	22PF 5% 50V
C347	1-124-465-00	ELECT	0.47uF 20% 50V	C386	1-162-919-11	CERAMIC CHIP	22PF 5% 50V
				C387	1-162-919-11	CERAMIC CHIP	22PF 5% 50V
				C388	1-162-919-11	CERAMIC CHIP	22PF 5% 50V
				C403	1-135-473-21	ELECT	3300uF 20% 16V
				C406	1-127-573-11	CERAMIC CHIP	1uF 10% 16V

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description	Remark
C407	1-126-572-11	ELECT	4.7uF	20%	35V			< CONNECTOR >	
C451	1-124-234-00	ELECT	22uF	20%	16V				
C452	1-124-234-00	ELECT	22uF	20%	16V				
C454	1-128-057-11	ELECT	330uF	20%	6.3V				
C455	1-124-234-00	ELECT	22uF	20%	16V				
C456	1-162-974-11	CERAMIC CHIP	0.01uF		50V				
C457	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C501	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V				
C501	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V				(AEP,UK,E)
C502	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V			< JACK >	(US)
C503	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C505	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C506	1-164-315-11	CERAMIC CHIP	470PF	5%	50V				
C507	1-164-230-11	CERAMIC CHIP	220PF	5%	50V			< DIODE >	
C508	1-164-160-11	CERAMIC CHIP	20PF	5%	50V				
C509	1-162-920-11	CERAMIC CHIP	27PF	5%	50V				
C510	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C511	1-125-838-11	CERAMIC CHIP	2.2uF	10%	6.3V				
C512	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C513	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C514	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C515	1-124-584-00	ELECT	100uF	20%	10V				
C516	1-162-920-11	CERAMIC CHIP	27PF	5%	50V				
C517	1-164-160-11	CERAMIC CHIP	20PF	5%	50V				
C602	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V				
C603	1-126-934-11	ELECT	220uF	20%	16V				
C650	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C651	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C652	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C653	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C655	1-124-589-11	ELECT	47uF	20%	16V				
C656	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C657	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C658	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C659	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C660	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V				
C701	1-124-589-11	ELECT	47uF	20%	16V				
C703	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C704	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C705	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C706	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
C707	1-162-974-11	CERAMIC CHIP	0.01uF		50V				
C708	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C709	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C710	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C711	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V				
C712	1-162-974-11	CERAMIC CHIP	0.01uF		50V				
C801	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C802	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V				
C813	1-115-156-11	CERAMIC CHIP	1uF		10V				
C814	1-164-156-11	CERAMIC CHIP	0.1uF		25V				
CN101	1-774-701-11	PIN, CONNECTOR 16P							
* CN201	1-506-984-11	PIN, CONNECTOR (PC BOARD) 2P							
* CN301	1-506-985-11	PIN, CONNECTOR (PC BOARD) 3P							
CN401	1-764-617-12	PIN, CONNECTOR (PC BOARD) 30P							
CN601	1-580-907-31	PLUG, CONNECTOR (BUS CONTROL IN)							
CN602	1-568-955-11	PIN, CONNECTOR 6P							
CN603	1-563-614-31	CONNECTOR, FLEXIBLE 11P							
CN604	1-815-499-21	CONNECTOR, FPC (ZIF) 18P							
CN302	1-774-700-11	JACK, PIN 6P (BUS AUDIO IN, AUDIO OUT REAR/FRONT)							
D101	8-719-055-30	DIODE D1FS4A-TA							
D102	8-719-055-30	DIODE D1FS4A-TA							
D104	8-719-801-78	DIODE 1SS184							
D105	8-719-060-81	DIODE MA735-TX							
D106	8-719-053-18	DIODE 1SR154-400TE-25							
D107	8-719-422-62	DIODE MA8062-L-TX							
D109	8-719-977-03	DIODE DTZ5.6B							
D202	8-719-988-61	DIODE 1SS355TE-17							
D203	8-719-422-41	DIODE MA8051-L-TX							
D204	8-719-800-76	DIODE MA153-TX (AEP,UK,E)							
D205	8-719-422-41	DIODE MA8051-L-TX (AEP,UK,E)							
D301	8-719-074-47	DIODE CRS02(TE85L)							
D302	8-719-074-47	DIODE CRS02(TE85L)							
D303	8-719-074-47	DIODE CRS02(TE85L)							
D304	8-719-074-47	DIODE CRS02(TE85L)							
D305	8-719-074-47	DIODE CRS02(TE85L)							
D306	8-719-074-47	DIODE CRS02(TE85L)							
D307	8-719-074-47	DIODE CRS02(TE85L)							
D308	8-719-074-47	DIODE CRS02(TE85L)							
D309	8-719-801-78	DIODE 1SS184							
D311	8-719-988-61	DIODE 1SS355TE-17							
D401	8-719-049-38	DIODE 1N5404TU							
D404	8-719-977-12	DIODE DTZ6.8B							
D405	8-719-053-18	DIODE 1SR154-400TE-25							
D406	8-719-053-18	DIODE 1SR154-400TE-25							
D407	8-719-988-61	DIODE 1SS355TE-17							
D501	8-719-988-61	DIODE 1SS355TE-17 (AEP,UK,E)							
D502	8-719-988-61	DIODE 1SS355TE-17							
D503	8-719-988-61	DIODE 1SS355TE-17							
D504	8-719-422-41	DIODE MA8051-L-TX							
D505	8-719-988-61	DIODE 1SS355TE-17							
D506	8-719-988-61	DIODE 1SS355TE-17							
D507	8-719-801-78	DIODE 1SS184							
D508	8-719-988-61	DIODE 1SS355TE-17							
D509	8-719-988-61	DIODE 1SS355TE-17							
D510	8-719-988-61	DIODE 1SS355TE-17							
D511	8-719-988-61	DIODE 1SS355TE-17							

CDX-M620/M670

MAIN

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
D602	8-719-017-95	DIODE MA8180-TX				< JACK >	
D603	8-719-422-64	DIODE MA8062-M					
D604	8-719-017-95	DIODE MA8180-TX		J651	1-566-822-41	JACK (REMOTE IN) (AEP,UK,E)	
D605	8-719-420-51	DIODE MA729				< COIL >	
D606	8-719-988-61	DIODE 1SS355TE-17					
D607	8-719-017-95	DIODE MA8180-TX		L101	1-419-506-11	INDUCTOR 150uH	
D608	8-719-988-61	DIODE 1SS355TE-17		L102	1-414-392-41	INDUCTOR 1uH	
D609	8-719-801-78	DIODE 1SS184		L103	1-419-506-11	INDUCTOR 150uH	
D610	8-719-977-12	DIODE KDZ6.8V (AEP,UK,E)		L104	1-414-394-41	INDUCTOR 2.2uH	
D611	8-719-977-12	DIODE KDZ6.8V (AEP,UK,E)		L105	1-414-394-41	INDUCTOR 2.2uH	
D612	8-719-988-61	DIODE 1SS355TE-17		L201	1-216-295-11	SHORT 0	
D650	8-719-081-98	DIODE MM3Z6V8T1		L401	1-419-476-31	COIL, CHOKE 250uH	
D651	8-719-801-78	DIODE 1SS184		L501	1-414-185-51	INDUCTOR 22uH	
D652	8-719-820-05	DIODE 1SS181		L701	1-414-856-51	INDUCTOR 10uH	
D801	8-719-977-12	DIODE DTZ6.8B				< TRANSISTOR >	
D802	8-719-078-81	DIODE DF5A6.8FU(TE85R)		Q101	8-729-038-68	TRANSISTOR KRC103S	
D803	8-719-988-61	DIODE 1SS355TE-17		Q102	8-729-038-55	TRANSISTOR KRA103S	
D804	8-719-423-32	DIODE MA8120-M		Q103	8-729-820-46	TRANSISTOR 2SB1202FAS	
D805	8-719-078-81	DIODE DF5A6.8FU(TE85R)		Q105	8-729-034-49	TRANSISTOR KRC104S	
D806	8-719-078-81	DIODE DF5A6.8FU(TE85R)		Q106	8-729-820-46	TRANSISTOR 2SB1202FAS	
D807	8-719-988-61	DIODE 1SS355TE-17		Q107	8-729-038-68	TRANSISTOR KRC103S	
		< FERRITE BEAD >		Q108	8-729-106-60	TRANSISTOR 2SB1115A-YQ	
FB706	1-414-760-21	FERRITE, EMI (SMD)		Q109	8-729-106-60	TRANSISTOR 2SB1115A-YQ	
FB707	1-414-760-21	FERRITE, EMI (SMD)		Q110	8-729-106-60	TRANSISTOR 2SB1115A-YQ	
		< IC >		Q111	8-729-038-68	TRANSISTOR KRC103S	
IC101	8-759-990-43	IC TL1451ACDB-E20		Q112	8-729-038-68	TRANSISTOR KRC103S	
IC102	8-759-836-78	IC RN5VD53AA-TL		Q113	8-729-040-17	TRANSISTOR 2SD2164-K	
IC201	8-759-909-71	IC BA4558F-T1 (AEP,UK,E)		Q114	8-729-106-60	TRANSISTOR 2SB1115A-YQ	
IC202	8-759-492-59	IC SAA6588T/V2-118 (AEP,UK,E)		Q115	8-729-038-67	TRANSISTOR KRC102S	
IC301	8-759-422-21	IC NJM4580V(TE2)		Q116	8-729-034-49	TRANSISTOR KRC104S	
IC302	8-759-422-21	IC NJM4580V(TE2)		Q117	8-729-038-67	TRANSISTOR KRC102S	
IC303	8-759-422-21	IC NJM4580V(TE2) (M670:US)		Q118	8-759-068-54	IC WS57C291B-RE20A	
IC304	8-759-422-21	IC NJM4580V(TE2) (M670:US)		Q119	8-729-019-00	TRANSISTOR 2SD2394-G	
IC305	8-759-827-13	IC TDA7406T		Q201	8-729-920-85	TRANSISTOR 2SD1664-QR	
IC306	8-759-363-28	IC TC7660SEOA713 (M670:US)		Q202	8-729-120-28	TRANSISTOR 2SC2412K-T-146-R (AEP,UK,E)	
IC307	8-759-422-21	IC NJM4580V(TE2) (M670:US)		Q203	8-729-038-67	TRANSISTOR KRC102S (AEP,UK,E)	
IC308	8-759-422-21	IC NJM4580V(TE2) (M670:US)		Q301	8-729-021-95	TRANSISTOR RN1441-A(TE85L) (M670:US)	
IC309	8-759-660-96	IC TDA7560 (M670:US)		Q301	8-729-920-21	TRANSISTOR DTC314TKH04 (AEP,UK,E)	
IC309	8-759-827-14	IC TA8268AH (EXCEPT M670:US)		Q302	8-729-021-95	TRANSISTOR RN1441-A(TE85L) (M670:US)	
IC310	8-759-422-21	IC NJM4580V(TE2)		Q302	8-729-920-21	TRANSISTOR DTC314TKH04 (AEP,UK,E)	
IC501	6-700-182-01	IC MB90574BPMT-G-321-BND (US)		Q303	8-729-021-95	TRANSISTOR RN1441-A(TE85L) (M670:US)	
IC501	6-700-183-01	IC MB90574BPMT-G-322-BND (AEP,UK,E)		Q303	8-729-920-21	TRANSISTOR DTC314TKH04 (AEP,UK,E)	
IC502	8-759-828-22	IC XC61CN4102MR		Q304	8-729-021-95	TRANSISTOR RN1441-A(TE85L) (M670:US)	
IC601	8-759-449-89	IC BA8270F-E2		Q304	8-729-920-21	TRANSISTOR DTC314TKH04 (AEP,UK,E)	
IC650	8-759-337-40	IC NJM2904V(TE2)		Q305	8-729-021-95	TRANSISTOR RN1441-A(TE85L) (M670:US)	
IC651	8-759-580-33	IC BA6288FS-E2		Q305	8-729-920-21	TRANSISTOR DTC314TKH04 (AEP,UK,E)	
IC652	8-759-668-14	IC PQ09DZ1U		Q306	8-729-120-28	TRANSISTOR 2SC2412K-T-146-R (M670:US)	
IC701	8-759-277-63	IC TC7W14FU(TE12R)		Q307	8-729-106-60	TRANSISTOR 2SB1132-T100-R (M670:US)	
IC702	6-700-210-01	IC HD6432355A36F		Q308	8-729-120-28	TRANSISTOR 2SC2412K-T-146-R (M670:US)	
IC801	8-759-830-17	IC RRX9000-0401R#01		Q309	8-729-144-85	FET 2SK1133	
				Q310	8-729-038-56	TRANSISTOR KRA104S	
				Q312	8-729-034-49	TRANSISTOR KRC104S	

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
Q401	8-729-049-13	TRANSISTOR	UPA1853GR-9JG-E1	R138	1-216-821-11	METAL CHIP	1K 5% 1/16W
Q402	8-729-038-68	TRANSISTOR	KRC103S	R139	1-216-864-11	SHORT	0
Q404	8-729-038-68	TRANSISTOR	KRC103S	R140	1-216-864-11	SHORT	0
Q405	8-729-120-28	TRANSISTOR	2SC1623-L5L6	R141	1-216-845-11	METAL CHIP	100K 5% 1/16W
Q406	8-729-120-28	TRANSISTOR	2SC1623-L5L6	R201	1-216-001-00	METAL CHIP	10 5% 1/10W
Q407	8-729-120-28	TRANSISTOR	2SC1623-L5L6	R202	1-216-864-11	SHORT	0
Q501	8-759-068-54	IC	WS57C291B-RE20A	R203	1-216-864-11	SHORT	0
Q502	8-729-038-67	TRANSISTOR	KRC102S	R204	1-216-817-11	METAL CHIP	470 5% 1/16W
Q602	8-729-038-67	TRANSISTOR	KRA104S	R205	1-216-833-11	METAL CHIP	10K 5% 1/16W
Q603	8-729-038-67	TRANSISTOR	KRC102S	R206	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (AEP,UK,E)
Q650	8-729-038-68	TRANSISTOR	KRC103S	R207	1-216-809-11	METAL CHIP	100 5% 1/16W (AEP,UK,E)
Q651	8-729-120-28	TRANSISTOR	2SC1623-L5L6	R208	1-216-845-11	METAL CHIP	100K 5% 1/16W (AEP,UK,E)
Q652	8-729-216-22	TRANSISTOR	2SA1162-G	R209	1-216-295-11	SHORT	0 (AEP,UK,E)
< RESISTOR >				R210	1-216-833-11	METAL CHIP	10K 5% 1/16W (AEP,UK,E)
R51	1-216-821-11	METAL CHIP	1K 5% 1/16W	R211	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (AEP,UK,E)
R101	1-216-809-11	METAL CHIP	100 5% 1/16W	R212	1-216-825-11	METAL CHIP	2.2K 5% 1/16W (AEP,UK,E)
R102	1-216-055-00	METAL CHIP	1.8K 5% 1/10W	R213	1-216-857-11	METAL CHIP	1M 5% 1/16W (AEP,UK,E)
R103	1-216-055-00	METAL CHIP	1.8K 5% 1/10W	R214	1-216-809-11	METAL CHIP	100 5% 1/16W (AEP,UK,E)
R104	1-216-055-00	METAL CHIP	1.8K 5% 1/10W	R215	1-216-853-11	METAL CHIP	470K 5% 1/16W (AEP,UK,E)
R105	1-216-809-11	METAL CHIP	100 5% 1/16W	R216	1-216-817-11	METAL CHIP	470 5% 1/16W (AEP,UK,E)
R106	1-216-829-11	METAL CHIP	4.7K 5% 1/16W	R217	1-216-797-11	METAL CHIP	10 5% 1/16W (AEP,UK,E)
R107	1-216-829-11	METAL CHIP	4.7K 5% 1/16W	R218	1-216-823-11	METAL CHIP	1.5K 5% 1/16W (AEP,UK,E)
R108	1-218-861-11	METAL CHIP	3.9K 0.5% 1/16W	R219	1-216-821-11	METAL CHIP	1K 5% 1/16W (AEP,UK,E)
R109	1-218-847-11	METAL CHIP	1K 0.5% 1/16W	R220	1-216-797-11	METAL CHIP	10 5% 1/16W (AEP,UK,E)
R110	1-218-873-11	METAL CHIP	12K 0.5% 1/16W	R221	1-216-864-11	SHORT	0
R111	1-216-841-11	METAL CHIP	47K 5% 1/16W	R222	1-216-864-11	SHORT	0
R112	1-216-841-11	METAL CHIP	47K 5% 1/16W	R301	1-216-821-11	METAL CHIP	1K 5% 1/16W
R113	1-216-841-11	METAL CHIP	47K 5% 1/16W	R302	1-216-833-11	METAL CHIP	10K 5% 1/16W
R114	1-216-841-11	METAL CHIP	47K 5% 1/16W	R303	1-216-864-11	SHORT	0 (EXCEPTM670:US)
R115	1-216-845-11	METAL CHIP	100K 5% 1/16W	R304	1-216-833-11	METAL CHIP	10K 5% 1/16W
R116	1-218-897-11	METAL CHIP	120K 0.5% 1/16W	R305	1-216-864-11	SHORT	0
R117	1-216-864-11	SHORT	0	R306	1-216-864-11	SHORT	0
R118	1-216-809-11	METAL CHIP	100 5% 1/16W	R307	1-216-833-11	METAL CHIP	10K 5% 1/16W
R119	1-216-055-00	METAL CHIP	1.8K 5% 1/10W	R308	1-216-833-11	METAL CHIP	10K 5% 1/16W
R120	1-216-055-00	METAL CHIP	1.8K 5% 1/10W	R309	1-216-833-11	METAL CHIP	10K 5% 1/16W
R121	1-216-055-00	METAL CHIP	1.8K 5% 1/10W	R310	1-216-833-11	METAL CHIP	10K 5% 1/16W
R122	1-216-809-11	METAL CHIP	100 5% 1/16W	R311	1-216-864-11	SHORT	0 (EXCEPTM670:US)
R123	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	R312	1-216-821-11	METAL CHIP	1K 5% 1/16W
R124	1-216-845-11	METAL CHIP	100K 5% 1/16W	R313	1-216-833-11	METAL CHIP	10K 5% 1/16W
R125	1-218-847-11	METAL CHIP	1K 0.5% 1/16W	R314	1-216-809-11	METAL CHIP	100 5% 1/16W (EXCEPT M670:US)
R126	1-218-866-11	METAL CHIP	6.2K 0.5% 1/16W				
R127	1-216-845-11	METAL CHIP	100K 5% 1/16W				
R128	1-216-057-00	METAL CHIP	2.2K 5% 1/10W				
R129	1-216-057-00	METAL CHIP	2.2K 5% 1/10W				
R130	1-216-845-11	METAL CHIP	100K 5% 1/16W				
R131	1-216-829-11	METAL CHIP	4.7K 5% 1/16W				
R132	1-216-833-11	METAL CHIP	10K 5% 1/16W				
R133	1-216-835-11	METAL CHIP	15K 5% 1/16W				
R134	1-216-821-11	METAL CHIP	1K 5% 1/16W				
R135	1-216-057-00	METAL CHIP	2.2K 5% 1/10W				
R136	1-216-057-00	METAL CHIP	2.2K 5% 1/10W				
R137	1-216-841-11	METAL CHIP	47K 5% 1/16W				

CDX-M620/M670

MAIN

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R314	1-216-813-11	METAL CHIP	220 5% 1/16W (M670:US)	R347	1-216-864-11	SHORT	0 (EXCEPT M670:US)
R316	1-216-833-11	METAL CHIP	10K 5% 1/16W	R348	1-216-864-11	SHORT	0 (EXCEPT M670:US)
R317	1-216-841-11	METAL CHIP	47K 5% 1/16W	R349	1-216-864-11	SHORT	0 (EXCEPT M670:US)
R318	1-216-845-11	METAL CHIP	100K 5% 1/16W (M670:US)	R350	1-216-833-11	METAL CHIP	10K 5% 1/16W (M670:US)
R319	1-216-837-11	METAL CHIP	22K 5% 1/16W (M670:US)	R351	1-216-833-11	METAL CHIP	10K 5% 1/16W (M670:US)
R320	1-216-845-11	METAL CHIP	100K 5% 1/16W (M670:US)	R352	1-216-835-11	METAL CHIP	15K 5% 1/16W (M670:US)
R321	1-216-841-11	METAL CHIP	47K 5% 1/16W (M670:US)	R353	1-216-822-11	METAL CHIP	1.2K 5% 1/16W (M670:US)
R322	1-216-837-11	METAL CHIP	22K 5% 1/16W (M670:US)	R354	1-216-821-11	METAL CHIP	1K 5% 1/16W (M670:US)
R323	1-216-841-11	METAL CHIP	47K 5% 1/16W (M670:US)	R355	1-216-835-11	METAL CHIP	15K 5% 1/16W (M670:US)
R324	1-216-841-11	METAL CHIP	47K 5% 1/16W	R356	1-216-813-11	METAL CHIP	220 5% 1/16W
R325	1-216-809-11	METAL CHIP	100 5% 1/16W (EXCEPT M670:US)	R357	1-216-813-11	METAL CHIP	220 5% 1/16W
R325	1-216-813-11	METAL CHIP	220 5% 1/16W (M670:US)	R358	1-216-813-11	METAL CHIP	220 5% 1/16W
R326	1-216-809-11	METAL CHIP	100 5% 1/16W (EXCEPT M670:US)	R359	1-216-817-11	METAL CHIP	470 5% 1/16W (M670:US)
R326	1-216-813-11	METAL CHIP	220 5% 1/16W (M670:US)	R360	1-216-831-11	METAL CHIP	6.8K 5% 1/16W
R327	1-216-841-11	METAL CHIP	47K 5% 1/16W	R361	1-216-813-11	METAL CHIP	220 5% 1/16W
R329	1-216-841-11	METAL CHIP	47K 5% 1/16W	R362	1-216-821-11	METAL CHIP	1K 5% 1/16W (M670:US)
R330	1-216-833-11	METAL CHIP	10K 5% 1/16W	R363	1-216-845-11	METAL CHIP	100K 5% 1/16W
R331	1-216-841-11	METAL CHIP	47K 5% 1/16W (M670:US)	R364	1-216-813-11	METAL CHIP	220 5% 1/16W
R332	1-216-841-11	METAL CHIP	47K 5% 1/16W (M670:US)	R365	1-216-833-11	METAL CHIP	10K 5% 1/16W (M670:US)
R333	1-216-845-11	METAL CHIP	100K 5% 1/16W (M670:US)	R366	1-216-821-11	METAL CHIP	1K 5% 1/16W (M670:US)
R334	1-216-837-11	METAL CHIP	22K 5% 1/16W (M670:US)	R367	1-216-821-11	METAL CHIP	1K 5% 1/16W (M670:US)
R335	1-216-833-11	METAL CHIP	10K 5% 1/16W	R368	1-216-835-11	METAL CHIP	15K 5% 1/16W (M670:US)
R336	1-216-845-11	METAL CHIP	100K 5% 1/16W (M670:US)	R369	1-216-835-11	METAL CHIP	15K 5% 1/16W (M670:US)
R337	1-216-837-11	METAL CHIP	22K 5% 1/16W (M670:US)	R370	1-216-833-11	METAL CHIP	10K 5% 1/16W (M670:US)
R338	1-216-809-11	METAL CHIP	100 5% 1/16W (EXCEPT M670:US)	R371	1-216-833-11	METAL CHIP	10K 5% 1/16W (M670:US)
R338	1-216-813-11	METAL CHIP	220 5% 1/16W (M670:US)	R372	1-216-864-11	SHORT	0
R339	1-216-833-11	METAL CHIP	10K 5% 1/16W	R373	1-216-864-11	SHORT	0
R340	1-216-833-11	METAL CHIP	10K 5% 1/16W	R374	1-216-841-11	METAL CHIP	47K 5% 1/16W
R341	1-216-809-11	METAL CHIP	100 5% 1/16W (EXCEPT M670:US)	R375	1-216-864-11	SHORT	0 (US)
R341	1-216-813-11	METAL CHIP	220 5% 1/16W (M670:US)	R376	1-216-841-11	METAL CHIP	47K 5% 1/16W
R342	1-216-841-11	METAL CHIP	47K 5% 1/16W	R377	1-216-864-11	SHORT	0
R343	1-216-864-11	SHORT	0 (EXCEPT M670:US)	R379	1-216-805-11	METAL CHIP	47 5% 1/16W
R344	1-216-864-11	SHORT	0 (EXCEPT M670:US)	R380	1-216-841-11	METAL CHIP	47K 5% 1/16W
R345	1-216-864-11	SHORT	0	R382	1-216-817-11	METAL CHIP	470 5% 1/16W
R346	1-216-864-11	SHORT	0 (EXCEPT M670:US)	R383	1-216-295-11	SHORT	0 (M670:US)
				R384	1-216-845-11	METAL CHIP	100K 5% 1/16W (M670:US)
				R385	1-216-845-11	METAL CHIP	100K 5% 1/16W (M670:US)
				R388	1-216-829-11	METAL CHIP	4.7K 5% 1/16W (M670:US)

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R389	1-216-829-11	METAL CHIP	4.7K 5% 1/16W (M670:US)	R512	1-216-815-11	METAL CHIP	330 5% 1/16W
R389	1-216-864-11	SHORT	0 (EXCEPT M670:US)	R513	1-216-821-11	METAL CHIP	1K 5% 1/16W
R390	1-216-841-11	METAL CHIP	47K 5% 1/16W	R514	1-216-841-11	METAL CHIP	47K 5% 1/16W
R391	1-216-821-11	METAL CHIP	1K 5% 1/16W	R515	1-216-821-11	METAL CHIP	1K 5% 1/16W
R393	1-216-821-11	METAL CHIP	1K 5% 1/16W	R516	1-216-864-11	SHORT	0
R395	1-216-821-11	METAL CHIP	1K 5% 1/16W	R517	1-216-821-11	METAL CHIP	1K 5% 1/16W
R397	1-216-821-11	METAL CHIP	1K 5% 1/16W	R518	1-216-829-11	METAL CHIP	4.7K 5% 1/16W
R399	1-216-845-11	METAL CHIP	100K 5% 1/16W (M670:US)	R519	1-216-813-11	METAL CHIP	220 5% 1/16W
R400	1-216-845-11	METAL CHIP	100K 5% 1/16W (M670:US)	R520	1-216-821-11	METAL CHIP	1K 5% 1/16W
R401	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	R521	1-216-864-11	SHORT	0
R402	1-216-821-11	METAL CHIP	1K 5% 1/16W	R522	1-216-864-11	SHORT	0
R403	1-216-073-00	METAL CHIP	10K 5% 1/10W	R523	1-216-864-11	SHORT	0
R404	1-216-073-00	METAL CHIP	10K 5% 1/10W	R524	1-216-864-11	SHORT	0
R405	1-216-833-11	METAL CHIP	10K 5% 1/16W	R526	1-216-845-11	METAL CHIP	100K 5% 1/16W
R406	1-216-833-11	METAL CHIP	10K 5% 1/16W	R527	1-216-831-11	METAL CHIP	6.8K 5% 1/16W
R409	1-216-073-00	METAL CHIP	10K 5% 1/10W	R528	1-216-845-11	METAL CHIP	100K 5% 1/16W
R410	1-216-073-00	METAL CHIP	10K 5% 1/10W	R529	1-216-845-11	METAL CHIP	100K 5% 1/16W (EXCEPT M670:US)
R411	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	R530	1-216-864-91	SHORT	0 (M670:US)
R412	1-216-841-11	METAL CHIP	47K 5% 1/16W (M670:US)	R535	1-216-845-11	METAL CHIP	100K 5% 1/16W
R413	1-216-841-11	METAL CHIP	47K 5% 1/16W	R536	1-216-845-11	METAL CHIP	100K 5% 1/16W
R414	1-216-841-11	METAL CHIP	47K 5% 1/16W	R537	1-216-845-11	METAL CHIP	100K 5% 1/16W
R415	1-216-829-11	METAL CHIP	4.7K 5% 1/16W	R538	1-216-845-11	METAL CHIP	100K 5% 1/16W
R416	1-216-829-11	METAL CHIP	4.7K 5% 1/16W	R539	1-216-845-11	METAL CHIP	100K 5% 1/16W
R417	1-216-829-11	METAL CHIP	4.7K 5% 1/16W	R540	1-216-845-11	METAL CHIP	100K 5% 1/16W
R418	1-216-833-11	METAL CHIP	10K 5% 1/16W	R541	1-216-845-11	METAL CHIP	100K 5% 1/16W
R419	1-216-833-11	METAL CHIP	10K 5% 1/16W	R542	1-216-845-11	METAL CHIP	100K 5% 1/16W
R420	1-216-841-11	METAL CHIP	47K 5% 1/16W	R543	1-216-845-11	METAL CHIP	100K 5% 1/16W
R421	1-216-837-11	METAL CHIP	22K 5% 1/16W	R544	1-216-853-11	METAL CHIP	470K 5% 1/16W
R422	1-216-845-11	METAL CHIP	100K 5% 1/16W	R545	1-216-845-11	METAL CHIP	100K 5% 1/16W
R423	1-216-833-11	METAL CHIP	10K 5% 1/16W	R546	1-216-845-11	METAL CHIP	100K 5% 1/16W
R424	1-216-833-11	METAL CHIP	10K 5% 1/16W	R547	1-216-821-11	METAL CHIP	1K 5% 1/16W
R425	1-216-829-11	METAL CHIP	4.7K 5% 1/16W	R548	1-216-864-11	SHORT	0
R451	1-216-295-11	SHORT	0	R549	1-216-845-11	METAL CHIP	100K 5% 1/16W
R452	1-216-017-11	RES-CHIP	47 5% 1/10W	R550	1-216-821-11	METAL CHIP	1K 5% 1/16W
R453	1-216-295-11	SHORT	0	R551	1-216-821-11	METAL CHIP	1K 5% 1/16W
R455	1-216-001-00	METAL CHIP	10 5% 1/10W	R552	1-216-821-11	METAL CHIP	1K 5% 1/16W
R456	1-216-295-11	SHORT	0	R553	1-216-817-11	METAL CHIP	470 5% 1/16W
R457	1-216-864-11	SHORT	0	R601	1-216-841-11	METAL CHIP	47K 5% 1/16W
R500	1-216-864-11	SHORT	0 (AEP,UK,E)	R602	1-216-809-11	METAL CHIP	100 5% 1/16W
R501	1-216-837-11	METAL CHIP	22K 5% 1/16W	R603	1-216-809-11	METAL CHIP	100 5% 1/16W
R502	1-216-821-11	METAL CHIP	1K 5% 1/16W	R604	1-216-835-11	METAL CHIP	15K 5% 1/16W
R503	1-216-864-11	SHORT	0	R605	1-216-821-11	METAL CHIP	1K 5% 1/16W
R504	1-216-833-11	METAL CHIP	10K 5% 1/16W	R606	1-216-809-11	METAL CHIP	100 5% 1/16W (AEP,UK,E)
R505	1-216-845-11	METAL CHIP	100K 5% 1/16W	R607	1-216-809-11	METAL CHIP	100 5% 1/16W (AEP,UK,E)
R506	1-216-833-11	METAL CHIP	10K 5% 1/16W	R608	1-218-716-11	METAL CHIP	10K 0.5% 1/16W
R507	1-216-833-11	METAL CHIP	10K 5% 1/16W	R650	1-216-833-11	METAL CHIP	10K 5% 1/16W
R508	1-216-845-11	METAL CHIP	100K 5% 1/16W	R651	1-216-836-11	METAL CHIP	18K 5% 1/16W
R509	1-216-821-11	METAL CHIP	1K 5% 1/16W	R652	1-216-821-11	METAL CHIP	1K 5% 1/16W
R510	1-216-821-11	METAL CHIP	1K 5% 1/16W	R653	1-216-845-11	METAL CHIP	100K 5% 1/16W
R511	1-216-864-11	SHORT	0	R654	1-216-829-11	METAL CHIP	4.7K 5% 1/16W

CDX-M620/M670

MAIN **SERVO**

Ref. No.	Part No.	Description		Remark
R655	1-216-837-11	METAL CHIP	22K	5% 1/16W
R656	1-216-304-11	METAL CHIP	3.3	5% 1/10W
R657	1-216-839-11	METAL CHIP	33K	5% 1/16W
R658	1-216-304-11	METAL CHIP	3.3	5% 1/10W
R659	1-216-304-11	METAL CHIP	3.3	5% 1/10W
R660	1-216-809-11	METAL CHIP	100	5% 1/16W
R661	1-216-809-11	METAL CHIP	100	5% 1/16W
R662	1-216-304-11	METAL CHIP	3.3	5% 1/10W
R701	1-216-821-11	METAL CHIP	1K	5% 1/16W
R702	1-216-821-11	METAL CHIP	1K	5% 1/16W
R703	1-216-821-11	METAL CHIP	1K	5% 1/16W
R704	1-216-821-11	METAL CHIP	1K	5% 1/16W
R705	1-216-821-11	METAL CHIP	1K	5% 1/16W
R708	1-216-821-11	METAL CHIP	1K	5% 1/16W
R709	1-216-864-11	SHORT	0	
R711	1-216-864-11	SHORT	0	
R712	1-216-845-11	METAL CHIP	100K	5% 1/16W
R713	1-216-864-11	SHORT	0	
R714	1-216-821-11	METAL CHIP	1K	5% 1/16W
R715	1-216-864-11	SHORT	0	
R716	1-216-821-11	METAL CHIP	1K	5% 1/16W
R717	1-216-845-11	METAL CHIP	100K	5% 1/16W
R718	1-216-845-11	METAL CHIP	100K	5% 1/16W
R719	1-216-845-11	METAL CHIP	100K	5% 1/16W
R722	1-216-845-11	METAL CHIP	100K	5% 1/16W
R723	1-216-845-11	METAL CHIP	100K	5% 1/16W
R724	1-216-845-11	METAL CHIP	100K	5% 1/16W
R725	1-216-845-11	METAL CHIP	100K	5% 1/16W
R726	1-216-833-11	METAL CHIP	10K	5% 1/16W
R727	1-216-845-11	METAL CHIP	100K	5% 1/16W
R801	1-216-821-11	METAL CHIP	1K	5% 1/16W
R802	1-216-821-11	METAL CHIP	1K	5% 1/16W
R803	1-218-716-11	METAL CHIP	10K	0.5% 1/16W
R804	1-218-716-11	METAL CHIP	10K	0.5% 1/16W
R805	1-216-845-11	METAL CHIP	100K	5% 1/16W
R806	1-216-821-11	METAL CHIP	1K	5% 1/16W
R807	1-216-809-11	METAL CHIP	100	5% 1/16W
R808	1-216-809-11	METAL CHIP	100	5% 1/16W
R809	1-216-821-11	METAL CHIP	1K	5% 1/16W
R810	1-216-821-11	METAL CHIP	1K	5% 1/16W
R811	1-216-821-11	METAL CHIP	1K	5% 1/16W
R812	1-216-821-11	METAL CHIP	1K	5% 1/16W
R813	1-216-821-11	METAL CHIP	1K	5% 1/16W
R814	1-216-817-11	METAL CHIP	470	5% 1/16W
R815	1-216-845-11	METAL CHIP	100K	5% 1/16W
R816	1-216-813-11	METAL CHIP	220	5% 1/16W
R817	1-216-821-11	METAL CHIP	1K	5% 1/16W
R818	1-216-841-11	METAL CHIP	47K	5% 1/16W
R819	1-216-845-11	METAL CHIP	100K	5% 1/16W
R820	1-216-845-11	METAL CHIP	100K	5% 1/16W
R821	1-216-845-11	METAL CHIP	100K	5% 1/16W
R822	1-216-845-11	METAL CHIP	100K	5% 1/16W
R823	1-216-821-11	METAL CHIP	1K	5% 1/16W

Ref. No.	Part No.	Description		Remark
R824	1-216-817-11	METAL CHIP	470	5% 1/16W
R825	1-216-857-11	METAL CHIP	1M	5% 1/16W
R827	1-216-845-11	METAL CHIP	100K	5% 1/16W
R828	1-216-821-11	METAL CHIP	1K	5% 1/16W
R830	1-216-845-11	METAL CHIP	100K	5% 1/16W
< THERMISTOR (POSITIVE) >				
TH101	1-810-940-11	THERMISTOR, POSITIVE		
TH102	1-810-940-11	THERMISTOR, POSITIVE		
TH601	1-801-792-21	THERMISTOR, POSITIVE		
< TUNER >				
TUX201	A-3220-813-A	TUNER UNIT (TUX-020)		
< VIBRATOR >				
X201	1-579-900-21	VIBRATOR, CRYSTAL (4.332MHz) (AEP,UK,E)		
X501	1-567-098-41	VIBRATOR, CRYSTAL (32.768kHz)		
X503	1-767-993-31	VIBRATOR, CRYSTAL (3.68MHz)		
X701	1-781-822-21	VIBRATOR, CERAMIC (18.432MHz)		
X801	1-781-282-11	VIBRATOR, CERAMIC (4MHz)		

*	A-3294-809-A	SERVO BOARD, COMPLETE		

< CAPACITOR >				
C101	1-115-156-11	CERAMIC CHIP	1uF	10V
C103	1-104-609-11	ELECT CHIP	100uF	20% 4V
C104	1-115-156-11	CERAMIC CHIP	1uF	10V
C106	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C107	1-115-156-11	CERAMIC CHIP	1uF	10V
C108	1-162-974-11	CERAMIC CHIP	0.01uF	50V
C109	1-162-917-11	CERAMIC CHIP	15PF	5% 50V
C115	1-164-733-11	CERAMIC CHIP	820PF	10% 50V
C116	1-165-128-11	CERAMIC CHIP	0.22uF	16V
C117	1-164-733-11	CERAMIC CHIP	820PF	10% 50V
C118	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C127	1-104-851-11	ELECT CHIP	10uF	10% 10V
C301	1-126-393-11	ELECT CHIP	33uF	20% 10V
C302	1-164-360-11	CERAMIC CHIP	0.1uF	16V
C303	1-163-037-11	CERAMIC CHIP	0.022uF	10% 25V
C304	1-163-037-11	CERAMIC CHIP	0.022uF	10% 25V
C305	1-162-965-11	CERAMIC CHIP	0.0015uF	10% 50V
C306	1-162-965-11	CERAMIC CHIP	0.0015uF	10% 50V
C307	1-162-962-11	CERAMIC CHIP	470PF	10% 50V
C308	1-162-962-11	CERAMIC CHIP	470PF	10% 50V
C309	1-164-227-11	CERAMIC CHIP	0.022uF	10% 25V
C310	1-125-838-11	CERAMIC CHIP	2.2uF	10% 6.3V
C311	1-164-677-11	CERAMIC CHIP	0.033uF	10% 16V
C502	1-162-965-11	CERAMIC CHIP	0.0015uF	10% 50V
C504	1-162-967-11	CERAMIC CHIP	0.0033uF	10% 50V
C505	1-165-176-11	CERAMIC CHIP	0.047uF	10% 16V
C506	1-107-823-11	CERAMIC CHIP	0.47uF	10% 16V
C507	1-107-826-11	CERAMIC CHIP	0.1uF	10% 16V

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C508	1-164-230-11	CERAMIC CHIP 220PF	5% 50V	R111	1-216-842-11	METAL CHIP 56K	5% 1/16W
C509	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R113	1-216-839-11	METAL CHIP 33K	5% 1/16W
C510	1-164-217-11	CERAMIC CHIP 150PF	5% 50V	R122	1-216-845-11	METAL CHIP 100K	5% 1/16W
C511	1-164-217-11	CERAMIC CHIP 150PF	5% 50V	R123	1-216-839-11	METAL CHIP 33K	5% 1/16W
C512	1-162-963-11	CERAMIC CHIP 680PF	10% 50V	R127	1-216-821-11	METAL CHIP 1K	5% 1/16W
C513	1-162-963-11	CERAMIC CHIP 680PF	10% 50V	R213	1-216-821-11	METAL CHIP 1K	5% 1/16W
C515	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R301	1-216-839-11	METAL CHIP 33K	5% 1/16W
C516	1-162-974-11	CERAMIC CHIP 0.01uF	50V	R302	1-216-839-11	METAL CHIP 33K	5% 1/16W
C517	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R303	1-216-821-11	METAL CHIP 1K	5% 1/16W
C518	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R304	1-216-839-11	METAL CHIP 33K	5% 1/16W
C519	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R306	1-216-833-11	METAL CHIP 10K	5% 1/16W
C520	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R307	1-216-833-11	METAL CHIP 10K	5% 1/16W
C521	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R308	1-216-833-11	METAL CHIP 10K	5% 1/16W
C522	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R309	1-216-833-11	METAL CHIP 10K	5% 1/16W
C550	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R310	1-216-833-11	METAL CHIP 10K	5% 1/16W
C553	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R311	1-216-833-11	METAL CHIP 10K	5% 1/16W
C554	1-164-360-11	CERAMIC CHIP 0.1uF	16V	R312	1-216-845-11	METAL CHIP 100K	5% 1/16W
< CONNECTOR >				R313	1-216-842-11	METAL CHIP 56K	5% 1/16W
CN1	1-764-616-12	HOUSING, CONNECTOR (PC BOARD) 30P		R314	1-216-842-11	METAL CHIP 56K	5% 1/16W
CN2	1-794-153-21	CONNECTOR, FPC (ZIF) 16P		R315	1-216-842-11	METAL CHIP 56K	5% 1/16W
CN3	1-770-347-21	CONNECTOR, FPC 6P		R316	1-216-842-11	METAL CHIP 56K	5% 1/16W
< FERRITE BEAD >				R317	1-216-838-11	METAL CHIP 27K	5% 1/16W
FB101	1-469-710-21	INDUCTOR, FERRITE BEAD		R318	1-216-840-11	METAL CHIP 39K	5% 1/16W
FB102	1-469-710-21	INDUCTOR, FERRITE BEAD		R319	1-216-840-11	METAL CHIP 39K	5% 1/16W
FB503	1-469-730-11	INDUCTOR, FERRITE BEAD		R320	1-216-833-11	METAL CHIP 10K	5% 1/16W
< IC >				R321	1-216-846-11	METAL CHIP 120K	5% 1/16W
IC1	8-752-095-36	IC CXA2596M-T6		R322	1-216-835-11	METAL CHIP 15K	5% 1/16W
IC5	8-752-920-24	IC CXP84640-081Q		R501	1-216-833-11	METAL CHIP 10K	5% 1/16W
IC7	8-759-832-99	IC LA6576L-TE-L		R503	1-216-845-11	METAL CHIP 100K	5% 1/16W
IC501	8-752-392-04	IC CXD2598Q		R504	1-216-857-11	METAL CHIP 1M	5% 1/16W
< JUMPER RESISTOR >				R505	1-216-839-11	METAL CHIP 33K	5% 1/16W
JR501	1-216-864-11	SHORT 0		R506	1-216-845-11	METAL CHIP 100K	5% 1/16W
JR505	1-216-864-11	SHORT 0		R507	1-216-827-11	METAL CHIP 3.3K	5% 1/16W
JR506	1-216-864-11	SHORT 0		R511	1-216-845-11	METAL CHIP 100K	5% 1/16W
< TRANSISTOR >				R513	1-216-827-11	METAL CHIP 3.3K	5% 1/16W
Q101	8-729-904-87	TRANSISTOR 2SB1197K-T-146-R		R516	1-216-845-11	METAL CHIP 100K	5% 1/16W
< RESISTOR >				R517	1-216-837-11	METAL CHIP 22K	5% 1/16W
R101	1-216-847-11	METAL CHIP 150K	5% 1/16W	R518	1-216-834-11	METAL CHIP 12K	5% 1/16W
R102	1-216-847-11	METAL CHIP 150K	5% 1/16W	R519	1-216-834-11	METAL CHIP 12K	5% 1/16W
R103	1-216-801-11	METAL CHIP 22	5% 1/16W	R520	1-216-834-11	METAL CHIP 12K	5% 1/16W
R104	1-216-857-11	METAL CHIP 1M	5% 1/16W	R521	1-216-834-11	METAL CHIP 12K	5% 1/16W
R105	1-216-833-11	METAL CHIP 10K	5% 1/16W	R522	1-216-834-11	METAL CHIP 12K	5% 1/16W
R106	1-216-857-11	METAL CHIP 1M	5% 1/16W	R523	1-216-834-11	METAL CHIP 12K	5% 1/16W
R107	1-216-835-11	METAL CHIP 15K	5% 1/16W	R524	1-216-845-11	METAL CHIP 100K	5% 1/16W
R108	1-216-838-11	METAL CHIP 27K	5% 1/16W	R526	1-216-845-11	METAL CHIP 100K	5% 1/16W
R109	1-216-801-11	METAL CHIP 22	5% 1/16W	R527	1-216-845-11	METAL CHIP 100K	5% 1/16W
R110	1-216-843-11	METAL CHIP 68K	5% 1/16W	R531	1-216-809-11	METAL CHIP 100	5% 1/16W
				R532	1-216-845-11	METAL CHIP 100K	5% 1/16W
				R533	1-216-845-11	METAL CHIP 100K	5% 1/16W
				R535	1-216-845-11	METAL CHIP 100K	5% 1/16W
				R551	1-216-841-11	METAL CHIP 47K	5% 1/16W
				R552	1-216-841-11	METAL CHIP 47K	5% 1/16W
				R553	1-216-845-11	METAL CHIP 100K	5% 1/16W

CDX-M620/M670

SERVO **SUB (CD)** **SW**

Ref. No.	Part No.	Description	Remark
R554	1-216-845-11	METAL CHIP 100K 5%	1/16W
R555	1-216-845-11	METAL CHIP 100K 5%	1/16W
R558	1-216-864-11	SHORT 0	
R560	1-216-809-11	METAL CHIP 100 5%	1/16W
R563	1-216-809-11	METAL CHIP 100 5%	1/16W
R564	1-216-845-11	METAL CHIP 100K 5%	1/16W
R568	1-216-837-11	METAL CHIP 22K 5%	1/16W
R569	1-216-809-11	METAL CHIP 100 5%	1/16W
R570	1-216-821-11	METAL CHIP 1K 5%	1/16W
R572	1-216-809-11	METAL CHIP 100 5%	1/16W
R590	1-216-845-11	METAL CHIP 100K 5%	1/16W
R594	1-216-845-11	METAL CHIP 100K 5%	1/16W
R595	1-216-845-11	METAL CHIP 100K 5%	1/16W
R599	1-216-821-11	METAL CHIP 1K 5%	1/16W
< SWITCH >			
SW1	1-762-944-12	SWITCH, DETECTION (SMALL TYPE) (DOWN)	
< VIBRATOR >			
X1	1-781-758-21	VIBRATOR, CERAMIC (CHIP TYPE) (10MHz)	
X2	1-781-759-21	VIBRATOR, CERAMIC (CHIP TYPE) (16MHz)	

*	1-681-373-11	SUB (CD) BOARD	

< CAPACITOR >			
C903	1-164-156-11	CERAMIC CHIP 0.1uF	25V
C904	1-164-156-11	CERAMIC CHIP 0.1uF	25V
C905	1-124-778-00	ELECT CHIP 22uF 20%	6.3V
C906	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V
C907	1-125-837-11	CERAMIC CHIP 1uF 10%	6.3V
C908	1-164-388-11	CERAMIC CHIP 270PF 5%	50V
< FLAT CABLE >			
CN901	1-783-268-11	CABLE, FLAT 11P	
< DIODE >			
D901	8-719-988-61	DIODE 1SS355TE-17	
D902	8-719-017-95	DIODE KDZ18V	
D903	8-719-079-10	LED CL-220UB-X-TS (DISC IN)	
D906	8-719-422-41	DIODE MA8051-L-TX	
D907	8-719-977-12	DIODE MA8068-M-TX	
D908	8-719-083-14	DIODE RRX9000-0501	
< FERRITE BEAD >			
FB903	1-500-329-21	INDUCTOR, FERRITE BEAD	
< IC >			
IC901	8-759-830-18	IC RRX9000-0601#1	

Ref. No.	Part No.	Description	Remark
< TRANSISTOR >			
Q901	8-729-216-22	TRANSISTOR 2SA1037K-T-146-S	
Q902	8-729-038-67	TRANSISTOR KRC102S	
< RESISTOR >			
R901	1-216-833-11	METAL CHIP 10K 5%	1/16W
R902	1-216-845-11	METAL CHIP 100K 5%	1/16W
R903	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R904	1-216-035-00	METAL CHIP 270 5%	1/10W
R906	1-216-811-11	METAL CHIP 150 5%	1/16W
R907	1-216-864-11	SHORT 0	
R908	1-216-850-11	METAL CHIP 270K 5%	1/16W
R909	1-216-846-11	METAL CHIP 120K 5%	1/16W
< SWITCH >			
SW901	1-692-135-21	SWITCH, KEYBOARD (RESET)	

*	1-681-375-11	SW BOARD	

< SWITCH >			
SW1001	1-771-937-21	SWITCH, DETECTION (OPEN/CLOSE)	
SW1002	1-529-566-31	SWITCH, PUSH (1 KEY) (CENTER)	

MISCELLANEOUS			

2	1-776-207-72	CORD (WITH CONNECTOR) (POWER) (US)	
2	1-776-527-71	CORD (WITH CONNECTOR) (ISO) (POWER)	(AEP,UK,E)
113	1-777-246-41	CORD (WITH CONNECTOR) (ANT)	
114	1-790-375-21	CORD (WITH CONNECTOR) (SUB OUT (MONO))	
115	1-757-775-11	CORD (WITH CONNECTOR) (AUX-IN (AUDIO))	
177	1-681-390-11	FLEXIBLE BOARD	
351	X-3378-480-1	CHASSIS (OP) ASSY (including M901)	
356	1-676-707-11	PICK-UP FLEXIBLE BOARD	
357	1-677-182-11	MOTOR FLEXIBLE BOARD	
△360	8-820-103-03	PICK-UP, OPTICAL KSS-720A/K1RP	
F901	1-532-877-11	FUSE (BLADE TYPE) (AUTO FUSE) 10A	
M601	X-3378-769-1	MOTOR ASSY (OPEN/CLOSE)	
M902	A-3301-985-A	MOTOR ASSY, SLED (SLED)	
M903	A-3315-039-A	MOTOR SUB ASSY, LO (LOADING)	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Ref. No.	Part No.	Description	Remark
ACCESSORIES & PACKING MATERIALS			

	1-476-546-11	REMOTE COMMANDER (RM-X111) (AEP,UK,E)	
	1-476-546-21	REMOTE COMMANDER (RM-X110) (US)	
	3-230-446-11	MANUAL, INSTRUCTION (ENGLISH,FRENCH, SPANISH) (US)	
	3-230-447-11	MANUAL, INSTRUCTION, INSTALL (ENGLISH, FRENCH,SPANISH) (US)	
	3-230-448-11	MANUAL, INSTRUCTION (ENGLISH,SPANISH, SWEDISH,PORTUGUESE,GREEK, RUSSIAN) (AEP,UK,E)	
	3-230-449-11	MANUAL, INSTRUCTION, INSTALL (ENGLISH, GERMAN,FRENCH,ITALIAN, DUTCH) (AEP,UK,E)	
	3-230-549-01	LID, BATTERY CASE (for RM-X110/X111)	
	X-3378-390-1	CASE ASSY (for FRONT PANEL)	

HARDWARE LIST

#1	7-685-790-09	SCREW +PTT 2.6X4 (S)
#2	7-685-792-09	SCREW +PTT 2.6X6 (S)
#3	7-685-794-09	SCREW +PTT 2.6X10 (S)
#4	7-627-553-28	SCREW, PRECISION +P 2X2.5
#5	7-624-102-04	STOP RING 1.5, TYPE -E
#6	7-627-552-88	SCREW, PRECISION +P 1.7X2.2
#7	7-685-105-19	SCREW +P 2X8 TYPE2 NON-SLIT
#8	7-627-553-37	SCREW, PRECISION +P 2X3 TYPE3
#9	7-628-253-00	SCREW, SPECIAL
#10	7-627-553-17	SCREW, PRECISION +P 2X2 TYPE3
#11	7-627-850-28	SCREW, PRECISION +P 1.4X3
#12	7-621-255-25	SCREW +P 2X4

Ref. No.	Part No.	Description	Remark
PARTS FOR INSTALLATION AND CONNECTIONS			

401	3-014-370-21	FRAME, FITTING	
402	3-916-012-01	BRACKET (ND), FITTING ASSIST (US)	
403	7-682-160-01	SCREW +P 4X6 (US)	
404	X-3368-725-1	SCREW ASSY, FITTING (US)	
405	3-386-828-01	SCREW, FITTING (AEP,UK,E)	
406	3-349-410-01	BUSHING (AEP,UK,E)	
407	X-3366-405-1	SCREW ASSY (EXP), FITTING (AEP,UK,E)	
408	3-230-445-01	COLLAR	
409	3-934-325-01	SCREW (+K 5X8 TP)	
410	1-465-459-21	ADAPTOR, ANTENNA (AEP,UK,E)	
411	3-030-929-01	SPRING, FITTING	
412	1-776-207-72	CORD (WITH CONNECTOR) (POWER) (US)	
413	1-776-527-71	CORD (WITH CONNECTOR) (ISO) (POWER)	(AEP,UK,E)
414	3-231-993-01	KEY (01)	

